

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [MYPLUS](#) /

› [MYPLUS 16 Inch Under Cabinet Lights User Manual](#)

MYPLUS MYPLUSGG101

MYPLUS 16 Inch Under Cabinet Lights User Manual

Model: MYPLUSGG101

1. INTRODUCTION

Thank you for choosing the MYPLUS 16 Inch Under Cabinet Light. This innovative lighting solution features convenient hand wave activation and adjustable brightness, designed to enhance visibility and ambiance in various indoor spaces. This manual provides detailed instructions for installation, operation, and maintenance to ensure optimal performance and longevity of your product.

2. PRODUCT FEATURES

- **Hand Wave Activation:** Effortlessly turn lights on/off with a simple hand wave (effective distance: 1-3 inches).
- **Adjustable Brightness:** Dimmable by holding your hand beneath the sensor for 1-3 seconds to achieve desired illumination.
- **Memory Function:** Remembers your last brightness setting for consistent lighting.
- **Versatile Application:** Ideal for kitchen countertops, offices, garages, desks, storage rooms, laundry rooms, workbenches, and closets.
- **Sleek Design:** Ultra-thin profile (2cm thickness, 8cm width) for seamless integration.
- **Natural White Light:** 4000K color temperature provides a neutral white light.

3. WHAT'S IN THE Box

The MYPLUS 16 Inch Under Cabinet Light package includes the following components:

- LED Light Bar
- Installation Buckles and Adhesive



Image: All components included in the MYPLUS Under Cabinet Light package.

4. SETUP AND INSTALLATION

The MYPLUS Under Cabinet Light offers flexible installation options using either screws or adhesive pads.

Installation Steps:

1. Choose your desired mounting location under a cabinet, shelf, or desk. Ensure the surface is clean and dry.
2. Decide between screw mounting (for permanent fixture) or adhesive mounting (for easier removal).
3. If using adhesive, attach the provided 3M adhesive pads to the installation buckles.
4. Secure the buckles to the chosen surface. For screw mounting, use the provided screws. For adhesive mounting, press firmly to ensure a strong bond.
5. Snap the LED light bar into the installed buckles.
6. Plug the light into a standard 110V-120V AC power outlet.




Image: Visual guide for installing the light using either screws or adhesive pads.

Installation Video:

Your browser does not support the video tag.

Video: This video demonstrates the installation process of the MYPLUS 16 Inch Hand Wave Under Cabinet Lights, showing how to mount the light and connect it to power.

5. OPERATING INSTRUCTIONS

The MYPLUS Under Cabinet Light features intuitive hand wave controls for ease of use.

Turning On/Off:

Wave your palm horizontally under the sensor once to turn the light on or off. The sensor is effective from a distance of approximately 1-3 inches. Avoid waving multiple times in quick succession or covering the sensor.

Place your hand below the IR sensor for 1-3 seconds to adjust the brightness

The light will remember the brightness until you adjust it again.



Image: Demonstrates the hand wave gesture to activate or deactivate the light.

Adjusting Brightness (Dimming):

To adjust the brightness, place your hand beneath the sensor and hold it there for 1-3 seconds. The light will cycle through its brightness levels. Release your hand when the desired brightness is reached. The light will remember your preferred setting.

430lm

4000K Warm White Light



Image: Illustrates how to dim the light by holding a hand under the sensor.

Operation Video:

Your browser does not support the video tag.

Video: This video demonstrates the hand wave activation and dimming features of the MYPLUS 16 Inch Under Cabinet Lights.

6. MAINTENANCE

To ensure the longevity and optimal performance of your MYPLUS Under Cabinet Light, follow these simple maintenance guidelines:

- Cleaning:** Gently wipe the light bar with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the finish or electronic components.
- Sensor Care:** Keep the hand wave sensor clean and unobstructed for proper functionality. Avoid covering the sensor with objects or liquids.
- Power Disconnection:** Always unplug the light from the power outlet before performing any cleaning or maintenance.

7. TROUBLESHOOTING

If you encounter any issues with your MYPLUS Under Cabinet Light, please refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Light does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure the light is securely plugged into a working outlet. Check your circuit breaker.
Hand wave sensor is unresponsive.	Incorrect hand wave technique; sensor obstructed or covered; sensor too far.	Ensure you are waving your hand horizontally within 1-3 inches of the sensor. Remove any obstructions. Do not cover the sensor.
Brightness adjustment is not working.	Hand not held steady; sensor covered.	Hold your hand steadily beneath the sensor for 1-3 seconds. Ensure the sensor is not covered.

Troubleshooting Video:

Your browser does not support the video tag.

Video: This video provides operational and troubleshooting guidance for the MYPLUS Under Cabinet Light (Model GG111, which is similar to MYPLUSGG101).

8. SPECIFICATIONS

Feature	Detail
Brand	MYPLUS
Model Name	Hand Wave Cabinet Lights
Item Model Number	MYPLUSGG101
Size	16" one-pack
Product Dimensions	16"L x 1.77"W x 1.57"H
Item Weight	7.4 ounces
Color	White
Material	Plastic
Light Source Type	LED
Light Color	4000K Natural White
Wattage	7 watts
Voltage	1.2E+2 Volts (AC)
Power Source	Corded Electric
Control Method	Hand Control
Mounting Type	Under Cabinet
Indoor/Outdoor Usage	Indoor

Feature	Detail
Assembly Required	Yes
Country of Origin	China

9. WARRANTY AND SUPPORT

Specific warranty information is not provided in the product details. For any warranty claims, technical support, or product inquiries, please contact the manufacturer, MYPLUS, directly through their official channels or the retailer where the product was purchased.