



Manuals.plus /

- › **OPPO** /
- › OPPO A98 5G Smartphone User Manual

OPPO A98 5G

OPPO A98 5G Smartphone User Manual

Model: A98 5G | Brand: OPPO

INTRODUCTION TO THE **OPPO A98 5G**

The OPPO A98 5G is a high-performance smartphone designed for seamless connectivity and advanced mobile experiences. It features a large 6.72-inch 120Hz display, a versatile 64MP AI camera system with a 40x microscope lens, and a powerful 5000mAh battery with 67W SUPERVOOC fast charging. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device.



Figure 1: The OPPO A98 5G smartphone in Dreamy Blue, showcasing its design and the included USB-C charging cable.

WHAT'S IN THE BOX

Upon opening your OPPO A98 5G package, please verify that all the following items are present:

- OPPO A98 5G Smartphone (Dreamy Blue)
- USB Cable
- SIM Ejector Tool (typically included, though not explicitly listed in "whats_in_the_box", it's standard for dual-SIM phones)
- Quick Start Guide and Safety Information (may vary by region)

SETUP GUIDE

1. Inserting SIM Cards

The OPPO A98 5G supports Dual-SIM functionality. Use the provided SIM ejector tool to open the SIM tray located on the side of the device. Carefully place your Nano-SIM cards into the designated slots. Ensure the gold contacts face downwards and the notched corner aligns correctly. Gently push the tray back into the phone until it clicks into place.

Important Network Compatibility Note for USA Buyers:

This smartphone is not compatible with CDMA networks, including VERIZON, SPRINT, and US CELLULAR. Please confirm 3G or 4G/LTE compatibility with your network provider before use.

2. Initial Charging

Before first use, it is recommended to fully charge your OPPO A98 5G. Connect the USB cable to the phone's charging port and the other end to a compatible power adapter (not included, but 67W SUPERVOOC is supported) or a computer's USB port. The device features a 5000mAh battery and supports 67W SUPERVOOC fast charging for rapid power replenishment.

67W SUPERVOOC™*



Batería grande de 5000 mAh

La batería que no se agota

* La marca SUPERVOOC y sus logotipos son marcas registradas propiedad de Guangdong OPPO Mobile Telecommunications Corp. Ltd.

Figure 2: The OPPO A98 5G connected to a charger, illustrating the 67W SUPERVOOC fast charging capability and the 5000mAh battery.

3. Powering On and Initial Configuration

Press and hold the Power button (located on the side) until the OPPO logo appears. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, sign in to your Google account, and set up security features like fingerprint or facial recognition.

OPERATING YOUR OPPO A98 5G

Display and Navigation

The device features a 6.72-inch IPS LCD display with a 1080 x 2400 pixel resolution and a 120Hz refresh rate, providing a smooth visual experience. Navigate the Android 13 operating system using intuitive touch gestures.



* La pantalla admite una frecuencia de actualización de hasta 120 Hz. La frecuencia de actualización puede variar en función de la situación. Por favor, consulte el uso real.

Figure 3: The OPPO A98 5G display demonstrating its 120Hz ultra-high refresh rate for smooth scrolling and visuals.

Camera System

The OPPO A98 5G is equipped with a versatile camera setup:

- **Main Camera:** 64 MP, f/1.7, 26mm (wide), PDAF for high-resolution photos.
- **Microscope Camera:** 2 MP, f/3.3, 34mm (microscope) with 40x magnification for capturing intricate details.
- **Depth Camera:** 2 MP, f/2.4, for enhanced portrait mode effects.
- **Front Camera:** 32 MP, f/2.4, 22mm (wide) for clear selfies and video calls.

32MP

Cámara selfie

64MP

Cámara AI

2MP

Cámara de profundidad

40x

Micro lente



Figure 4: A detailed view of the OPPO A98 5G's rear camera module, highlighting the 64MP AI camera, 2MP depth camera, and 40x microlens.



Cámara AI de 64 MP

Detalles que deslumbran

Figure 5: A user holding the OPPO A98 5G, demonstrating the use of its 64MP AI Camera for capturing detailed images.



Figure 6: A composite image showcasing key features of the OPPO A98 5G, including 67W SUPERVOOC charging, 5000mAh battery, 40x microlens, 64MP AI camera, 120Hz display, and RAM expansion up to 8GB.

Performance and Storage

Powered by the Qualcomm SM6375 Snapdragon 695 5G (6 nm) Octa-core processor and 8GB of RAM, the OPPO A98 5G delivers smooth performance for daily tasks and gaming. It comes with 256GB of internal storage, expandable via microSDXC card for additional space.

MAINTENANCE

Battery Care

- Avoid exposing the device to extreme temperatures (hot or cold) as this can degrade battery life.
- Use only OPPO-approved chargers and cables to ensure optimal charging and prevent damage.
- For long-term storage, charge the battery to around 50% and power off the device.

Software Updates

Regularly check for and install system updates to ensure your device has the latest security patches, features, and performance improvements. You can typically find this option in *Settings > About phone > Software update*.

Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of the phone. For stubborn smudges, slightly dampen the cloth with water or a screen cleaner. Avoid using harsh chemicals or abrasive materials.

TROUBLESHOOTING

This section addresses common issues you might encounter with your OPPO A98 5G.

Device Not Powering On

- Ensure the battery is sufficiently charged. Connect the charger and wait a few minutes before attempting to power on again.
- Perform a forced restart by holding the Power button and Volume Up button simultaneously for about 10-15 seconds.

Network Connectivity Issues

- Verify that your SIM card is correctly inserted and activated.
- Check your network settings (*Settings > Mobile network*) to ensure data roaming is enabled if you are abroad.
- Confirm that your network provider supports GSM/LTE/5G bands compatible with this international version of the phone. Remember, it is not compatible with CDMA networks (Verizon, Sprint, US Cellular).
- Try toggling Airplane Mode on and off.

Slow Performance or App Crashes

- Close unnecessary background applications.
- Clear cache for problematic apps (*Settings > Apps > [App Name] > Storage > Clear cache*).
- Ensure you have sufficient free storage space.
- Restart the device.

Charging Problems

- Inspect the USB cable and charging port for any damage or debris.
- Try a different USB cable and power adapter.
- Ensure the power outlet is functional.

TECHNICAL SPECIFICATIONS

Model Name	Oppo A98 (5G)
Dimensions	6.52 x 3 x 0.32 inches (165.6 x 74.3 x 8.2 mm)
Weight	6.8 ounces (192 Grams)
Display	6.72 inches IPS LCD, 1080 x 2400 pixels, 120 Hz Refresh Rate
Operating System	Android 13.0
Processor	Qualcomm SM6375 Snapdragon 695 5G (6 nm), Octa-core (2x2.2 GHz Kryo 660 Gold & 6x1.7 GHz Kryo 660 Silver)
RAM	8 GB
Internal Storage	256 GB (expandable via microSDXC)
Main Camera	64 MP (wide), 2 MP (microscope), 2 MP (depth)
Front Camera	32 MP (wide)
Battery	5000 mAh Lithium Polymer (non-removable), 67W SUPERVOOC fast charging
Audio Jack	3.5 mm
Connectivity	Wi-Fi, Cellular (2G, 3G, 4G LTE, 5G), GPS
Color	Dreamy Blue

74.3 mm

156.6 mm



Frecuencia de actualización ultra alta de 6,72" y 120 Hz

Peso: 192g

8.2 mm

Figure 7: Technical diagram illustrating the dimensions and weight of the OPPO A98 5G smartphone.

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the warranty card included with your product or visit

the official OPPO website. Keep your proof of purchase for warranty claims.

OPPO Official Website: www.oppo.com