OLIGHT IMINI2-ODG-300000

OLIGHT IMINI 2 EDC Rechargeable Keychain Flashlight User Manual

Brand: OLIGHT | Model: IMINI2-ODG-300000

1. Introduction and Overview

The OLIGHT IMINI 2 is an ultra-compact and portable LED keychain flashlight, designed for convenience and reliability in everyday situations and emergencies. Its innovative design allows for instant activation and hands-free operation, making it an essential tool for any user.

- **Single Output:** The IMINI 2 produces a wide and balanced output of 50 lumens, providing ample light for close-range tasks.
- **Instant Activation:** Simply detaching the body from the magnetic cap turns the light on, ensuring immediate access to illumination when needed most.
- **Rechargeable Design:** An integrated USB plug at the tail allows for direct insertion into any USB adapter for charging, achieving a full charge within 60 minutes.
- **Hands-Free Experience:** Equipped with a magnetic base, the mini light can attach to any iron surface, freeing both hands for other tasks.
- **Mini and Compact:** Measuring only 55 mm long and weighing just 19.5g (0.69oz), its lightweight aluminum body is barely noticeable on your keychain and offers 1.5 meters of drop resistance.



Figure 1: The OLIGHT IMINI 2 EDC Rechargeable Keychain Flashlight in OD Green.



Figure 2: The compact size of the IMINI 2, shown next to a wireless earbud for scale.




Figure 3: Detailed output specifications including lumen, runtime, throw, and candela.

2. What's in the Box

Your OLIGHT IMINI 2 package includes the following items:

- imini 2 x 1 (Keychain Flashlight)
- USB Port Cover x 2 (one pre-installed, one spare)
- Key Chain x 1 (Carabiner-style clip)
- User Manual x 1 (This document)



Figure 4: All items included in the OLIGHT IMINI 2 product package.

3. Setup

Initial Charging

Before first use, it is recommended to fully charge your IMINI 2 flashlight. The integrated USB plug makes charging simple and convenient.

1. Gently remove the protective USB port cover from the tail of the flashlight.
2. Insert the exposed USB plug directly into any standard USB-A port (e.g., on a computer, wall adapter, or power bank).
3. The indicator light on the flashlight will turn red to show it is charging.
4. Once fully charged (approximately 60 minutes), the indicator light will turn green.
5. After charging, replace the protective USB port cover to protect the plug from dust and moisture.



Figure 5: The IMINI 2 features an integrated USB plug for direct charging without cables.



Figure 6: The red indicator light signifies that the flashlight is currently charging.

Attaching to Keychain

Use the provided carabiner-style key chain to easily attach your IMINI 2 to your keys, bag, or other gear for convenient

everyday carry.

4. Operating Instructions

Turning On/Off

The IMINI 2 features an intuitive instant activation mechanism:

- **To Turn On:** Simply pull the flashlight body away from its magnetic cap. The light will instantly illuminate.
- **To Turn Off:** Reattach the flashlight body to its magnetic cap. The light will automatically turn off.



Figure 7: The flashlight activates instantly when separated from its magnetic cap.

Hands-Free Use

The strong magnetic base of the IMINI 2 allows for convenient hands-free lighting:

- Once activated, attach the magnetic base of the flashlight to any ferrous metal surface.
- This allows you to direct light where needed while keeping both hands free for tasks such as repairs, reading, or navigating in low-light conditions.



Figure 8: Utilize the magnetic base for convenient hands-free illumination.

5. Maintenance

Charging

To ensure optimal performance, regularly charge your IMINI 2. The integrated USB plug simplifies this process, eliminating the need for separate charging cables.

- Always ensure the USB port is clean and free of debris before charging.
- Use the provided USB port covers to protect the charging contacts when not in use. Two covers are included for convenience.

General Care

- Keep the flashlight clean by wiping it with a soft, dry cloth.
- Avoid dropping the flashlight from excessive heights, although it is designed with 1.5 meters of drop resistance.
- Store the flashlight in a cool, dry place when not in use for extended periods.

6. Troubleshooting

If you encounter any issues with your OLIGHT IMINI 2, please refer to the following common troubleshooting tips:

- **Light Not Turning On:** Ensure the flashlight is fully charged. Verify that the magnetic connection between the body and the cap is clean and free of obstructions.
- **Charging Issues:** Check that the USB plug is fully inserted into a working USB-A port. Ensure the charging contacts on the flashlight are clean.
- **Weak Light Output:** This typically indicates a low battery. Recharge the flashlight fully.

For further assistance, please contact OLIGHT customer support.

7. Specifications

Feature	Detail
Special Feature	Lightweight
Color	OD Green
Power Source	Battery Powered
Light Source Type	LED

Feature	Detail
Material	Aluminum
White Brightness	50 Lumens
Product Dimensions	0.59"D x 0.59"W x 2.17"H
Voltage	3.7 Volts
Light Path Distance	1.5 Meters
Battery Cell Composition	Lithium Ion
Item Weight	0.69 Ounces
Number of Batteries	1 Lithium Ion batteries required. (included)
Water Resistance Level	Waterproof
Runtime	1 hour
Country of Origin	China
Date First Available	July 5, 2023

8. Warranty and Support

The OLIGHT IMINI 2 EDC Rechargeable Keychain Flashlight comes with a**Lifetime warranty***, ensuring long-term reliability and peace of mind.

For detailed warranty information, technical support, or any inquiries not covered in this manual, please refer to the official OLIGHT website or contact their customer service directly.

You can also find a downloadable PDF version of the user manualhere.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question