

[Manuals.plus](#) /

› [SEDETA](#) /

› SEDETA L-Shaped Gaming and Home Office Desk with LED Lights (Model 80-I shaped desk) - Instruction Manual

SEDETA 80-I shaped desk

SEDETA L-Shaped Gaming and Home Office Desk with LED Lights

Model: 80-I shaped desk - Instruction Manual

1. INTRODUCTION

Thank you for choosing the SEDETA L-Shaped Gaming and Home Office Desk. This manual provides detailed instructions for the safe assembly, proper operation, and effective maintenance of your new desk. Please read this manual thoroughly before beginning assembly or use to ensure optimal performance and longevity of your product.




Image 1.1: Overview of the SEDETA L-Shaped Gaming and Home Office Desk with LED lighting.

2. SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- **Assembly:** Always assemble the desk on a soft, clean surface to prevent scratches. It is recommended that two adults assemble this desk.
- **Stability:** Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten hardware as needed.
- **Weight Capacity:** Do not exceed the recommended weight capacity for any part of the desk. Distribute weight evenly.
- **Electrical Components:** Handle LED lights and associated wiring with care. Do not expose to water or excessive moisture. Ensure power supply is disconnected during installation or maintenance.
- **Children:** Keep small parts and packaging materials away from children during assembly to prevent choking hazards.

3. PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer service.

- L-Shaped Desk Panels (Main desktop, return desktop)
- Top Hutch with Storage Compartments
- Metal Frame Components
- Keyboard Tray
- CPU Tower Shelf
- Storage Bag (Fabric)
- Headphone Hook
- RGB LED Light Strip with Remote Control
- Assembly Hardware (Screws, Allen wrench, etc.)
- Instruction Manual

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is highly recommended to have two people for assembly.

4.1. Choose Your Configuration

The SEDETA desk offers a reversible design, allowing for L-shaped or long desk configurations. Plan your desired layout before starting assembly.

Corner installation



Image 4.1: Available desk configurations and key dimensions.




Image 4.2: Example of a U-shaped setup using two reversible desks.

4.2. General Assembly Tips

- Lay out all parts and hardware on a soft, clean surface.
- Do not fully tighten screws until all components for a section are loosely assembled. This allows for minor adjustments.
- Refer to the included graphical instruction manual for step-by-step diagrams.

4.3. Main Desk Assembly

1. Assemble the metal frames for the main desk sections.
2. Attach the desktop panels to the assembled frames. Ensure proper orientation for your chosen L-shape or long desk configuration.
3. Secure the connecting plates between the desk sections if forming an L-shape.

4.4. Hutch Assembly

1. Assemble the hutch frame and shelves.
2. Attach the hutch to the main desktop. The hutch can be positioned on either the left or right side of the desk.



Image 4.3: Detail of the top hutch for storage.

4.5. Accessory Installation

1. **Keyboard Tray:** Install the sliding rails and attach the keyboard tray beneath the main desktop.



21.7" Keyboard Tray >>>
Perfect for 108-key or 87-key keyboard + mouse

Image 4.4: Detail of the 21.7-inch keyboard tray.

2. **Storage Bag:** Hook the fabric storage bag onto the designated frame points.



Image 4.5: Detail of the side-mounted storage bag.

3. **Headphone Hook:** Attach the headphone hook to the desired location on the desk frame.



Image 4.6: Detail of the headphone hook.

4. **CPU Tower Shelf:** Position the CPU tower shelf as indicated in the manual.

4.6. LED Light Installation

1. Carefully adhere the LED light strip to the underside of the hutch or desired desk edges.

2. Connect the LED strip to the power supply and controller.

5. OPERATING INSTRUCTIONS

5.1. LED Light Operation

The integrated RGB LED lights offer various customization options:

- **Remote Control:** Use the included remote to power on/off, change colors (over 60,000 options), adjust brightness, and select from 29 flashing modes.
- **APP Control:** Download the compatible smartphone application to control the LED lights. The app provides advanced features including music sync and timing functions.
- **Music Sync:** The built-in sensitivity-adjustable microphone allows the LED light colors to change in rhythm with sound and music.



Image 5.1: LED light control features and options.

5.2. Utilizing Desk Features

- **Keyboard Tray:** Slide the tray in and out as needed for comfortable keyboard and mouse placement.
- **Storage Bag:** Use the fabric bag for documents, magazines, or other small items to keep your desktop clear.
- **Headphone Hook:** Hang your headphones on the hook for easy access and to keep them off the desk surface.
- **Hutch:** Utilize the top hutch shelves for monitors, books, decorative items, or additional storage.

6. MAINTENANCE

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as necessary to maintain desk stability.
- **LED Lights:** Keep the LED strip and controller free from dust. Do not attempt to repair damaged LED components; contact customer service if issues arise.

7. TROUBLESHOOTING

If you encounter any issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
LED lights do not turn on.	Power connection loose; remote battery dead; LED strip damaged.	Check all power connections. Replace remote battery. If still not working, contact customer service.
Desk feels wobbly after assembly.	Screws not fully tightened; uneven floor.	Ensure all assembly screws are fully tightened. Use furniture levelers if your floor is uneven.
Parts do not align during assembly.	Incorrect orientation of parts; screws overtightened prematurely.	Review the instruction manual for correct part orientation. Loosen all screws in the section, adjust parts, then re-tighten evenly.
Missing or damaged parts.	Shipping damage; packaging error.	Do not proceed with assembly. Contact SEDETA customer service immediately for replacement parts.

8. SPECIFICATIONS

Feature	Detail
Brand	SEDETA
Model Number	80-I shaped desk
Shape	L-Shape (Reversible)
Product Dimensions (D x W x H)	19.7"D x 67"W x 57"H
Color	Walnut

Feature	Detail
Style	Gaming / Home Office
Base Material	Metal
Top Material Type	Wood (Walnut finish)
Special Features	Keyboard Tray Included, Reversible Design, LED Lights, Storage Shelves, Headphone Hook
Included Components	Headphone Hook, Keyboard Tray, Storage Bag, Top Hutch, CPU Tower Shelf
Item Weight	80 Pounds
Required Assembly	Yes

9. WARRANTY AND CUSTOMER SUPPORT

SEDETA is committed to providing high-quality products and customer satisfaction. If your desk arrives damaged, scratched, or with missing parts, please do not hesitate to contact our professional after-sales customer service team. We aim to address your concerns within 24 hours.

For support, please refer to the contact information provided with your purchase or visit the official SEDETA website.