Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LG 75UR8750PSA

LG 75UR8750PSA 75-inch 4K UHD AI ThinQ Smart TV Instruction Manual

Model: 75UR8750PSA

Introduction

This manual provides essential information for the safe and efficient operation of your LG 75UR8750PSA 75-inch 4K UHD AI ThinQ Smart TV. Please read it thoroughly before using the product and retain it for future reference.



Figure 1: Front view of the LG 75UR8750PSA 75-inch 4K UHD Smart TV with its remote control, displaying a vibrant floral image.

Setup

1. Unpacking

- Carefully remove the TV and all accessories from the packaging.
- Retain the packaging materials for future transport or service.

2. Stand Installation

Attach the stand to the TV following the instructions provided in the separate assembly guide. Ensure all screws are securely fastened.



Figure 2: Close-up view of the stand for the LG 75UR8750PSA 75-inch 4K UHD Smart TV, illustrating its design and attachment points.

3. Wall Mounting (Optional)

If wall-mounting, use a VESA-compliant wall mount kit (sold separately) and follow the instructions provided with the mount. Consult a professional for installation to ensure safety.

4. Connecting External Devices

Connect your external devices (e.g., cable box, Blu-ray player, gaming console) to the TV's input ports.

- **HDMI Ports:** Connect high-definition devices. This TV features multiple HDMI inputs.
- **USB Ports:** Connect USB storage devices for media playback. This TV includes 2 USB ports.
- **Optical Digital Audio Out:** Connect to a soundbar or audio receiver for enhanced sound.
- **LAN Port:** Connect an Ethernet cable for a wired internet connection.
- **Antenna/Cable Input:** Connect an antenna or cable for broadcast TV.



Figure 3: Detailed view of the input ports on the back of the LG 75UR8750PSA 75-inch 4K UHD Smart TV, including HDMI, USB, Optical Digital Audio Out, and LAN.

Operating the TV

1. Power On/Off

Connect the power cord to an electrical outlet. Press the Power button on the remote control or the TV to turn it on or off.

2. Remote Control

The included remote control allows you to navigate menus, adjust settings, and access smart features. This TV includes a universal remote control with Bluetooth technology.



Figure 4: A person using the LG Magic Remote to control the TV while watching a dynamic motorcycle racing scene.

3. webOS 23 Smart Features

Your LG Smart TV runs on webOS 23, offering an intuitive interface for accessing content and applications.

- **My Profile:** Get personalized movie recommendations and special notifications.

- **AI Concierge:** Provides tailored content suggestions.
- **Quick Cards:** Organize your favorite apps and services for quick access.




Figure 5: Screenshot of the LG webOS interface with ThinQ AI, showing personalized profiles, AI Concierge, and quick access cards.

Picture and Sound Features

1. 4K REAL and HDR10 Pro

Experience realistic image quality and vivid colors with 4K REAL. HDR10 Pro delivers optimized brightness levels for vibrant colors and remarkable detail.



Figure 6: LG UHD TV displaying a vast snowy landscape, illustrating the immersive viewing experience of 4K REAL.

2. α5 AI Processor 4K Gen6

The α5 AI Processor 4K Gen6 automatically analyzes and optimizes both picture and sound. It enhances conventional images to 4K resolution with greater clarity and precision using its 4K Upscaler.

- **AI Brightness Control:** Ensures the perfect brightness level for any environment by adapting to ambient lighting.
- **AI Sound Pro:** Improves audio by converting 2.0 channel sound to virtual 5.1 surround sound.



Figure 7: Graphic illustrating the LG α5 AI Processor 4K Gen6, highlighting AI Brightness Control and AI Sound Pro features.

3. FILMMAKER MODE

With FILMMAKER MODE, movies are displayed preserving the original color and settings as intended by the creators.



Figure 8: Image depicting a cinematic viewing experience on the LG 75UR8750PSA TV, showcasing various streaming service logos.

Gaming Features

Enjoy high-speed HDR gaming with the latest gaming specifications, including ALLM (Auto Low Latency Mode), eARC (enhanced Audio Return Channel), and HGiG (HDR Gaming Interest Group).

Game Optimizer and Dashboard

Optimize your gaming experience with Game Optimizer and Dashboard. Access a variety of settings in a single menu for quick and intuitive operation.



Figure 9: Screenshot of the LG Game Optimizer dashboard, displaying settings for FPS, VRR, Black Stabilizer, and Low Latency for an optimized gaming experience.

Connectivity

Your LG Smart TV offers diverse connectivity options:

- **Wi-Fi:** Built-in Wi-Fi for wireless internet access.
- **Bluetooth:** Connect compatible Bluetooth devices, such as headphones or soundbars.
- **HDMI:** Multiple HDMI ports for high-definition audio and video input.
- **USB:** Two USB ports for connecting storage devices.
- **Smart Home Integration:** Works with Apple AirPlay, Apple Home, and Matter for seamless integration into your smart home ecosystem.
- **Voice Assistants:** Features multiple voice assistant support, including Alexa built-in.



Figure 10: Screenshot of the LG TV's 'Wow Interface' showing diversified sound output configurations, including Bluetooth, Optical Out, and HDMI (ARC) options.



Figure 11: Logos for smart assistants and connectivity features of the LG 75UR8750PSA TV, including Matter, Alexa built-in, Apple AirPlay, and Apple Home.

Maintenance

Cleaning the TV

- Always unplug the TV before cleaning.
- Use a soft, dry cloth to wipe the screen and cabinet.
- For stubborn marks, lightly dampen the cloth with water or a mild screen cleaner. Do not spray cleaner directly onto the screen.
- Avoid using abrasive cleaners, waxes, or solvents.

Troubleshooting

If you encounter issues with your TV, refer to the following common solutions:

- **No Power:** Ensure the power cord is securely plugged into both the TV and a working electrical outlet.
- **No Picture/Sound:** Check that the correct input source is selected. Verify all cables are securely connected.
- **Remote Control Not Working:** Replace the batteries. Ensure there are no obstructions between the remote and the TV.
- **Network Connection Issues:** Restart your router and modem. For Wi-Fi, ensure the TV is within range. For wired connections, check the Ethernet cable.
- **Smart Features Not Responding:** Try restarting the TV by unplugging it for a few minutes and then plugging it back in.

For more detailed troubleshooting, consult the full electronic manual available on the LG support website.

Specifications




Figure 12: Diagram illustrating the dimensions of the LG 75UR8750PSA 75-inch 4K UHD Smart TV.

Feature	Detail
Brand	LG
Model	75UR8750PSA
Model Year	2023
Screen Size	75 Inches
Display Technology	LED
Display Type	UHD
Resolution	3840 x 2160 Pixels (4K)
Refresh Rate	60 Hz
Operating System	WebOS
Special Features	Multiple Voice Assistance, Browser, Flat Screen
Connectivity Technology	Bluetooth, HDMI, USB, Wi-Fi
Total USB Ports	2
Audio Output Mode	Surround
Speaker Surround Sound Channel Configuration	5.1
Output Wattage	20 Watts

Feature	Detail
Power Source	Corded Electric
Mounting Type	Table Mount
Product Dimensions (WxDxH)	167.8 x 36.1 x 102.7 cm
Product Weight	31.8 kg
Included Components	Remote control, User manual, Warranty card

Warranty and Support

Your LG 75UR8750PSA TV comes with a warranty. Please refer to the included warranty card for details on coverage and terms. For technical support, service, or additional information, please visit the official LG support website or contact LG customer service. You can find more information and support at the LG Electronics Store on Amazon.

© 2023 LG Electronics. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C584T3RZ

More documents and user manuals: **https://manuals.plus/**