

XIAOMI BHR4562GL

Xiaomi Handheld Vacuum Cleaner User Manual

Model: BHR4562GL | Brand: XIAOMI

[Safety Information](#) [Package Contents](#) [Product Overview](#) [Setup](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Xiaomi Handheld Vacuum Cleaner. Please read it thoroughly before using the device and retain it for future reference. The Xiaomi Handheld Vacuum Cleaner is a compact and powerful cleaning device designed for quick and efficient cleanups in various environments, including homes and vehicles. Its lightweight design and strong suction make it ideal for tackling dust, debris, and pet hair.

SAFETY INFORMATION

- Always ensure the vacuum cleaner is fully charged before first use.
- Do not use the device to vacuum liquids, hot ashes, or sharp objects.
- Keep the device away from water and high humidity.
- Do not expose the vacuum cleaner to direct sunlight for extended periods, especially in hot environments like a car on a summer day, to prevent damage.
- Keep out of reach of children.
- Use only the provided USB-C cable for charging.
- Ensure the dust cup and filters are properly installed before operation.

PACKAGE CONTENTS

Upon unpacking, verify that all items listed below are present and in good condition:

- Xiaomi Handheld Vacuum Cleaner (Main Unit)
- Crevice Nozzle

- Brush Nozzle
- USB-C Charging Cable
- User Manual (this document)



Image: The Xiaomi Handheld Vacuum Cleaner with its included accessories: the main vacuum unit, a crevice nozzle, a brush nozzle, and a USB-C charging cable.

PRODUCT OVERVIEW

The Xiaomi Handheld Vacuum Cleaner features a sleek, minimalist design, making it both functional and aesthetically pleasing. It is designed for ease of use and portability.





Image: The main unit of the Xiaomi Handheld Vacuum Cleaner, showcasing its compact and cylindrical design in white.

Key Components:

- **Main Unit:** Houses the motor, battery, and control button.
- **Dust Cup:** Transparent section where collected debris is stored. Features a slide-and-lock design to prevent accidental opening.
- **Primary Steel Filter:** Filters out larger particles.

- **HEPA Filter Core:** Filters out >99.5% of dust and minuscule particles.
- **Power Button:** Single button for operation (power on/off, switch suction levels).
- **USB-C Charging Port:** Located at the bottom for convenient charging.



Slide-and-lock design
for prevention of accidental dust cup
opening

Removable steel primary filter
for filtering out larger particles

HEPA Filter core
for filtering out >99.5% of dust and
miniscule particles

Image: An exploded view illustrating the slide-and-lock dust cup design, the removable steel primary filter, and the HEPA filter core for effective particle filtration.

SETUP

1. Initial Charging:

Before first use, fully charge the vacuum cleaner. Connect the provided USB-C cable to the charging port at the bottom of the device and plug the other end into a compatible USB power source. A full charge typically takes approximately 1.5 hours. The indicator light will show charging status.



Image: The bottom of the vacuum cleaner showing the USB-C charging port, with a charging cable connected. The device can be charged using a power bank for portability.

2. Attaching Accessories:

Select the appropriate nozzle for your cleaning task. The crevice nozzle is ideal for narrow spaces, while the brush nozzle is suitable for delicate surfaces like keyboards or upholstery.

1. Align the chosen nozzle with the opening of the dust cup.
2. Gently push and twist until it is securely attached.

OPERATING INSTRUCTIONS

Powering On/Off and Suction Levels:

The vacuum cleaner features a single power button for simplified operation.

1. **To Power On (Low Gear):** Press the power button once. The device will start in low gear, providing approximately 30 minutes of battery life.
2. **To Switch to High Gear:** Press the power button a second time while the device is running. This activates the high suction mode, offering approximately 9 minutes of battery life for more demanding tasks.
3. **To Power Off:** Press the power button a third time. The device will shut down.



Image: Illustration showing the two suction speed levels: Low gear for 30 minutes of battery life and High gear for 9 minutes of battery life.

Usage Scenarios:

The compact and powerful design of the Xiaomi Handheld Vacuum Cleaner makes it versatile for various cleaning needs:

- **Vehicle Interiors:** Easily clean crumbs, dust, and debris from car seats, floor mats, and hard-to-reach crevices.
- **Home Use:** Perfect for quick cleanups on sofas, shelves, tabletops, and other surfaces.
- **Pet Hair:** Effectively picks up pet hair from upholstery and carpets.
- **Electronics:** Use the brush attachment to gently clean dust from keyboards and other sensitive electronics.



Image: A collage demonstrating the vacuum cleaner's versatility, showing it cleaning furniture crevices, car interiors, and keyboard gaps.

Your browser does not support the video tag.

Video: A full walkthrough review of the Xiaomi Mini Handheld Vacuum, demonstrating its features, accessories, and cleaning capabilities on various surfaces like sofas, shelves, and keyboards. It also covers charging and bin emptying.

MAINTENANCE

1. Emptying the Dustbin:

To maintain optimal suction performance, empty the dustbin regularly, especially after each significant use.

1. Ensure the vacuum cleaner is turned off.
2. Locate the dust disposal button/latch on the top of the dust cup.
3. Press the button to open the dust cup lid and empty the contents into a waste bin.



Image: The vacuum cleaner's dust cup opened, demonstrating the one-click dust disposal mechanism that keeps hands clean.

2. Cleaning and Replacing Filters:

The Xiaomi Handheld Vacuum Cleaner uses a dual-filter system for efficient cleaning. Regular cleaning of the filters is crucial for maintaining performance.

1. Twist the top section of the vacuum cleaner to detach the dust cup assembly.
2. Carefully remove the primary steel filter and the HEPA filter core.
3. Tap the filters gently to remove loose dust. For thorough cleaning, the steel filter is washable. The HEPA filter can be cleaned with a brush or by blowing air through it (e.g., using the exhaust end of the vacuum).
4. Ensure filters are completely dry before reassembling.
5. Replace filters if they are damaged or excessively clogged.



Image: The removable steel primary filter and HEPA filter core, shown being cleaned with water, highlighting their washable design for easy maintenance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Low battery; charging issue.	Ensure the device is fully charged. Check USB-C cable and power source.
Weak suction power.	Full dustbin; clogged filters; improper assembly.	Empty the dustbin. Clean or replace filters. Ensure dust cup and nozzles are securely attached.
Short battery life.	Using high suction mode excessively; aging battery.	Use low gear for general cleaning. Ensure full charge before use. If battery life significantly degrades, contact support.
Device makes unusual noise.	Obstruction in nozzle or dust cup; motor issue.	Check for and remove any obstructions. If noise persists, contact customer support.

SPECIFICATIONS

- **Brand:** XIAOMI
- **Model:** BHR4562GL
- **Product Dimensions:** 2.2"L x 2.2"W x 10.5"H (5.5 cm diameter x 26.7 cm height)
- **Item Weight:** 1.1 pounds (0.5 kg)
- **Power:** 120 Watts
- **Suction Strength:** 13,000 Pa
- **Motor Speed:** 88,000 RPM (Rotations Per Minute)
- **Battery:** 2000 mAh Lithium Ion (included)
- **Runtime:** Up to 30 minutes (Low Gear), Up to 9 minutes (High Gear)
- **Charging:** USB-C (approx. 1.5 hours for full charge)
- **Filter Type:** Dual filter with HEPA filter core and removable steel primary filter

- **Special Feature:** Bagless, Cordless, Portable
- **Included Components:** Crevice Tool, Upholstery Brush (Brush Nozzle)
- **Control Method:** Push Button / Touch
- **Indoor/Outdoor Usage:** Indoor



Image: An internal view highlighting the powerful brushless motor and dual-vent design, which reduces energy loss and improves cleaning efficiency. The quick start/stop feature prevents dust from settling in the nozzle.

WARRANTY & SUPPORT


Your Xiaomi Handheld Vacuum Cleaner is covered by a manufacturer's warranty. For detailed warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official Xiaomi website.

For technical support, troubleshooting assistance, or warranty claims, please contact Xiaomi Customer Service through their official channels. Keep your purchase receipt and product model number (BHR4562GL) handy when contacting support.


You can visit the official Xiaomi Store for more information:[Xiaomi Store on Amazon](#)



Related Documents - BHR4562GL


<div>Xiaomi 6A Type-A to Type-C Cable</div>	<div>Xiaomi 6A Type-A to Type-C Cable User Guide User guide for the Xiaomi 6A Type-A to Type-C Cable, including compliance information and WEEE disposal instructions in multiple languages.</div>
---	--



Detailed user manual for the Xiaomi Mi Handheld Vacuum Cleaner (SCWXCQ01RR). Covers safety, setup, operation, maintenance, troubleshooting, specifications, and warranty information for optimal use.



<div>SMARTM M J I A Store</div> <div></div>	<div>Xiaomi Mijia Car Vacuum Cleaner User Manual</div> <div>User manual for the Xiaomi Mijia Car Vacuum Cleaner (Model MJXCQ01QW), detailing usage, battery status, accessory functions, dustbin emptying, maintenance, troubleshooting, and technical specifications. Learn how to operate, clean, and maintain your device for optimal performance.</div>
<div>SMARTM M J I A Store</div> <div></div>	<div>Xiaomi Vacuum Cleaner G20 User Manual - Comprehensive Guide</div> <div>This document provides a comprehensive user manual for the Xiaomi Vacuum Cleaner G20. It covers safety instructions, product overview, installation guides, charging procedures, usage tips, care and maintenance, troubleshooting common issues, technical specifications, environmental notices, and warranty information.</div>



[\[pdf\]](#)

PowerPoint Presentation SHEPLYAKOVA Darya Беспроводные пылесосы Tefal Все беспроводные имеют универсальную щетку с электроприводом прекрасный результат на любом покрытии без необходимости менять насадки 100049816859bi01 main cdn sbermegamarket ru hlr system 204 684 762 751 712 21 |||

Tefal : , , 2- 4- , , , , : , , ... 10 BLDC- 7 990 Kitfort -578 80 24 /5 0,7 0,5 . BLDC- 5 190

Xiaomi Mi Vacuum Cleaner mini **BHR4562GL** Kitfort -557 80 6 30 /5 50 30 /5 - 0,5 0,1
 . USB BLDC- - 1,6 0,6 . 3 9...

lang:en score:13 filesize: 8.47 M page_count: 125 document date: 2022-06-22

[illegible]

ComX-Computers & LaptopDirect Product Price Guide

A comprehensive listing of products, prices, and descriptions from ComX-Computers and LaptopDirect, including various electronics, home appliances, and accessories.

Valid as of June 30, 2021.

lang:en score:11 filesize: 4.66 M page_count: 1444 document date: 2021-06-30