iTOMA 205

iTOMA Wireless Alarm Clock User Manual

Model: 205

Introduction

Thank you for choosing the iTOMA Wireless Alarm Clock. This device combines a digital alarm clock with a Bluetooth speaker, FM radio, and convenient dual charging capabilities (wireless and USB). This manual provides detailed instructions to help you set up, operate, and maintain your new alarm clock, ensuring optimal performance and longevity.

Product Overview

Package Contents

- iTOMA Wireless Alarm Clock (Model 205)
- Power Adapter
- FM Wire Antenna
- User Manual

Device Layout and Features



Image Description: The iTOMA alarm clock, black and white, featuring a large digital display. A smartphone is placed on top for wireless charging, indicated by a blue glow. A smartwatch is connected via a USB cable to the side for wired charging. This image highlights the dual charging capabilities.



Image Description: The iTOMA alarm clock is shown on a bedside table, with its digital display showing the time. Below the image, a row of icons visually represents the key features of the device: Volume, Snooze, Dual Alarm, LED Decor, Dimmer, USB Port, FM Radio, and Wireless Charging.

Setup

Power Connection

Connect the provided power adapter to the DC IN port on the back of the alarm clock and plug it into a standard wall outlet. The display will light up, indicating the unit is powered on.

Initial Time Setting

1. Press and hold the **CLOCK SET** button. The hour digits will flash.
2. Use the **HR+** or **HR-** buttons to adjust the hour.
3. Press the **CLOCK SET** button again. The minute digits will flash.
4. Use the **MIN+** or **MIN-** buttons to adjust the minutes.
5. Press **CLOCK SET** one more time to confirm and exit time setting mode.

Operating Instructions

Setting the Alarm (Dual Alarm)




Image Description: A detailed view of the top control panel of the iTOMA alarm clock. It highlights the two alarm settings, AL1 and AL2, with clear indicators for choosing between a buzzer sound or FM radio as the wake-up source. Numbered circles (1 and 2) point to the respective alarm controls.

The iTOMA alarm clock features two independent alarms (AL1 and AL2) that can be set to wake you up with either a buzzer or FM radio.

1. To set Alarm 1, slide the **AL1** switch to **SET**. The alarm time will flash.
2. Use **HR+** and **MIN+** buttons to set the desired alarm time.
3. Slide the **AL1** switch to select **FM** (radio) or **BUZZER**.
4. Slide the **AL1** switch to **ON** to activate the alarm.
5. Repeat for Alarm 2 using the **AL2** switch.
6. To turn off an alarm, slide its respective switch to **OFF**.
7. To use the snooze function, press the **SNOOZE** button when the alarm sounds. The alarm will pause for 9 minutes and then sound again.

FM Radio Operation



Image Description: The iTOMA alarm clock is positioned on a white desk next to a laptop, illustrating its use in a workspace. The display shows a time, and graphic elements around the clock indicate FM radio frequencies (e.g., FM 86.8, FM 100.2, FM 93.3), emphasizing its FM radio capability.

Enjoy your favorite FM radio stations with clear reception.

1. Extend the FM wire antenna for better reception.
2. Press the **ON/OFF** button to turn on the radio.
3. Press the **FM** button to switch to FM radio mode.
4. Press and hold the **MEM./STO.** button to auto-scan and save available stations. The clock can store up to 20 preset stations.
5. Use the **PREV** or **NEXT** buttons to navigate through preset stations.
6. To manually tune, press the **HR+** or **HR-** buttons to fine-tune the frequency.
7. Adjust the volume using the **VOL+** or **VOL-** buttons.
8. To set the sleep timer, press the **SLEEP** button repeatedly to cycle through sleep times (10-90 minutes). The radio will automatically turn off after the selected duration.

Bluetooth Connectivity



Image Description: This image shows a hand holding a smartphone displaying a music player interface, positioned next to the iTOMA alarm clock. The text "Listen to Your Music via BLUETOOTH" is prominently displayed, indicating the clock's capability to stream audio wirelessly from a Bluetooth-enabled device.

Stream your favorite music wirelessly from your smartphone or tablet.

1. Press the **BT** button to switch to Bluetooth mode. The Bluetooth indicator on the display will flash.
2. On your device (smartphone, tablet), enable Bluetooth and search for "iTOMA 205" (or similar name).
3. Select the device to pair. Once connected, the Bluetooth indicator will stop flashing and remain solid.
4. You can now play audio from your device through the alarm clock's speaker.
5. Use the **PLAY/PAUSE** and **PREV/NEXT** buttons on the alarm clock to control playback.

Wireless and USB Charging

The iTOMA alarm clock offers convenient charging options for your devices.

- **Wireless Charging:** Place your Qi-enabled smartphone on the wireless charging pad located on top of the alarm clock. Ensure the phone is centered for optimal charging. A charging indicator will appear on the phone's screen.
- **USB Charging:** Connect your device's USB charging cable to the USB charging port on the back of the alarm clock. This port provides power to charge your device.

Display Dimmer and Night Light



Image Description: This image illustrates the dimmer control feature of the iTOMA alarm clock. It shows four distinct display brightness levels: OFF, L-1 (low), L-2 (medium), and L-3 (high). A slider bar below visually represents the brightness range from 0% to 100%, demonstrating the adjustable display intensity.

Adjust the display brightness to your preference and utilize the integrated night light.

- **Display Dimmer:** Press the **DIMMER** button repeatedly to cycle through 4 brightness levels (L-3, L-2, L-1, OFF). The display can also automatically adjust brightness based on ambient light.
- **Night Light:** Press the **LED** button to turn on the night light. Press again to cycle through two night light modes or turn it off.

Maintenance

To ensure the longevity and proper functioning of your iTOMA alarm clock, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the unit. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.
- **Placement:** Place the unit on a stable, flat surface away from direct sunlight, heat sources, and excessive moisture.
- **Power:** Disconnect the power adapter if the unit will not be used for an extended period.

Troubleshooting

If you encounter any issues with your iTOMA alarm clock, please refer to the table below for common problems and their solutions.

Problem	Possible Cause	Solution
Clock display is blank.	No power.	Ensure the power adapter is securely connected to the unit and a working power outlet.
Alarm does not sound.	Alarm not activated or set incorrectly.	Check that the AL1/AL2 switch is set to ON and the alarm time is correctly set. Ensure volume is not at minimum.
Poor FM radio reception.	Antenna not extended or interference.	Fully extend the FM wire antenna. Try repositioning the antenna or the unit to reduce interference.
Bluetooth device won't pair.	Bluetooth not in pairing mode or device too far.	Ensure the alarm clock is in Bluetooth pairing mode (indicator flashing). Move your device closer to the alarm clock. Restart both devices.
Wireless charging not working.	Phone not Qi-enabled or misaligned.	Ensure your phone supports Qi wireless charging. Realign the phone on the charging pad, ensuring it is centered. Remove any thick phone cases.

Specifications



Image Description: A clear diagram illustrating the physical dimensions of the iTOMA alarm clock. The image provides measurements in both inches and millimeters: 5.67 inches (144mm) for both width and depth, and 2.8 inches (70mm) for height.

Feature	Detail

Feature	Detail
Brand	iTOMA
Model Number	205
Color	Black or White
Product Dimensions	14.4 x 3.81 x 7 cm (5.67 x 1.5 x 2.76 inches)
Item Weight	640 g (1.41 lbs)
Material	Plastic
Display Type	Digital
Power Source	Corded Electric
Special Features	Alarm, Radio, Charging Port (USB & Wireless)
Age Range (Description)	Teenager
Room Type	Living Room, Bedroom
Shape	Square

Warranty and Support



Image Description: The bottom panel of the product packaging, displaying important information such as the iTOMA website for more

information, technical support details, and a contact email for service warranty. It also indicates the product is 'Made in China' and lists battery requirements.

Your iTOMA Wireless Alarm Clock comes with a limited warranty. For detailed warranty information, technical support, or service inquiries, please visit the official iTOMA website or contact their support team.

- **Official Website:** Please visit www.itoma.com for more information.
- **Technical Support:** For technical assistance, refer to the support section on the iTOMA website.
- **Service Warranty:** For warranty claims or service, please contactinfo@itoma.com.
- **Product ASIN:** B0C58N124H

© 2024 iTOMA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question