

KIOPOWQ BQ-608

KIOPOWQ 4-in-1 Manicure Machine BQ-608 User Manual

Model: BQ-608 | Brand: KIOPOWQ

INTRODUCTION

This 4-in-1 nail machine, model BQ-608, is designed for comprehensive nail care, combining a nail dust collector, nail drill, LED lighting, and a hand pad. Constructed from high-quality ABS material, it offers durability and efficiency for both professional and home use. The integrated dust collection system helps maintain a clean working environment, while the adjustable LED light ensures optimal visibility. This manual provides essential information for the safe and effective operation and maintenance of your device.

PRODUCT FEATURES

The KIOPOWQ BQ-608 Manicure Machine integrates multiple functionalities to enhance your nail care experience:

- **High Efficiency and Powerful Function:** Features a brushless DC motor and adjustable wind speed up to 4300rpm for effective dust absorption, ensuring a cleaner and healthier nail polishing environment. This product combines nail polishing, dust collection, and lighting functions.
- **Thoughtful Design & Efficient Heat Dissipation:** Includes comfortable hand pads designed to fit hand contours. The 360° adjustable LED light provides comprehensive illumination. Multiple heat dissipation holes in the base prevent overheating and extend product life.
- **Easy Installation and Operation & Compact and Lightweight:** Simple structure with complete accessories and a detailed manual for quick assembly. Plug-and-play operation. Compact size (9.06*9.06*2.76 inches) and lightweight (3.09lbs) for easy desktop placement.
- **Detailed Components:**
 - **Grinding Pen:** Ergonomically designed for comfortable holding and easy operation.
 - **Grinding Drill Heads:** Comes with 6 interchangeable grinding heads and a storage box.
 - **Handle Socket:** Provides a convenient resting place for the nail drill handle during operation.
 - **Non-slip Feet:** Four non-slip feet enhance product stability.
 - **Long Power Cord:** A 6.23 ft power cord offers flexibility and safety.
- **Sturdy and Durable & Easy to Clean:** Made primarily of ABS with a painting process for high hardness and compressive strength, ensuring extended service life. Features a simple construction, smooth surface, and pull-out

removable filter for easy cleaning.

Powerful motor 30,000 rpm

Adjustable rotation direction, fast speed



Strong wind, fine filter

Pull-out filter, large suction



360° all-round lighting

The angle can be rotated arbitrarily, fully illuminated

360°



Hand pad design

Silicone hand pad design, more comfortable when you do your nails



Figure 1: Key features of the 4-in-1 Manicure Machine, including the powerful motor, dust filter, adjustable LED light, and hand pad.

What kind of machine is the multifunctional nail machine?



It's a polished pen

It's lighting

It is a vacuum cleaner

It is a nail pad

Figure 2: Visual representation of the machine's four primary functions: nail drilling, lighting, dust collection, and hand support.

PACKAGE CONTENTS

Upon opening the package, please verify that all the following items are included:

- 1 x 4-in-1 Nail Machine (Main Unit)
- 1 x LED Lamp (Flexible Gooseneck)
- 1 x Handle (Nail Drill Pen)
- 1 x Adapter (Power Supply)
- 6 x Grinding Head Suits (Assorted Drill Bits)
- 1 x Power Cord
- 1 x English Manual



Figure 3: Contents included in the product package.

SAFETY INFORMATION

Please read and understand all safety instructions before operating the device to prevent injury or damage.

- Always wear safety glasses when using the nail drill.
- Do not touch the rotating bit or any moving parts during operation.
- Keep the device away from water and other liquids to prevent electric shock. Do not immerse the product in water.
- Stop using the machine immediately if you notice any abnormal phenomena or sounds.
- Always unplug the device from the power supply before cleaning, performing maintenance, or changing accessories.
- Follow the instructions in this manual for proper use, handling, and storage.
- Ensure the power supply is cut off before any cleaning procedures.

SETUP

The 4-in-1 Manicure Machine requires minimal assembly. Follow these steps to set up your device:

1. **Unpack Components:** Carefully remove all items from the packaging and ensure all listed package contents are present.
2. **Attach LED Lamp:** Insert the flexible gooseneck LED lamp into its designated port on the main unit. Ensure it is securely seated.
3. **Connect Nail Drill Handle:** Plug the nail drill handle's connector into the "Motor" socket on the front panel of the main unit.
4. **Insert Grinding Head:** Select the desired grinding head and insert it firmly into the chuck of the nail drill handle. Ensure it is properly secured before use.
5. **Connect Power:** Connect the power adapter to the "Power Jack" on the main unit, then plug the power cord into a standard 100V-240V 50HZ/60HZ electrical outlet.



Figure 4: Assembled 4-in-1 Manicure Machine.

OPERATING INSTRUCTIONS

Familiarize yourself with the controls and follow these steps for operation:

Nail machine button parts description




Figure 5: Control panel and component labels.

1. **Power On:** Ensure the machine is properly set up and plugged in. Flip the "POWER" switch to the ON position.
2. **Adjust Nail Drill Speed:** Rotate the "Motor" knob to adjust the speed of the nail drill within the range of 0-30000rpm.
3. **Change Nail Drill Rotation Direction:** Use the "REV FWD" switch to select the desired rotation direction (forward or reverse) for the nail drill.
4. **Activate Dust Collector:** Rotate the "FAN" knob to adjust the suction power of the nail dust collector according to the amount of nail powder generated. The fan working speed is about 4300rpm.
5. **Control LED Light:** Flip the "LAMP" switch to turn the LED light ON or OFF. The LED lamp provides 360° adjustable illumination.
6. **Utilize Hand Pad:** Place your hand comfortably on the integrated hand pad during manicure procedures.
7. **Changing Grinding Heads:** To change a grinding head, ensure the nail drill is off and the bit is cool. Use the quick head loading mechanism to remove the current bit and insert a new one firmly.

Regular maintenance ensures the longevity and optimal performance of your 4-in-1 Manicure Machine.

- **Cleaning the Unit:** Before cleaning, always cut off the power supply and unplug the machine. Wipe the smooth surfaces of the unit with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Filter Replacement:** The pull-out filter element for the dust collector should be cleaned regularly. We recommend replacing the filter every 1-2 months, depending on usage frequency, to ensure effective dust collection.
- **Nail Drill Bit Care:** Clean grinding heads after each use. Store them in the provided special storage box to prevent loss and damage.
- **General Care:** Avoid immersing the product in water. Keep the machine in a dry, clean environment when not in use.



Figure 6: The pull-out filter for easy maintenance.

TROUBLESHOOTING

If you encounter any issues with your 4-in-1 Manicure Machine, please refer to the following common troubleshooting tips.

If the problem persists, contact customer support.

Problem	Possible Cause	Solution
Machine does not power on.	Power cord not properly connected; Power switch is off; No power from outlet.	Ensure power cord is securely plugged into the machine and outlet. Flip the power switch to ON. Test the outlet with another device.
Nail drill not rotating.	Handle not connected; Speed knob set to minimum; Direction switch is off or in neutral.	Ensure the handle is securely plugged into the "Motor" socket. Increase the "Motor" speed knob. Check the "REV FWD" switch.
Dust collector suction is weak.	Fan speed set too low; Filter is clogged; Filter needs replacement.	Increase the "FAN" speed knob. Clean the pull-out filter. Replace the filter if it is old or heavily clogged.
LED light not working.	Lamp switch is off; Lamp not securely connected.	Flip the "LAMP" switch to ON. Ensure the LED lamp is firmly inserted into its port.
Unusual noise or vibration.	Loose grinding head; Internal component issue.	Ensure the grinding head is securely inserted. If noise persists, discontinue use and contact customer support.

Important Note: In the process of use, if there is any abnormal phenomenon, it should be stopped immediately.

SPECIFICATIONS

Attribute	Detail
Product Model	BQ-608
Color	White
Material	ABS, Silicone
Style	Modern
Power Source	Corded Electric
Input Voltage	100V-240V 50HZ/60HZ
Output Voltage	12V DC
Rated Power	80W (Actual Power: About 25W)
Adapter Model	BQ-25
LED Lamp Power	3W
LED Working Voltage	12V

Attribute	Detail
Color Temperature	6000K
Lighting Angle	360°
Fan Working Speed	About 4300rpm
Motor Type	Brushless DC Motor
Noise Level	<70dB
Power Cord Length	1.9m / 6.23ft
Product Size (L*W*H)	23*23*7cm / 9.06*9.06*2.76in
Net Weight	1.4kg / 3.09lbs
Manufacturer	DORASEVEN7
Date First Available	May 15, 2023



Figure 7: Various views and dimensions of the product.

WARRANTY AND SUPPORT

Specific warranty information for the KIOPOWQ 4-in-1 Manicure Machine BQ-608 was not provided in the available product data. Please refer to the product packaging, the seller's website, or contact the manufacturer directly for detailed warranty terms and conditions.

For technical support, troubleshooting assistance beyond this manual, or inquiries regarding parts and service, please contact KIOPOWQ customer service through their official channels, typically found on their website or the product's purchase page.