

[Manuals.plus](#) /

› [SANODESK](#) /

› SANODESK EP1E+120*60 Electric Standing Desk User Manual

SANODESK EP1E+120*60

SANODESK EP1E+120*60 Electric Standing Desk User Manual

Model: EP1E+120*60

Brand: SANODESK

1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your SANODESK EP1E+120*60 Electric Standing Desk. This height-adjustable desk is designed to offer a flexible workspace, allowing seamless transitions between sitting and standing positions to promote a healthier work environment. Please read this manual thoroughly before assembly and use to ensure proper function and safety.



Figure 1.1: SANODESK Electric Standing Desk (Black Frame + Black Desktop).

2. SAFETY INFORMATION

- Ensure all components are securely fastened before operating the desk.
- Keep hands and objects clear of moving parts during height adjustment.
- Do not overload the desk. The maximum static load capacity is 80 kg (176 lbs).
- Do not allow children to operate the desk unsupervised.
- Disconnect power before cleaning or performing any maintenance.
- Use only the provided power adapter and components.
- Avoid placing liquids directly on the control panel or motor housing.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts are present and undamaged. Refer to the assembly diagram for visual identification of components.

- Desktop (FCS-certified full panel)
- Desk Frame (Powder-coated high-quality steel, T-shaped legs)
- Electric Motor
- Control Panel (2-button)
- Power Adapter
- Assembly Hardware (screws, bolts, etc.)
- Assembly Tools (e.g., Allen wrench)
- User Manual

4. SETUP AND ASSEMBLY

The SANODESK electric standing desk is designed for quick and easy assembly, typically taking approximately 20 minutes. All necessary tools and step-by-step instructions are included.

1. Unpack all components and lay them out on a clean, flat surface.
2. Assemble the desk frame according to the provided assembly instructions, ensuring all connections are secure.
3. Attach the electric motor and control panel to the frame, aligning with pre-drilled holes.
4. Carefully place the desktop onto the assembled frame and secure it using the provided hardware.
5. Connect the power adapter to the motor and then to a power outlet.

EASY TO ASSEMBLE

You can assemble the entire table in about 20 minutes



Figure 4.1: Desk components laid out for assembly.

HIGH QUALITY & STABLE MOTOR



Figure 4.2: Desk stability and load capacity demonstration.

5. OPERATING INSTRUCTIONS

The SANODESK electric standing desk features a user-friendly 2-button control panel for effortless height adjustment.

5.1 Height Adjustment

- **To Raise the Desk:** Press and hold the "Up" button on the control panel. The desk will smoothly ascend.
- **To Lower the Desk:** Press and hold the "Down" button on the control panel. The desk will smoothly descend.
- Release the button at your desired height. The desk can be adjusted between 710mm (27.95 inches) and 1160mm (45.67 inches).

HEIGHT ADJUSTABLE

710-1160mm smooth and quiet adjustment to meet your needs



Figure 5.1: Height adjustment range of the desk.

5.2 Power Consumption

The desk is designed for energy efficiency, consuming less than 0.5 watts in standby mode. This low power consumption helps reduce electricity usage and environmental impact.

6. MAINTENANCE

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals. Ensure the desk is unplugged before cleaning.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight.
- **Cable Management:** Keep power cords and other cables tidy to prevent entanglement or damage during height adjustments.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk does not move.	No power, loose connection, motor error.	Check power cord connection. Ensure outlet is functional. Reconnect all cables. If issue persists, contact support.
Desk moves unevenly or makes unusual noise.	Overload, loose components, obstruction.	Reduce weight on the desk. Check all screws and bolts for tightness. Ensure no objects are obstructing the legs.
Control panel unresponsive.	Power issue, cable disconnected.	Verify power supply. Check the connection between the control panel and the motor/controller.

If you encounter issues not listed here or if the suggested solutions do not resolve the problem, please contact SANODESK customer support.

8. SPECIFICATIONS

- **Brand:** SANODESK
- **Model Number:** ffc518a5-3c14-44cc-a2ef-5a11b8ce0d7e (EP1E+120*60)
- **Color:** Black Frame + Black Desktop
- **Desktop Material:** FCS-certified Wood (Full Desktop)
- **Base Material:** Alloy Steel (Powder-coated)
- **Special Features:** Adjustable, Electric
- **Room Type:** Office
- **Desk Dimensions (Desktop):** 120 cm x 60 cm (47.24 inches x 23.62 inches)
- **Height Adjustment Range:** 710 mm - 1160 mm (27.95 inches - 45.67 inches)
- **Static Load Capacity:** 80 kg (176 lbs)
- **Assembly Required:** Yes (Approx. 20 minutes)
- **Power Consumption (Standby):** Less than 0.5 watts
- **UPC:** 810072824912

FIT PERFECTLY ON THE MOST COMMON TABLE TOPS




Figure 8.1: Desk frame compatibility with common table tops.



Smooth desktop in whole piece
Protective Edge
Environmental Friendly Desktop



Figure 8.2: Desktop features: Smooth, Protective Edge, Environmental Friendly (FSC).

9. WARRANTY AND SUPPORT

9.1 Product Warranty

The SANODESK EP1E+120*60 Electric Standing Desk comes with the following warranty:

- **Motor:** 2-year warranty
- **Desk Frame:** 5-year warranty

This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact SANODESK customer support through the official SANODESK website or your point of purchase. Provide your model number and a detailed description of the issue.

for faster service.

You can visit the official SANODESK store on Amazon for more information:[SANODESK Store](#)

© 2023 SANODESK. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C58QDJ9V>

More documents and user manuals: <https://manuals.plus/>