

## JIAABCHOMO hair clippers men-697

# JIAABCHOMO 6-in-1 Beard Trimmer Hair Clipper Set User Manual

Model: hair clippers men-697

## 1. INTRODUCTION

Thank you for choosing the JIAABCHOMO 6-in-1 Beard Trimmer Hair Clipper Set. This versatile grooming kit is designed to provide a comprehensive solution for your beard, hair, and body grooming needs. Featuring multiple interchangeable heads and guide combs, a powerful motor, and a long-lasting rechargeable battery, this device offers precision and convenience for a professional look at home.

## 2. PRODUCT COMPONENTS

The JIAABCHOMO 6-in-1 grooming kit includes the following components:

- 1 x Hair Clippers (main unit)
- 1 x Beard Trimmer Head
- 1 x Hair Trimmer Head
- 1 x Nose Trimmer Head
- 1 x Foil Shaver Head
- 1 x Precision Trimmer Head
- 1 x Body Trimmer Head
- 8 x Trimmer Guide Combs (various lengths)
- 1 x Cleaning Brush
- 1 x Comb
- 1 x USB Type-C Charging Cable
- 1 x Encased Cloth (Grooming Cape)





Figure 2.2: Detailed view of the trimmer and its accessories, including dimensions for various parts.

### 3. SETUP

#### 3.1 Charging the Device

Before first use, fully charge the trimmer. The device features a Type-C charging port for convenience.

1. Connect the provided USB Type-C charging cable to the charging port at the bottom of the trimmer.
2. Connect the other end of the USB cable to a compatible power source such as a power bank, phone charger, car charger, or laptop.
3. The LCD display on the trimmer will show the charging progress. A full charge takes approximately 2

hours.

4. Once fully charged, the trimmer provides up to 180 minutes of working time.



Figure 3.1: Type-C Fast Charging options for the trimmer.

### 3.2 Attaching and Detaching Trimmer Heads

The trimmer comes with multiple interchangeable heads for different grooming tasks.

1. To attach a head: Align the desired trimmer head with the main unit and press it down firmly until it clicks into place.
2. To detach a head: Hold the main unit firmly and gently push the trimmer head upwards to release it.



Figure 3.2: Steps for attaching and detaching trimmer heads.

### 3.3 Attaching Guide Combs

Guide combs are used to achieve specific hair lengths.

1. Select the appropriate guide comb for your desired hair length (e.g., 1.5mm, 3mm, 6mm, 9mm).
2. Align the guide comb with the trimmer head and slide it on until it securely locks into place.
3. To remove, gently slide the comb off the trimmer head.

# Limit Combs



Figure 3.3: Available guide comb lengths and their applications.

## 4. OPERATING INSTRUCTIONS

The JIAABCHOMO grooming kit is designed for ease of use with its ergonomic design and powerful motor.

### 4.1 General Operation

- Ensure the device is charged before use. The LCD display shows the battery percentage.
- Press the On/Off button to power on the trimmer.
- Press the On/Off button again to power off the trimmer.

### 4.2 Using Different Trimmer Heads

Select the appropriate head for your grooming task:

- **Beard Trimmer:** Ideal for shaping and trimming beards to desired lengths. Use with or without guide combs.

- **Hair Clippers:** Suitable for cutting and styling hair on the head. Use with guide combs for uniform length.
- **Nose Trimmer:** Designed for safely trimming nose and ear hair. Insert gently into the nostril or ear canal.
- **Foil Shaver:** Provides a close shave for smooth results on facial hair or small areas.
- **Precision Trimmer:** For detailing and creating sharp lines around the beard, mustache, or hairline.
- **Body Trimmer:** For grooming body hair.



Figure 4.1: The 6-in-1 grooming kit and its functions.



Figure 4.2: Examples of the 6-in-1 grooming kit in use.

## 5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your grooming kit.

### 5.1 Cleaning

- After each use, turn off the trimmer and detach the trimmer head.
- Use the provided cleaning brush to remove any loose hairs from the blades and the trimmer head.
- The head of the electric beard trimmer is washable. You can rinse it under tap water for approximately three seconds.
- **Important:** The charging port and the main body of the trimmer are NOT waterproof. Do not submerge the main unit in water or rinse the charging port.
- Allow the trimmer head to air dry completely before reattaching it to the main unit or storing.

### 5.2 Storage

- Store the trimmer and its accessories in a cool, dry place, away from direct sunlight and moisture.
- Keep out of reach of children.

## 6. TROUBLESHOOTING

If you encounter any issues with your JIAABCHOMO grooming kit, please refer to the following common solutions:

- **Trimmer not turning on:** Ensure the device is fully charged. Check the charging cable and adapter for any damage.
- **Poor trimming performance:** Clean the blades and trimmer head thoroughly to remove any trapped hairs. Ensure the blades are not dull or damaged.
- **Excessive noise or vibration:** This could indicate a loose trimmer head or debris caught in the motor. Turn off the device, remove the head, clean thoroughly, and reattach. If the issue persists, contact customer support.
- **LCD display not working:** Ensure the device is charged. If the display remains blank or faulty, contact customer support.

For issues not covered here, please contact JIAABCHOMO customer support.

## 7. SPECIFICATIONS

<b>Model Name</b>	beard trimmer-697
<b>Item Model Number</b>	hair clippers men-697
<b>Product Dimensions</b>	15.7 x 3 x 3 cm
<b>Weight</b>	620 g
<b>Power Source</b>	Wireless Electric
<b>Battery</b>	1500mAh Lithium Battery
<b>Charging Time</b>	2 hours
<b>Working Time</b>	Up to 180 minutes
<b>Motor Speed</b>	6200 RPM
<b>Noise Level</b>	<56dB
<b>Blade Material</b>	Stainless Steel
<b>Manufacturer</b>	JIAABCHOMO

# Ergonomic Design



Figure 7.1: Key design and feature highlights of the trimmer.

# Low Noise Powerful Motor



Figure 7.2: Motor performance and noise level details.

## 8. SAFETY INFORMATION

- Read all instructions before using this appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not use this appliance near bathtubs, showers, basins or other vessels containing water.
- Do not immerse the main unit of the trimmer in water or other liquids.
- Keep the charging port dry.
- Always unplug the appliance before cleaning or maintenance.
- Do not use the appliance if it is damaged in any way.
- Keep the appliance and its cord away from heated surfaces.
- Use only the attachments supplied with the appliance.

## 9. WARRANTY AND SUPPORT

JIAABCHOMO products are manufactured with quality and performance in mind. For specific warranty details, please refer to the warranty card or documentation included with your purchase. If you require technical support, have questions about product operation, or need assistance with troubleshooting, please contact JIAABCHOMO customer service through the retailer where you purchased the product or visit the official JIAABCHOMO website for contact information.