Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Uliptz WH203A

Uliptz WH203A Bluetooth Over-Ear Headphones User Manual

Model: WH203A

Introduction

Thank you for choosing the Uliptz WH203A Bluetooth Over-Ear Headphones. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your device. Please read this manual carefully before use.

Package Contents

Please check the package for the following items:

- Uliptz WH203A Bluetooth Over-Ear Headphones
- USB-C Charging Cable
- 3.5mm Audio Cable
- User Manual

Note: The term "Kabelloser Ladebehälter" (Wireless charging case) in the original product data likely refers to the charging cable for the headphones, as a separate wireless charging case is not typical for this product type.

Product Overview

Familiarize yourself with the various parts and controls of your Uliptz WH203A headphones.



Image: Diagram showing the control buttons and ports on the Uliptz WH203A headphones. Labels include Volume Up/Next Track, Multi-Function Button, Volume Down/Previous Track, Type-C Charging Interface, LED Indicator, 3.5mm Audio Interface, and EQ Button.

- **Volume Up / Next Track Button:** Press briefly to increase volume, press and hold for next track.
- **Multi-Function Button (MFB):** Power on/off, play/pause, answer/end calls, activate voice assistant.
- **Volume Down / Previous Track Button:** Press briefly to decrease volume, press and hold for previous track.
- **Type-C Charging Interface:** For charging the headphones.
- **LED Indicator:** Shows power, charging, and pairing status.
- **3.5mm Audio Interface:** For wired connection.
- **EQ Button:** Cycle through different equalizer modes.

Setup

Charging the Headphones

Before first use, fully charge your headphones. Use the provided USB-C cable to connect the headphones to a USB

power source (e.g., computer, wall adapter).



Image: An image highlighting the 500 mAh battery capacity of the Uliptz headphones, indicating up to 65 hours of playtime on a single charge and 4 hours of playtime from a 10-minute quick charge.

- The LED indicator will show red during charging and turn off when fully charged.
- A full charge takes approximately 2.5 hours.
- A quick 10-minute charge provides up to 4 hours of playtime.

Bluetooth Pairing

1. Ensure the headphones are turned off.
2. Press and hold the Multi-Function Button until the LED indicator flashes blue and red alternately, indicating pairing mode.
3. On your device (smartphone, tablet, PC), enable Bluetooth and search for available devices.
4. Select "Uliptz WH203A" from the list of devices.
5. Once connected, the LED indicator will flash blue slowly.

Note: The headphones support Bluetooth 5.3 for a stable and fast connection.

Operating Instructions

Power On/Off

- **Power On:** Press and hold the Multi-Function Button for 3 seconds. The LED will flash blue.
- **Power Off:** Press and hold the Multi-Function Button for 3 seconds. The LED will turn red and then off.

Music Playback

- **Play/Pause:** Press the Multi-Function Button once.
- **Next Track:** Press and hold the Volume Up button.
- **Previous Track:** Press and hold the Volume Down button.
- **Volume Up:** Press the Volume Up button briefly.
- **Volume Down:** Press the Volume Down button briefly.

Phone Calls

- **Answer/End Call:** Press the Multi-Function Button once.
- **Reject Call:** Press and hold the Multi-Function Button for 2 seconds.
- **Redial Last Number:** Double-press the Multi-Function Button.

EQ Modes

The headphones feature 6 EQ sound modes. Press the EQ button to cycle through the available modes and find your preferred sound profile.



Image: An exploded view diagram of the Uliptz headphone speaker components, illustrating the "Incredible Lossless Sound Quality" with 40mm acoustic stereo drivers.

Wired Mode

To use the headphones in wired mode, connect the 3.5mm audio cable to the headphone's 3.5mm audio interface and the other end to your audio source. This mode does not require battery power.

Multi-Device Connection

The headphones can be paired with two devices simultaneously. After pairing with the first device, disable Bluetooth on that device. Pair with the second device. Then, re-enable Bluetooth on the first device, and the headphones should connect to both. You can seamlessly switch between audio sources.



Image: A purple Uliptz headphone shown with icons for a phone and an iPad, illustrating the "Smart One Connect Two" feature for simultaneous multi-device connection.

Comfort and Design

The Uliptz WH203A headphones are designed for extended comfort and portability.



Image: A collage showing the "Exquisite detail design" of the Uliptz headphones, highlighting Comfortable Memory Foam earcups, an Adjustable Headband, Foldable Design, and a Non-breakable Headband.

- **Comfortable Memory Foam:** The earcups are made with soft memory foam for a comfortable fit during long listening sessions.
- **Adjustable Headband:** The metal slider headband can be adjusted to fit various head sizes.
- **Foldable Design:** The headphones can be folded for easy storage and portability, making them ideal for travel.

Maintenance

- Clean the headphones regularly with a soft, dry cloth.
- Avoid exposing the headphones to extreme temperatures, humidity, or direct sunlight.
- Do not use abrasive cleaners or solvents.
- Store the headphones in a cool, dry place when not in use.

Troubleshooting

Problem	Solution
Headphones won't turn on.	Ensure the headphones are charged. Connect to a power source using the USB-C cable.
Cannot pair with device.	◦ Ensure headphones are in pairing mode (LED flashing blue and red). ◦ Make sure Bluetooth is enabled on your device. ◦ Move headphones closer to your device. ◦ Forget "Uliptz WH203A" from your device's Bluetooth list and try pairing again.
No sound or low volume.	◦ Adjust volume on both headphones and your connected device. ◦ Ensure headphones are properly connected via Bluetooth or 3.5mm cable. ◦ Check if the audio source is playing.
Poor call quality.	◦ Ensure the microphone is not obstructed. ◦ Move to an area with less background noise. ◦ Check your device's network connection.

Specifications

Feature	Detail
Brand	Uliptz
Model Name	WH203A
Color	Lila (Purple)
Ear Placement	Over Ear
Form Factor	Circumaural
Impedance	10 Ohm
Noise Control	Noise Shielding
Frequency Response	20 KHz
Sensitivity	105 dB
Headphone Jack	3.5 mm Jack
Included Items	USB-C Charging Cable, 3.5mm Audio Cable, User Manual
Age Group	Adult
Weight	180 Grams

Feature	Detail
Audio Driver Type	Dynamic Driver
Audio Driver Size	40 Millimeters
Housing Material	Plastic
Product Features	65 Hours Playtime, 6 EQ Sound Modes, Bluetooth 5.3 Connection, Foldable and Lightweight, Built-in Microphone
Wireless Technology	Bluetooth
Bluetooth Range	10 Meters
Bluetooth Version	5.3
Hardware Interface	3.5mm Audio, USB
Control Type	Button presses (built-in control panel)
Battery Life (Playtime)	Up to 65 Hours
Battery Charging Time	2.5 Hours

Warranty and Support

Your Uliptz WH203A headphones come with a**12-month warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use.
For warranty claims, technical support, or any questions regarding your product, please contact Uliptz customer service through the retailer where you purchased the product or visit the official Uliptz website for contact information.
Please retain your proof of purchase for warranty purposes.

© 2026 Uliptz. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C58XJZ4Q

More documents and user manuals: **https://manuals.plus/**