

[Manuals.plus](#) /

› [CNCEST](#) /

› CNCEST 2200W Smoothie Blender User Manual

CNCEST B0C59LVLBF

CNCEST 2200W Smoothie Blender User Manual

Model: B0C59LVLBF

INTRODUCTION

This manual provides essential instructions for the safe operation, maintenance, and troubleshooting of your CNCEST 2200W Smoothie Blender. Please read this manual thoroughly before first use and retain it for future reference.



Figure 1: The CNCEST 2200W Smoothie Blender, showcasing its main components including the base, jar, and lid.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before operating the blender.
- Do not immerse the motor base in water or other liquids.
- Unplug from outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.

- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Keep hands and utensils out of container while blending to prevent the possibility of severe injury to persons or damage to the blender. A scraper may be used but only when the blender is not running.
- Blades are sharp. Handle with care.
- Always operate blender with lid in place.
- Do not blend hot liquids in the blender jar as this may cause pressure buildup and result in burns.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

PARTS AND FEATURES

Familiarize yourself with the components of your CNCEST Smoothie Blender:

1. **Motor Base:** Houses the 2200W pure copper motor and control panel.
2. **Blender Jar:** Transparent container with a zinc alloy base and 402 stainless steel blades.
3. **Lid:** Secures the contents during blending.
4. **Control Panel:** Features ON/OFF switches, a variable speed dial, and a PULSE switch.
5. **Power Cord:** For connecting to a 110V power outlet.



Figure 2: Close-up of the control panel, showing the ON/OFF switches, variable speed dial, and PULSE function.



Figure 3: The motor base without the jar, illustrating the coupling mechanism for the blender jar.

SETUP

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Clean:** Before first use, wash the blender jar, lid, and any removable parts in warm, soapy water. Rinse thoroughly and dry. Wipe the motor base with a damp cloth.
3. **Assemble:** Place the blender jar securely onto the motor base. Ensure it is properly seated.
4. **Position:** Place the blender on a stable, flat, and dry surface.
5. **Connect Power:** Plug the power cord into a standard 110V electrical outlet.

OPERATING INSTRUCTIONS

1. **Prepare Ingredients:** Cut ingredients into appropriate sizes. For best results, add liquids first, then soft ingredients,

followed by harder ingredients and ice. Do not overfill the jar.

2. **Secure Lid:** Place the lid firmly onto the blender jar.

3. **Start Blending:**

- Flip the main power switch to the "ON" position.
- Use the variable speed dial to select your desired blending speed. Start with a lower speed and gradually increase as needed.
- For short bursts of power, use the "PULSE" switch. Hold it down for desired duration, then release.

4. **Monitor:** Observe the blending process. If ingredients are not circulating, turn off the blender, remove the lid, and use a spatula to push ingredients towards the blades. Replace lid before restarting.

5. **Finish Blending:** Once desired consistency is achieved, turn the speed dial to the lowest setting, then flip the main power switch to "OFF".

6. **Unplug:** Always unplug the blender from the power outlet after use.

Tips for Optimal Performance:

- For thick mixtures, use the tamper (if included) through the lid opening to push ingredients down towards the blades.
- Avoid blending excessively hot liquids to prevent pressure buildup.
- The 2200W pure copper motor and six 402 stainless steel blades are designed for efficient grinding and cutting of various foods and ice cubes.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your blender.

1. **Unplug:** Always ensure the blender is unplugged before cleaning.

2. **Self-Cleaning (Quick Clean):**

- Fill the blender jar halfway with warm water and a drop of dish soap.
- Secure the lid.
- Run the blender on a medium speed for 30-60 seconds.
- Empty the jar, rinse thoroughly with clean water, and dry.

3. **Deep Cleaning:**

- Disassemble the jar from the motor base.
- Wash the jar, lid, and any removable parts by hand in warm, soapy water. Use a brush for hard-to-reach areas around the blades.
- Rinse all parts thoroughly and allow them to air dry completely before reassembling or storing.

4. **Motor Base Cleaning:** Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid.

5. **Storage:** Store the blender in a clean, dry place.

Note: The anti-vibration cushion at the connection of the jar and the body helps reduce noise during operation. Ensure it is clean and properly seated.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in.	Ensure power cord is securely plugged into a 110V outlet. Flip the main power switch to "ON". Reset the circuit breaker. Ensure the blender jar is correctly placed on the motor base.
	Power switch is OFF.	
	Circuit breaker tripped.	
	Jar not properly seated.	
Ingredients not blending smoothly or blades are stuck.	Too little liquid.	Add more liquid.
	Too many ingredients.	Reduce the amount of ingredients.
	Ingredients are too large.	Cut ingredients into smaller pieces. Use the tamper (if available) or stop the blender and use a spatula to redistribute ingredients.
Loud noise during operation.	Jar not properly seated.	Ensure the blender jar is correctly placed on the motor base.
	Hard ingredients or ice.	Some noise is normal, especially with hard ingredients. If excessive, check for foreign objects.
Burning smell from motor.	Overloading the motor.	Reduce load.
	Extended continuous operation.	Turn off the blender and allow the motor to cool down for at least 15-20 minutes. If the smell persists, discontinue use and contact customer support.

SPECIFICATIONS

Model:	B0C59LVLBF
Brand:	CNCEST
Power:	2200W
Motor Type:	Pure Copper Motor
Voltage:	110 Volts
Blade Material:	402 Stainless Steel (Six blades)
Jar Material:	ABS Shell, Zinc Alloy Base
Noise Level:	Approximately 80dB
Product Dimensions (D x W x H):	15.7" x 12.6" x 11"
Recommended Uses:	Blending, Creams, Pureeing (Smoothies, Shakes, Frozen Drinks)



Figure 4: Side view of the blender illustrating approximate dimensions as depicted in the image (e.g., 50cm height, 21cm depth, 17cm width for the base).

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official CNCEST website. Please have your model number (B0C59LVLBF) and purchase date available when contacting support.

You can also visit the [CNCEST Store on Amazon](#) for more product information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question