

[Manuals.plus](#) /

› [Mega Bloks](#) /

› Mega Bloks Disney Magical Castle Construction Toy User Manual (Model HPB52)

Mega Bloks HPB52

Mega Bloks Disney Magical Castle Construction Toy User Manual

Model: HPB52

INTRODUCTION

The Mega Bloks Disney Magical Castle Construction Toy allows young children to create their own magical stories with beloved Disney characters. This set includes 96 large building blocks with special pieces and 4 Disney figures: Mickey, Minnie, Dumbo, and Tinker Bell. Children can construct a detailed Disney castle featuring fun elements like a spinning platform, a slide, and teacups. The blocks are compatible with all MEGA BLOKS construction toys, promoting fun and learning.

This manual provides essential information for the assembly, operation, and maintenance of your Mega Bloks Disney Magical Castle.



Image: The Mega Bloks Disney Magical Castle Construction Toy shown in its retail packaging, highlighting the assembled castle and included characters.

SAFETY INFORMATION

WARNING: This product contains or may generate small parts that can cause choking. Adult supervision is recommended during play, especially for children under 3 years old, despite the recommended age of 12 months and up for the larger blocks.

- Always ensure all pieces are securely connected during play.
- Keep packaging materials away from children to prevent suffocation hazards.
- Regularly inspect the toy for any damage or loose parts. Discontinue use if damage is found.

PACKAGE CONTENTS

Before assembly, please verify that all components are present:

- 96 large building blocks and special pieces
- 4 Disney figures: Mickey Mouse, Minnie Mouse, Dumbo, and Tinker Bell
- Reusable storage bag
- Instruction sheet (visual guide for assembly)



©Disney ©2023 MEGA Brands.

Image: Close-up of the four Disney figures (Mickey, Minnie, Dumbo, Tinker Bell) and various Mega Bloks pieces included in the set.

SETUP AND ASSEMBLY

Assembly is required for the Mega Bloks Disney Magical Castle. Follow the visual instructions provided in the box for step-by-step guidance.

1. **Unpack Components:** Carefully remove all blocks and figures from the reusable storage bag.
2. **Identify Base Pieces:** Locate the large green base pieces that form the foundation of the castle.
3. **Construct Castle Walls:** Begin connecting the larger blocks to form the castle walls and towers as shown in the instruction guide.
4. **Add Special Features:** Integrate the special pieces such as the slide, spinning platform, and teacups into the castle structure.
5. **Place Figures:** Once the castle is assembled, place Mickey, Minnie, Dumbo, and Tinker Bell figures in their designated spots or anywhere within the castle for imaginative play.



©Disney ©2023 MEGA Brands.

Image: The fully assembled Mega Bloks Disney Magical Castle, showcasing the slide, spinning teacups, and character figures.

OPERATING INSTRUCTIONS (PLAY FEATURES)

The Disney Magical Castle offers several interactive play features:

- **Spinning Platform:** Place figures like Dumbo or Minnie in the teacups on the spinning platform. Gently rotate the platform to make the teacups spin.
- **Slide:** Position a figure at the top of the red slide and let them slide down into the castle courtyard.
- **Castle Exploration:** Encourage imaginative play by moving the figures through the castle gates, up the towers, and around the various sections.



©Disney ©2023 MEGA Brands.

Image: Dumbo and Tinker Bell figures placed in the spinning teacups feature of the castle, illustrating the rotational movement.

MAINTENANCE AND CARE

To ensure the longevity and cleanliness of your Mega Bloks Disney Magical Castle:

- **Cleaning:** Wipe blocks and figures with a damp cloth and mild soap if necessary. Rinse thoroughly and air dry.
- **Storage:** After play, disassemble the castle if desired and store all blocks and figures in the provided reusable storage bag. This helps prevent loss of pieces and keeps the play area tidy.
- **Inspection:** Periodically check all blocks and figures for wear and tear. Replace any damaged parts if possible, or discontinue use if the toy becomes unsafe.

TROUBLESHOOTING

If you encounter any issues with your Mega Bloks Disney Magical Castle, consider the following:

- **Blocks not connecting securely:** Ensure blocks are aligned correctly and pressed firmly together. Check for any debris or foreign objects obstructing the connection points.
- **Missing pieces:** Refer to the package contents list. If a piece is genuinely missing from a new set, contact customer support.
- **Figures not fitting:** Ensure figures are placed in the correct slots or on appropriate block studs. Some figures may have specific bases designed for certain features.

SPECIFICATIONS

Brand	Mega Bloks
Model Number	HPB52
Number of Pieces	100
Material	Plastic
Color	Multicolor
Recommended Age	12 months and up
Educational Objectives	Imagination Development, Fine Motor Skills, Creative Thinking
Assembly Required	Yes
Batteries Required	No
Product Dimensions	32.1 x 43.18 x 30.48 cm; 1.01 kg (approx. 12.6 x 17 x 12 inches; 2.2 lbs)

WARRANTY AND SUPPORT

This product is backed by Fisher-Price, a brand known for quality children's toys. For any questions, concerns, or support regarding your Mega Bloks Disney Magical Castle, please contact Mega Bloks or Fisher-Price customer service. Refer to the packaging for specific contact details or visit the official Mega Bloks website for support information.

Note: Specific warranty terms and conditions may vary by region. Please retain your proof of purchase.