

[Manuals.plus](#) /

› [Luqeeeg](#) /

› Luqeeeg 400ml Smart Bluetooth Essential Oil Diffuser Instruction Manual

Luqeeeg Luqeeegrwvdm1fuzh-14

Luqeeeg 400ml Smart Bluetooth Essential Oil Diffuser Instruction Manual

Model: Luqeeegrwvdm1fuzh-14

1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your Luqeeeg 400ml Smart Bluetooth Essential Oil Diffuser. Please read this manual thoroughly before operating the device and retain it for future reference.



Figure 1.1: Luqeeeg 400ml Smart Bluetooth Essential Oil Diffuser, front view with Bluetooth symbol and phone showing app interface.

2. IMPORTANT SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the device:

- When loading essential oil into the machine, keep it upright. Do not invert or tilt the device.
- Do not use overloaded power sockets, damaged power cords, or damaged power plugs.
- When wall-mounted, ensure the machine is installed out of reach of children and pets.
- Ensure the device is placed on a stable, flat surface if not wall-mounted.
- Do not block the air outlet or inlet during operation.
- Use only essential oils recommended for atomizing diffusers.

3. PRODUCT OVERVIEW

The Luqeeq Smart Bluetooth Essential Oil Diffuser utilizes two-fluid atomization technology to disperse essential oils. It features a 400ml capacity and can be controlled via Bluetooth.

Package Contents:

- Essential Oil Diffuser Unit
- Power Adapter (US Plug)
- Essential Oil Bottle (400ml capacity)
- Wall Mounting Adhesive
- User Manual



Figure 3.1: Product dimensions showing height (21cm / 8.3in), width (15.5cm / 6.1in), and depth (7.5cm / 3in).

4. SETUP

4.1 Filling the Essential Oil Bottle

1. Press and hold the top button to open the device cover.
2. Pull out the atomization module and essential oil bottle assembly as a whole.
3. Rotate the essential oil bottle counter-clockwise to remove it from the atomization module.

4. Fill the essential oil bottle with your desired essential oil. Do not overfill.
5. Re-attach the essential oil bottle to the atomization module by rotating it clockwise until secure.
6. Install the atomization module back into the device and close the upper cover.

4.2 Installation Options

The diffuser can be installed in two ways: wall-mounted or placed on a flat surface.

- **Flat Placement:** Simply place the diffuser on a stable, flat surface.
- **Wall Mounting:** First, fix the wall mounting adhesive to the desired wall location. Then, hang the machine onto the adhesive using the screw position on the back plate hole. Ensure the wall surface is clean and dry before applying the adhesive.



Figure 4.1: Visual guide for opening the diffuser, removing the essential oil bottle, filling it, and reassembling the unit.

5. OPERATION

5.1 Powering On/Off

Connect the power adapter to the diffuser and a suitable power outlet. The device will power on automatically or can be turned on using the power button (location may vary, refer to device diagram if available).

5.2 Bluetooth Pairing and App Control

The Smart Bluetooth Fragrance Machine allows you to adjust settings remotely via a dedicated mobile application.

1. Download the official Luqeeq app from your smartphone's app store (iOS or Android).
2. Ensure Bluetooth is enabled on your smartphone.
3. Open the Luqeeq app and follow the on-screen instructions to search for and pair with your diffuser.
4. Once paired, you can manually adjust settings such as time periods for diffusion and fragrance concentration directly from the app.



Figure 5.1: A smartphone displaying the control interface for the diffuser, illustrating remote Bluetooth control and customizable spray patterns and timing.

5.3 Atomization Technology

The diffuser uses cutting-edge two-fluid atomization technology to effectively disperse essential oils into the air. This ensures a long-lasting and evenly spread fragrance across any space, creating a pure and aromatic environment.

5.4 Quiet Operation

The diffuser is designed for quiet operation, typically producing noise levels between 36-45 dB, making it suitable for use in bedrooms or other quiet environments without disturbance.



Figure 5.2: The diffuser placed on a bedside table, indicating its low noise level (36-45 dB) for a peaceful sleep environment.

6. MAINTENANCE

6.1 Cleaning the Unit

Regular cleaning helps maintain optimal performance. Disconnect the power before cleaning.

- Wipe the exterior of the diffuser with a soft, damp cloth.
- For the essential oil bottle and atomization module, clean with a small amount of rubbing alcohol or a specialized diffuser cleaner to remove any oil residue. Ensure all parts are completely dry before reassembly.
- Do not immerse the main unit in water or any other liquid.

6.2 Replacing Essential Oil

Follow the steps in Section 4.1 to remove and refill the essential oil bottle when it is empty or when you wish to change the fragrance.



Figure 6.1: The diffuser unit with its front panel open, revealing the internal components and the removable 400ml essential oil bottle.

7. TROUBLESHOOTING

If you encounter issues with your diffuser, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No mist is produced	Essential oil bottle is empty or improperly installed. Atomization module is clogged. Power is not connected.	Refill or correctly install the essential oil bottle. Clean the atomization module. Ensure power adapter is securely connected.
Device does not power on	No power supply. Faulty power adapter.	Check power connection and outlet. Try a different power outlet. Contact customer support if issue persists.
Bluetooth connection fails	Bluetooth is off on phone. App not installed or updated. Device is out of range.	Ensure phone Bluetooth is on. Reinstall or update the app. Move phone closer to the diffuser. Restart both devices.
Weak fragrance output	Low essential oil concentration setting. Essential oil level is low. Atomization module needs cleaning.	Adjust concentration settings in the app. Refill essential oil. Clean the atomization module.

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Brand	Luqeeq
Model Name	Luqeeqrwvdm1fuzh-14
Color	White
Material	Plastic
Power Source	Corded Electric
Capacity	400 Milliliters
Product Dimensions	8.3"L x 6.1"W x 3"H (21cm x 15.5cm x 7.5cm)
Coverage Area	5382 to 10764 square feet
Wattage	1 watts
Special Feature	Smart (Bluetooth Connectivity)
Auto Shutoff	No
Item Weight	2.24 pounds
Batteries Required	No

9. WARRANTY AND SUPPORT

9.1 Warranty Information

This product comes with a standard manufacturer's warranty. Please refer to the product packaging or the seller's website for specific warranty terms and conditions. Keep your purchase receipt as proof of purchase.

9.2 Customer Support

For technical assistance, troubleshooting not covered in this manual, or warranty claims, please contact Luqeeq customer support through the retailer where the product was purchased or visit the official Luqeeq website for contact information.