



Manuals.plus /

› CAR PASS /

› CAR PASS Universal Leather Back Seat Cover Instruction Manual, Model zt-0121HP-BK1

CAR PASS zt-0121HP-BK1

CAR PASS Universal Leather Back Seat Cover Instruction Manual

Model: zt-0121HP-BK1

1. INTRODUCTION

This manual provides detailed instructions for the installation, use, and maintenance of your CAR PASS Universal Leather Back Seat Cover. Designed for a wide range of automotive vehicles, this seat cover offers protection and enhances your vehicle's interior.

Please read this manual thoroughly before installation to ensure proper fit and functionality.



Image 1.1: The CAR PASS Universal Leather Back Seat Cover in black.

2. COMPATIBILITY

The CAR PASS Universal Back Seat Cover is designed for universal fit across most cars, sedans, trucks, pick-ups, and SUVs. It is important to verify your vehicle's seat configuration and dimensions before installation.

- **Rear Seat Dimensions:** 63cm H × 50cm L × 130cm W (24.8" × 19.7" × 51.2"). The stretch-friendly fabric adapts to ±3cm/1.2" size variations.
- **Headrest Compatibility:** Compatible with detachable headrests. Not suitable for seats with non-detachable or molded headrests.
- **Seat Belt Accessibility:** Designed to maintain full access to seatbelts.
- **Split Bench Compatibility:** Supports 40/60, 60/40, and 50/50 split bench configurations.
- **Armrest/Cupholder Access:** Features a zipper for access to integrated armrests or cupholders.
- **Airbag Compatibility:** Engineered to be compatible with side airbags.



Image 2.1: Visual guide to seat cover compatibility features.




Image 2.2: Detailed compatibility check for vehicle bench headrests.

3. FEATURES

- **Material:** High-quality breathable leather with a 5mm composite sponge interior for comfort and durability.

- **Design:** Full coverage design in black, intended to complement vehicle interiors.
- **Protection:** Shields original seats from spills, stains, pet hair, and UV rays.
- **Functionality:** Engineered to allow full access to seatbelts, armrests, and seat adjustment controls.
- **Headrest Covers:** Separate headrest covers facilitate easy adjustment.
- **Airbag Compatibility:** Designed to not interfere with side airbag deployment.
- **Breathable Mesh:** Incorporates breathable mesh sections for enhanced comfort.



Image 3.1: Key features of the seat cover, including zipper access and breathable material.

4. SETUP AND INSTALLATION

Installation of the CAR PASS Universal Back Seat Cover typically takes approximately 20 minutes. An installation diagram is included in the product packaging. The following steps outline the general installation process:

1. **Prepare Your Seats:** Ensure your vehicle's rear seats are clean and free of obstructions. Remove any items from the seat area.
2. **Remove Headrests:** If your vehicle has detachable headrests, remove them from the rear bench seat.
3. **Position the Backrest Cover:** Carefully slide the backrest portion of the seat cover over the top of

the rear seat. Align it so that the openings for seatbelts and headrest posts match your seat's configuration.

4. **Secure the Backrest Cover:** Fasten any straps or buckles located on the backrest cover, typically by pulling them through the seat gap and securing them underneath the seat.
5. **Position the Seat Base Cover:** Place the seat base portion of the cover onto the bottom cushion of the rear seat. Ensure it is centered and covers the entire cushion.
6. **Secure the Seat Base Cover:** Utilize the provided hooks, elastic bands, or buckles to secure the seat base cover firmly in place. This may involve tucking straps under the seat and connecting them to points underneath.
7. **Reinstall Headrests:** Once the main covers are in place, slide the separate headrest covers onto your vehicle's headrests and reinsert the headrests into their original positions.
8. **Adjust for Fit:** Smooth out any wrinkles and adjust the covers to achieve a snug fit. The cover should not slide after proper installation.

Note: Installation does not require lifting or removing the car seat from the vehicle.



Image 4.1: Installed CAR PASS seat cover in a vehicle.



Image 4.2: Detail of the zipper for split bench or armrest access.

5. OPERATING AND FUNCTIONALITY

The CAR PASS Universal Back Seat Cover is designed to integrate seamlessly with your vehicle's existing features:

- **Seatbelt Access:** Openings are provided to ensure all seatbelts remain fully functional and accessible for safety.
- **Armrest and Cupholder Access:** A strategically placed zipper allows for easy deployment and use of built-in armrests or cupholders without removing the cover.
- **Seat Adjustments:** The design accommodates standard seat adjustments, ensuring that controls remain usable.
- **Airbag Compatibility:** The cover is constructed to allow for proper deployment of side airbags, maintaining vehicle safety standards.

6. MAINTENANCE

To ensure the longevity and appearance of your CAR PASS Universal Back Seat Cover, follow these maintenance guidelines:

- **Cleaning:** The high-quality leather material is easy to clean. For general cleaning, wipe down the surface with a damp cloth. For tougher stains, use a mild automotive interior cleaner and a soft cloth. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Blot spills immediately with a clean, dry cloth to prevent staining.
- **Vacuuming:** Regularly vacuum the seat cover to remove dust, dirt, and debris.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause material degradation over time. Consider using sun shades when parking for extended periods.

7. TROUBLESHOOTING

If you encounter any issues with your CAR PASS Universal Back Seat Cover, consider the following:

- **Poor Fit:** Double-check the dimensions of your vehicle's rear seat against the product specifications (63cm H x 50cm L x 130cm W). Ensure all straps and buckles are securely fastened and adjusted for a snug fit. Universal fit products may not perfectly conform to every vehicle's unique contours.
- **Headrest Issues:** Confirm that your vehicle's headrests are detachable. The covers are not designed for non-detachable or molded headrests.
- **Sliding Cover:** Ensure all securing mechanisms (straps, hooks, elastic bands) are properly engaged and tightened underneath the seat.
- **Difficulty with Split Bench/Armrest:** Verify that the zipper is correctly aligned and fully opened or closed as needed for split functionality or armrest access.

If problems persist, please contact CAR PASS customer support for assistance.

8. SPECIFICATIONS

Attribute	Detail
Brand	CAR PASS
Model	Back Seat Cover
Item Model Number	zt-0121HP-BK1
Color	Rear Black
Item Weight	3.1 pounds
Package Dimensions	13.3 x 12.95 x 4.33 inches
Fit Type	Universal Fit
Has Seat Belt Accessibility	Yes
Date First Available	January 1, 2024

9. WARRANTY AND SUPPORT

CAR PASS is committed to providing high-quality products and customer satisfaction. While specific warranty details are not provided in this manual, we stand by the quality of our car seat covers.

For any questions, concerns, or support needs regarding your CAR PASS Universal Back Seat Cover, please refer to the contact information provided with your purchase or visit the official CAR PASS store online.

We strive to provide quality service and ensure your trust in our products.