

[manuals.plus](#) /› [Makolle](#) /› **Makolle Kids Selfie Camera S9PINK Instruction Manual**

Makolle S9

Makolle Kids Selfie Camera S9PINK Instruction Manual

Model: S9PINK

INTRODUCTION

This manual provides essential information for the safe and effective use of your Makolle Kids Selfie Camera S9PINK. Please read it thoroughly before operating the device and retain it for future reference.

SAFETY INFORMATION

- Do not disassemble or attempt to repair the camera yourself.
- Keep the camera away from water and excessive moisture.
- Avoid exposing the camera to extreme temperatures.
- Use only the provided charging cable and accessories.
- Ensure children use the camera under adult supervision.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- Camera Body
- 32GB SD Card
- Card Reader
- USB Cable
- Camera Lanyard
- User's Manual
- Camera Tripod



Image: Makolle Kids Selfie Camera S9PINK with all included accessories: camera body, 32GB SD card, card reader, USB cable, camera lanyard, and tripod.

Video: What accessories are included?

Video: A demonstration of the Makolle Kids Selfie Camera S9PINK's accessories, including the camera, lanyard, charging cable, and SD card.

Video: Kids camera SET? What does it come with?

Video: An unboxing and overview of the Makolle Kids Selfie Camera S9PINK kit, detailing each included item.

PRODUCT OVERVIEW

The Makolle Kids Selfie Camera S9PINK is designed for ease of use and durability, featuring a compact form factor and intuitive controls.

Key Components:

- **180° Flip Lens:** Allows for easy switching between front and rear-facing photography.
- **2.4-inch LED Display:** For viewing photos, videos, and navigating menus.
- **Control Buttons:** Intuitive buttons for navigation, selection, and capture.

- **Microphone/Speaker:** For video recording and audio playback.
- **USB Port:** For charging and data transfer.
- **SD Card Slot:** For memory expansion (32GB card included).



Image: Makolle Kids Selfie Camera S9PINK displaying various feature icons such as selfie mode, 1080p video, time-lapse, playback, games, MP3, 2.4-inch IPS screen, multiple funny stickers, 8x digital zoom, and 1000mAh battery.

SETUP

1. Inserting the SD Card

1. Locate the SD card slot on the side of the camera.
2. Gently insert the included 32GB SD card into the slot until it clicks into place. Ensure the card is inserted in the correct orientation.

2. Charging the Battery

1. Connect the provided USB cable to the camera's USB port.
2. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. Charging typically takes 2-3 hours.

4. Once fully charged, the indicator light will change or turn off.

3. Attaching the Lanyard and Tripod

1. Attach the camera lanyard to the designated loop on the camera body for secure carrying.
2. The mini tripod can be screwed into the tripod mount located at the bottom of the camera for stable shots.

OPERATING INSTRUCTIONS

1. Power On/Off

- To power on, press and hold the power button (usually marked with a power symbol) for a few seconds.
- To power off, press and hold the power button again. The camera features an auto-off function to conserve battery.

2. Basic Photo and Video Capture

- **Switching Modes:** Use the navigation buttons to select between Photo, Video, and other modes on the main menu.
- **Taking Photos:** In Photo mode, frame your shot on the screen and press the shutter button (usually the OK button) to capture an 8 Million Pixel image.
- **Recording Videos:** In Video mode, press the shutter button to start recording 1080P video. Press it again to stop.
- **180° Flip Lens:** The main lens can be manually flipped 180 degrees to switch between front-facing (for selfies) and rear-facing modes. The camera features autofocus for clear images.



Image: A child uses the Makolle Kids Selfie Camera S9PINK, showcasing its 180-degree flip lens for selfies and the 8X digital zoom capability.

3. Digital Zoom

- The camera supports 8x digital zoom. Use the up/down navigation buttons while in photo or video mode to zoom in or out.

4. Special Features

- MP3 Music Player:** Access the music player from the main menu to play MP3 files stored on the SD card.
- Photo Frames, Stickers, and Filters:** Enhance your photos with 12 photo frames, 8 stickers, and 6 filters available in photo mode.
- Burst Shooting:** Capture multiple photos in quick succession.
- Timed Shots:** Set a timer (e.g., 2 seconds) before taking a photo.



Image: The Makolle Kids Selfie Camera S9PINK screen shows various fun sticker effects that can be applied to photos, encouraging creativity.



Image: The Makolle Kids Selfie Camera S9PINK shows its time-lapse feature with options for 3-second and 5-second delays before capturing a photo.

5. Playback and File Management

- Select 'Playback' from the main menu to view your captured photos and videos.
- Use the navigation buttons to scroll through files.
- To transfer files to a computer, connect the camera via the USB cable or insert the SD card into the provided card reader and then into your computer.



Image: A family is shown enjoying various activities, with the Makolle Kids Selfie Camera S9PINK actively recording 1080P HD video, capturing their joyful moments.

6. Games

- The camera includes built-in games for entertainment. Select 'Games' from the main menu to access them.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the camera body and screen. Do not use liquid cleaners.
- **Battery Care:** Charge the battery regularly, even if not in use, to maintain its lifespan. Avoid fully discharging the battery for extended periods.
- **Storage:** Store the camera in a cool, dry place when not in use.

TROUBLESHOOTING

- **Camera not turning on:** Ensure the battery is charged. If the issue persists, try resetting the camera (if a reset button is available, refer to the manual's specific section).
- **Cannot take photos/videos:** Check if the SD card is inserted correctly and has sufficient free space.
- **Poor image quality:** Ensure the lens is clean and there is adequate lighting.
- **Files not transferring:** Verify the USB cable connection or try using a different USB port/card reader.


SPECIFICATIONS

Feature	Specification
Brand	Makolle
Model Name	S9
Model Number	S9PINK
Photo Sensor Resolution	8 MP
Video Resolution	1080p
Optical Zoom	8 x
Digital Zoom	8 x
Screen Size	2.4 Inches
Battery Capacity	1000 Milliamp Hours
Battery Average Life	2 Hours
Memory Storage Capacity	32 GB (SD Card included)
Connectivity Technology	USB
Supported File Format	JPEG (Image), MP4 (Video), MP3 (Audio)
Auto Focus Technology	Contrast Detection
Water Resistance Level	Water Resistant

WARRANTY AND SUPPORT

Your Makolle Kids Selfie Camera S9PINK comes with a **2 Year Manufacturer Warranty**. For any support inquiries or warranty claims, please contact Makolle customer service through their official channels.

Related Documents - S9

 <p>Vanja SD/TF Card Reader User Guide and FAQ</p> <p>Comprehensive user guide and frequently asked questions for the Vanja SD/TF Card Reader, a USB 3.0 to SD/Micro SD card adapter compatible with USB-C devices and various operating systems. Learn about supported card types, device compatibility, transfer speeds, and troubleshooting.</p>
 <p>ResMed S9 VPAP Series & H5i Welcome Guide: Setup, Operation, and Maintenance</p> <p>Comprehensive welcome guide for ResMed S9 VPAP Auto, ST, and S Positive Airway Pressure Devices and the H5i Heated Humidifier. Learn about setup, operation, cleaning, maintenance, and troubleshooting.</p>
 <p>Samsung TV E-Manual: Your Comprehensive Guide to Features and Operation</p> <p>Discover how to maximize your Samsung TV experience with this detailed E-Manual. It covers setup, connectivity, Smart Hub, picture and sound settings, gaming, troubleshooting, and accessibility features for all users.</p>
 <p>Boost Mobile User Guide: Activate Your Phone and SIM Card</p> <p>This user guide provides instructions for Boost Mobile customers on activating their service using the Amazon SIM Kit. It covers phone unlocking, number porting, device compatibility, finding phone model information, activation steps, managing SIM and eSIM profiles, and customer support contact details.</p>
 <p>Samsung Galaxy for Families: A Guide to Parental Controls</p> <p>Learn how to set up and manage parental controls on Samsung mobile devices using Galaxy for Families and Google Family Link. Protect your child online with features like website access, app ratings, purchase restrictions, location sharing, and screen time limits.</p>
 <p>Guide to Parental Controls on Samsung Mobile Devices with Galaxy for Families</p> <p>Learn how to set up and manage parental controls on Samsung mobile devices using Galaxy for Families and Google Family Link. This guide covers app restrictions, website access, location sharing, and more.</p>