K&F Concept KF13.141JP

K&F CONCEPT KF13.141JP Camera Sling Bag Instruction Manual

Model: KF13.141JP | Brand: K&F Concept

1. Introduction

Welcome to the K&F CONCEPT KF13.141JP Camera Sling Bag user manual. This document provides essential information for the proper setup, operation, and maintenance of your new camera bag. Please read this manual thoroughly to ensure optimal use and longevity of your product.



Figure 1: Overall view of the K&F CONCEPT KF13.141JP Camera Sling Bag.

2. Product Overview and Features

The K&F CONCEPT KF13.141JP Camera Sling Bag is designed for photographers seeking a versatile and protective carrying solution for their DSLR, SLR, or Mirrorless cameras and accessories. Key features include:

- **Broad Compatibility:** Designed for various camera brands including Nikon, Canon, Sony, Fuji, GoPro, and DJI.
- **Perfect Dimension:** External dimensions of 7.8*5.5*16.1 inches (LxWxH) with internal equipment dimensions of 7.1*4.7*9.84 inches (LxWxH).
- **Strong Protection:** Features a special side safety buckle, soft foam layering, and removable inner dividers to secure and protect gear from shock and impact.
- **Multi-functional Design:** A larger lower storage case with removable modular inserts for lenses and flash units, an upper compartment for accessories, and a tripod holder on one side.
- **Excellent Details & Service:** Sling design for quick camera access, adjustable shoulder strap for comfort, suitable for both men and women.




Figure 2: The 270-degree side large opening design allows for easy access to your camera gear.



Figure 3: Intelligent division featuring separate upper and lower compartments for refined storage.



Figure 4: Demonstrates the bag's versatile package capacity space with multiple loading options for various equipment.

3. Setup

3.1 Adjusting Internal Dividers

The camera bag features removable modular inserts that allow you to customize the internal layout to fit your specific camera, lenses, and other accessories. These dividers attach via Velcro, providing flexibility in organizing your gear securely.

1. Open the main compartment of the bag.
2. Carefully detach the Velcro dividers from the interior walls.
3. Arrange the dividers to create compartments that snugly fit your camera body, lenses, and other equipment. Ensure all items are cushioned and separated to prevent damage.
4. Press firmly on the Velcro tabs to secure the dividers in their new positions.

3.2 Attaching a Tripod

The bag includes a dedicated tripod holder on one side for convenient transport.

1. Locate the mesh pocket and adjustable strap on the side of the bag.
2. Place the base of your tripod into the mesh pocket.
3. Secure the upper part of the tripod using the adjustable strap, ensuring it is tight enough to hold the tripod

firmly in place during movement.

Your browser does not support the video tag.

Video 1: K&F Concept Camera Sling Bag 10L. This video demonstrates the bag's features, including internal organization and external tripod attachment.

4. Operating Instructions

4.1 Wearing the Bag

The K&F CONCEPT Camera Sling Bag offers multiple carrying methods for comfort and quick access:

- **Sling/Crossbody Style:** Wear the padded shoulder strap across your body for a secure and comfortable fit. The sling design allows for easy rotation of the bag from your back to your front for quick access to your camera.
- **Shoulder Bag Style:** Adjust the strap to wear the bag over one shoulder.
- **Backpack Style:** The shoulder strap can be adjusted to function as a single-strap backpack.

4.2 Quick Access Features

The bag is designed for efficient access to your equipment:

- **Side Opening:** A 270-degree side opening allows you to quickly retrieve your camera without fully removing the bag.
- **Top Compartment:** The upper section provides quick access to smaller accessories like batteries, memory cards, or personal items.



Figure 5: The 270-degree large opening design allows for quick side access to equipment.



Figure 6: Various wearing styles for the 2-in-1 stylish sling bag, suitable for photography and commuting.

Your browser does not support the video tag.

Video 2: How to operate the Sling bag shoulder belt. This video demonstrates how to adjust and operate the shoulder strap for optimal comfort and security.

Your browser does not support the video tag.

Video 3: K&F CONCEPT 10L Camera Crossbody Bag. This video provides a detailed look at the bag's features and how to utilize its various compartments.

5. Maintenance

5.1 Cleaning Instructions

To maintain the appearance and functionality of your camera bag:

- For light dirt, wipe the exterior with a damp cloth and mild soap.
- Do not machine wash or tumble dry.
- Allow the bag to air dry completely before storing or using.
- The water-resistant fabric helps protect against light rain; however, avoid prolonged exposure to heavy rain.

5.2 Storage

When not in use, store the bag in a cool, dry place away from direct sunlight to prevent material degradation.


6. Troubleshooting

6.1 Common Issues

- **Strap Discomfort:** If the shoulder strap feels uncomfortable, adjust its length and ensure the padded section rests properly on your shoulder. The bag's design is optimized for weight distribution.
- **Limited Space:** If you find space is limited, reconfigure the internal modular dividers to maximize storage efficiency for your specific gear. Consider removing non-essential items for lighter loads.
- **Zippers Sticking:** Ensure zippers are clean and free from debris. Apply a small amount of zipper lubricant if necessary.

7. Specifications

Feature	Detail
Product Dimensions	7.87 x 5.12 x 15.75 inches (LxWxH)
Item Weight	1.08 pounds (0.49 Kilograms)
Capacity Total	10 Liters
Item Model Number	KF13.141JP
Manufacturer	K&F Concept
Material	Polyester (Water-resistant)



Material	Polyester	**Color**	Black
Weight	0.58kg	**Dimensions**	20*14*41 cm (7.8*5.5*16 inches)

Figure 7: Detailed product dimensions and weight information.

8. Warranty and Support

K&F Concept provides a 1-year extra service on each bag. For warranty claims, technical support, or any inquiries regarding your KF13.141JP Camera Sling Bag, please contact K&F Concept customer service through their official website or the retailer where the product was purchased.