Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- SoundPEATS /
- > SoundPEATS Opera05 True Wireless Earbuds User Manual

SoundPEATS Opera05

SoundPEATS Opera05 True Wireless Earbuds User Manual

Model: Opera05

1. Introduction

This manual provides detailed instructions for the SoundPEATS Opera05 True Wireless Earbuds. Please read this guide thoroughly to ensure proper usage and to maximize your audio experience. The Opera05 earbuds feature Hi-Res Audio, LDAC codec support, active noise cancellation, and Bluetooth 5.3 connectivity.

2. PACKAGE CONTENTS

- SoundPEATS Opera05 True Wireless Earbuds
- Charging Case
- USB Type-C Charging Cable
- Ear Cushions (various sizes)
- User Manual



Image: Contents of the SoundPEATS Opera05 package, showing the earbuds, charging case, USB-C cable, various ear tip sizes, and the user manual.

3. PRODUCT OVERVIEW

The SoundPEATS Opera05 earbuds are designed for high-fidelity audio with advanced features. They come with a portable charging case for extended use.



Image: The SoundPEATS Opera05 True Wireless Earbuds, black with gold accents, resting beside their matching charging case.




Image: Close-up of the SoundPEATS Opera05 earbuds highlighting the mirror surface, laser-engraved slogan, and deconstructionism design elements.




Image: A person wearing a SoundPEATS Opera05 earbud, illustrating the Bluetooth 5.3 connectivity feature.

4. SETUP

4.1 Charging the Earbuds and Case

Before first use, fully charge both the earbuds and the charging case. Use the provided USB Type-C cable to charge the case. The indicator light on the case will flash slowly during charging and remain green when fully charged.



Image: The SoundPEATS Opera05 charging case, highlighting its Type-C charging port and indicating a total of 33 hours of playtime.

4.2 Initial Pairing

- 1. Open the charging case.
- 2. Long press the button on the charging case for 3 seconds until the indicator light flashes white. The earbuds are now in pairing mode.
- 3. Enable Bluetooth on your device (smartphone, tablet, etc.).
- 4. Select "SOUNDPEATS Opera05" from the list of available Bluetooth devices to complete the pairing.

Your browser does not support the video tag.

Video: This official SoundPEATS Opera05 User Guide video demonstrates the initial pairing process, smart touch controls, charging, and resetting the earbuds. (Relevant segment: 0:10 - 0:25 for pairing)

5. Operating Instructions

5.1 Smart Touch Controls

The SoundPEATS Opera05 earbuds feature intuitive touch controls on the outer surface of each earbud. Refer to the following table for common operations:

| Action | Left Earbud | Right Earbud | |
|-------------------|---|--------------|--|
| Single Tap | Volume Down | Volume Up | |
| Double Tap | Play/Pause Music, Answer/Hang Up Call | | |
| Long Press (1.5s) | Switch Noise Reduction Mode (ANC On/Pass Through/Normal Mode) | Next Track | |
| Triple Tap | Activate Voice Assistant | | |

Your browser does not support the video tag.

Video: This official SoundPEATS Opera05 User Guide video demonstrates the initial pairing process, smart touch controls, charging, and resetting the earbuds. (Relevant segment: 0:26 - 1:06 for smart touch controls)

6. MAINTENANCE

To ensure the longevity and optimal performance of your SoundPEATS Opera05 earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds, especially the ear tips and charging contacts, with a soft, dry, lint-free cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust, moisture, and physical damage.
- Water Resistance: The earbuds are IPX4 water-resistant, meaning they are protected against splashing water from any direction. They are not waterproof and should not be submerged in water. Avoid exposing them to heavy rain or sweat for prolonged periods.
- **Temperature:** Avoid exposing the earbuds and charging case to extreme temperatures (hot or cold) as this can affect battery life and overall performance.

7. TROUBLESHOOTING

If you encounter any issues with your SoundPEATS Opera05 earbuds, please refer to the following common troubleshooting steps:

7.1 Pairing Issues

- Earbuds not connecting: Ensure both earbuds are in the charging case and have sufficient charge. Open the case and press the button for 3 seconds to enter pairing mode.
- Device not finding earbuds: Turn off and on your device's Bluetooth. Try restarting your device.
- **Previous connection issues:** Delete the "SOUNDPEATS Opera05" pairing information from your device's Bluetooth settings and attempt to pair again.

7.2 Sound Issues

- **No sound or low volume:** Check the volume levels on both your device and the earbuds. Ensure earbuds are properly seated in your ears for a good seal.
- **Intermittent sound:** Ensure there are no obstructions between your device and the earbuds. Move closer to your device. Avoid environments with strong electromagnetic interference.

7.3 Charging Issues

• Earbuds not charging: Ensure the charging contacts on the earbuds and inside the case are clean and dry. Place the earbuds correctly into the charging slots.

• Charging case not charging: Use the provided USB Type-C cable and a compatible power adapter. Check the cable and port for any damage.

7.4 Resetting the Earbuds

If the above steps do not resolve the issue, you may need to reset the earbuds:

- 1. Delete the earbuds' pairing information from your device.
- 2. Place both earbuds back into the charging case.
- 3. Keep the charging case open.
- 4. Press and hold the charging case button for 10 seconds until the red and white indicator light of the charging case blinks twice alternately. The reset is finished.

Your browser does not support the video tag.

Video: This official SoundPEATS Opera05 User Guide video demonstrates the initial pairing process, smart touch controls, charging, and resetting the earbuds. (Relevant segment: 1:20 - 1:53 for resetting)

8. Specifications

| Feature | Detail | | |
|----------------------------|---------------------------------|--|--|
| Model Name | Opera05 | | |
| Connectivity Technology | Wireless (Bluetooth) | | |
| Bluetooth Version | 5.3 | | |
| Bluetooth Range | 10 Meters | | |
| Noise Control | Active Noise Cancellation | | |
| Audio Driver Type | Hybrid Driver | | |
| Audio Driver Size | 12 Millimeters | | |
| Battery Life (Earbuds) | 9 Hours | | |
| Total Playtime (with Case) | 33 Hours | | |
| Charging Time | 1.5 Hours | | |
| Headphones Jack | Type-C | | |
| Control Method | Touch | | |
| Water Resistance Level | Water Resistant (IPX4) | | |
| Item Weight (Earbuds) | 10 Grams (approx. 0.353 ounces) | | |
| Product Dimensions | 2 x 2 x 2 inches | | |

9. WARRANTY AND SUPPORT

SoundPEATS is committed to providing excellent customer service. If you have any questions or require assistance with your Opera05 earbuds, please contact SoundPEATS Customer Service. You can typically find contact information through your purchase platform or the official SoundPEATS website.

To contact customer service via Amazon:

- Go to "Account Service"
- Select "Order History"
- Find your order for the SoundPEATS Opera05
- Click on "Sold By" and then "Ask Question"

SoundPEATS products typically come with a 12-month warranty. Please refer to your purchase documentation for specific warranty details.

© 2024 SoundPEATS. All rights reserved.

Related Documents - Opera05

