

Manuals.plus /

› DUNLOP /

› DUNLOP Bluetooth Speaker with Light (Model: BLT-Lautsprecher-mit-Licht) User Manual

DUNLOP BLT-Lautsprecher-mit-Licht

DUNLOP Bluetooth Speaker with Light

Model: BLT-Lautsprecher-mit-Licht

INTRODUCTION

Thank you for purchasing the DUNLOP Bluetooth Speaker with Light. This portable speaker combines high-quality audio playback with an integrated LED light show, designed to enhance your listening experience. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.

SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the speaker to strong impacts.
- Do not disassemble, repair, or modify the device yourself. Refer all servicing to qualified personnel.
- Keep the speaker away from water and liquids. While it is indicated as water-resistant, it is not designed for submersion.
- Use only the provided charging cable or a certified USB Type-C cable for charging.
- Dispose of the battery and device according to local regulations.

PACKAGE CONTENTS

Ensure all items are present in the package:

- 1 x DUNLOP Bluetooth Speaker with Light
- 1 x USB Type-C Charging Cable (50 cm)
- 1 x User Manual (this document)

PRODUCT OVERVIEW



Front view of the DUNLOP Bluetooth Speaker with Light, showing the speaker grille and the transparent top housing with colorful LED light tubes.

Controls and Ports



Top view of the DUNLOP Bluetooth Speaker with Light, displaying the control buttons for power, mode, volume, and light functions.

Power Button: Press and hold to turn the speaker ON/OFF. Short press to play/pause music.

Mode Button: Short press to switch between Bluetooth, USB, and Micro SD card modes.

Volume Down / Previous Track Button: Short press for previous track. Press and hold to decrease volume.

Volume Up / Next Track Button: Short press for next track. Press and hold to increase volume.

Light Mode Button: Short press to cycle through different LED light patterns or turn lights off.



Back view of the DUNLOP Bluetooth Speaker with Light, showing the various input ports.

USB-C Charging Port: For charging the speaker's internal battery.

Micro SD Card Slot: Insert a Micro SD card for direct audio playback.

USB-A Port: Insert a USB flash drive for direct audio playback.

AUX-in Port: Connect external audio devices using a 3.5mm audio cable (not included).

CHARGING THE SPEAKER

1. Locate the USB-C charging port on the back of the speaker.
2. Connect the provided USB Type-C cable to the speaker's charging port.
3. Connect the other end of the USB cable to a USB power adapter (5V/1A recommended, not included) or a computer's USB port.
4. The charging indicator light will illuminate during charging and turn off when fully charged.
5. A full charge takes approximately 2-3 hours and provides 2-3 hours of playback time, depending on volume and light usage.

Note: Charge the speaker fully before first use for optimal battery performance.

SETUP AND OPERATION

Powering On/Off

- To turn ON: Press and hold the Power button until you hear an audible prompt and the LED lights activate.
- To turn OFF: Press and hold the Power button again until the speaker powers down.

Bluetooth Pairing

1. Ensure the speaker is powered ON and in Bluetooth mode (indicated by a flashing blue LED). If not, short press the Mode button to switch to Bluetooth mode.
2. Enable Bluetooth on your smartphone, tablet, or other audio device.
3. Search for available Bluetooth devices. You should see "DUNLOP Speaker" or a similar name in the list.
4. Select "DUNLOP Speaker" to connect. Once paired, you will hear a confirmation sound, and the blue LED will stop flashing and remain solid.
5. You can now play audio from your device through the speaker.

Note: The speaker will automatically attempt to reconnect to the last paired device when powered on.

Playing Audio from USB/Micro SD Card

1. Insert a USB flash drive or Micro SD card (with audio files) into the corresponding port on the speaker.
2. The speaker should automatically switch to USB or Micro SD card mode and begin playing audio. If not, short press the Mode button to select the correct source.
3. Use the Volume Up/Down and Previous/Next Track buttons on the speaker to control playback.

Controlling LED Lights

- Short press the Light Mode button to cycle through various light patterns.
- Continue pressing the Light Mode button to find your preferred light effect or to turn the lights off.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is depleted.	Charge the speaker fully using the USB-C cable.
Cannot pair via Bluetooth.	Speaker is not in pairing mode or too far from device.	Ensure speaker is in Bluetooth mode (flashing blue LED). Move speaker closer to your device (within 10m). Turn Bluetooth off and on again on your device.
No sound during playback.	Volume is too low or device is not connected.	Increase volume on both the speaker and your connected device. Ensure Bluetooth connection is established or correct source (USB/SD) is selected.
LED lights are not working.	Lights are turned off or in a static mode.	Press the Light Mode button to cycle through light patterns or turn them on.

SPECIFICATIONS

Model Name	BLT-Lautsprecher-mit-Licht
Brand	DUNLOP
Dimensions (L x W x H)	218 x 95 x 93 mm
Weight	400 Grams
Color	Black
Material	Plastic
Connectivity Technology	Bluetooth 5.0, USB, Micro SD, AUX
Wireless Range	Up to 10 meters
Power Source	Battery Powered (1200 mAh)
Charging Port	USB Type-C
Playback Time	2-3 hours (at moderate volume with lights)
Speaker Output Power	8 Watts
Audio Output Mode	Stereo
LED Lights	9 LEDs with multiple light modes
Water Resistance	Yes (Splash-resistant, not for submersion)
Compatible Devices	Smartphones, Tablets, Laptops, USB drives, Micro SD cards

WARRANTY AND SUPPORT

This DUNLOP product comes with a limited warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support or warranty claims, please contact your retailer or the DUNLOP customer service department through their official website.