Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Luqeeg Luqeegvnts2mcpq3

Luqeeg Bladeless Desk Fan Instruction Manual

Model: **Luqeegvnts2mcpq3** | Brand: **Luqeeg**

1. Product Overview

The Luqeeg Bladeless Desk Fan is a compact and efficient cooling solution designed for personal spaces such as offices, homes, and bedrooms. Its innovative bladeless design ensures safety, especially in households with children and pets, while providing quiet and effective air circulation. This fan also features an integrated LED light with adjustable brightness, making it a versatile addition to any room.





Figure 1: Front view of the Luqeeg Bladeless Desk Fan, showcasing its sleek design and touch controls.

Key features include:

- **Bladeless Design:** Enhances safety by eliminating exposed fan blades, making it ideal for homes with children and pets.
- **Quiet Operation:** Engineered with aerodynamic air ducts to minimize noise, ensuring a peaceful environment.
- **90-Degree Oscillation:** Provides wide-angle air distribution to cool larger areas effectively.
- **Long Duration Cooling:** Equipped with a 4000mAh battery for extended use, utilizing bladeless turbine technology for compressed, cool airflow.
- **Integrated LED Light:** Features a soft LED light with adjustable brightness for nighttime illumination and comfort.
- **USB Rechargeable:** Conveniently powered via USB for easy charging.

2. What's in the Box

Upon unboxing your Luqeeg Bladeless Desk Fan, please ensure all components are present and in good condition:

- 1 x Bladeless Desk Fan (with built-in 4000mAh Lithium Ion Battery)
- 1 x Charging Cable (USB)
- 1 x Instruction Manual (This document)



Figure 2: The Bladeless Desk Fan alongside its USB charging cable, as typically found in the product packaging.

Note: The product description mentions a "Remote" in "whats_in_the_box" but a customer review states "Missing Remote". Please verify your package contents upon arrival. This manual describes operation via touch control.

3. Setup and Charging

Before first use, it is recommended to fully charge the fan's built-in battery.

1. Locate the USB charging port on the fan.
2. Connect the provided USB charging cable to the fan's charging port.
3. Plug the other end of the USB cable into a compatible USB power source (e.g., a computer USB port, a USB wall adapter, or a power bank) with a DC 5V2A output.
4. The charging indicator light will illuminate, typically red or amber, during charging.
5. Charging time is approximately 3 hours for a full charge. The indicator light will change color (e.g., to green or off) when fully charged.

Ensure the fan is placed on a stable, flat surface during operation and charging.

4. Operating Instructions

The Luqeeg Bladeless Desk Fan features intuitive touch controls for easy operation.

4.1 Fan Control




Figure 3: Visual representation of the three fan speed settings: Natural Wind, Strong Wind, and Sleep Wind.

1. **Power On/Adjust Wind Speed:**
    - Press the power button (usually indicated by a power symbol) once to turn on the fan at the lowest speed (Natural Wind).
    - Subsequent short presses of the power button will cycle through the wind speeds:
        - 1st press: Natural Wind (Gear 1)
        - 2nd press: Strong Wind (Gear 2)
        - 3rd press: Sleep Wind (Gear 3)
        - 4th press: Power Off
2. **Automatic Oscillation:**
    - To activate the 90-degree automatic oscillation feature, press and hold the power button for a few seconds. The fan head will begin to rotate from side to side.

- To stop oscillation, press and hold the power button again.




Figure 4: Diagram illustrating the 90-degree wide-angle oscillation capability of the fan, ensuring broad air distribution.

4.2 LED Light Control

1. **Turn On/Off Light:**
    - Press the light button (usually indicated by a light bulb symbol) once to turn the LED light on or off.
2. **Adjust Brightness:**
    - To adjust the brightness of the LED light, press and hold the light button. The brightness will cycle through its levels. Release the button when the desired brightness is reached.



Figure 5: The fan operating in a bedroom, demonstrating the soft illumination provided by its integrated LED light.

5. Specifications

Feature	Detail
Model Name	Luqeegvnts2mcpq3
Power Source	Battery Powered (USB Rechargeable)
Battery Type	Lithium Ion Battery
Battery Capacity	4000mAh
Voltage	DC 5V2A

Feature	Detail
Charging Time	Approx. 3 Hours
Control Method	Touch Control
Oscillation Angle	90 Degrees
Number of Power Levels	3 (Natural, Strong, Sleep Wind)
Material	ABS, PC, Silicone (Plastic)
Item Weight	1.91 pounds
Dimensions	12.91 x 5.79 x 4.88 inches (Package Dimensions)
Room Type	Office, Bedroom
Indoor/Outdoor Usage	Indoor

6. Maintenance and Care

Proper maintenance ensures the longevity and optimal performance of your bladeless fan.

- **Cleaning:**
  - Always unplug the fan before cleaning.
  - Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals.
  - For dust accumulation in the air intake or outlet, use a soft brush or a vacuum cleaner with a narrow attachment to gently remove debris.
  - Do not immerse the fan in water or allow water to drip into the internal components.
- **Storage:**
  - When not in use for extended periods, store the fan in a cool, dry place, away from direct sunlight and extreme temperatures.
  - It is advisable to store it in its original packaging to protect it from dust and damage.

7. Troubleshooting

If you encounter any issues with your Luqeeg Bladeless Desk Fan, please refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted.	Charge the fan fully (approx. 3 hours).
	Charging cable or adapter issue.	Ensure the charging cable is securely connected and try a different USB adapter or port.

Problem	Possible Cause	Solution
Fan is not oscillating.	Oscillation feature not activated.	Press and hold the power button to activate oscillation.
LED light is not working.	Light feature not activated.	Press the light button to turn it on.
Weak airflow.	Fan is on a low speed setting.	Press the power button to cycle to a higher wind speed.
	Air intake/outlet blocked or dusty.	Clean the air intake and outlet areas as described in the Maintenance section.

If the problem persists after trying these steps, please contact customer support.

8. Warranty and Support

Luqeeg products are manufactured with quality and reliability in mind. Specific warranty details, including coverage period and terms, are typically provided with your purchase documentation or can be found on the official Luqeeg website.

For technical support, warranty claims, or any other inquiries, please refer to the contact information provided on your product packaging or visit the official Luqeeg brand store on Amazon:

Visit the Luqeeg Store on Amazon

Please have your model number (Luqeegvnts2mcpq3) and purchase date ready when contacting support.

© 2024 Luqeeg. All rights reserved.
This manual is subject to change without notice. Please refer to the latest version available online.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C5DSW1G2

More documents and user manuals: **https://manuals.plus/**