

# **JOOLA Elemental Pickleball Net Instruction Manual**

Model: 18233 | Brand: JOOLA

## **1. INTRODUCTION**

The JOOLA Elemental Pickleball Net is designed for both recreational and competitive play, offering a portable and durable solution for setting up a pickleball court anywhere. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your net system.



The JOOLA Elemental Pickleball Net system, including the regulation-size net and its convenient black carrying bag with yellow straps, ready for transport or storage.

## 2. PRODUCT FEATURES

- **Regulation Height:** Measures 91.4 cm (36 inches) on the sides and 86.4 cm (34 inches) in the middle. The 6.7 m (22 feet) length covers the entire pickleball court with the recommended extra 30.5 cm (1 foot) on each side.
- **Indoor and Outdoor Use:** Features a metal frame that creates a weather-resistant outdoor pickleball net, capable of withstanding various elements. The durable PVC net is knotless for improved sightlines and resists dirt and moisture.
- **Portable Design:** Includes a carrying bag with a sturdy zipper and reinforced stitching. The entire system weighs approximately 9 kg (under 20 lbs), making it easy to transport and set up anywhere.
- **Quick and Easy Setup:** No tools are required for assembly. All necessary components are included in the carrying bag, with labeled parts and clear instructions for rapid setup. Includes net markings for precise placement and a tension adjuster.



This image details the premium materials used in the JOOLA pickleball net: durable nylon fabric with a tensioning strap, knotless PE material with a plastic inside coating for the net, and durable quality interlocking steel for the frame, ensuring a free-standing and all-weather structure.

### 3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- Pickleball Net (1)
- Steel Frame Poles (various labeled sections)
- Base Supports (2)
- Carrying Bag (1)
- Instruction Manual (this document)


### 4. SETUP INSTRUCTIONS

Follow these steps to assemble your JOOLA Elemental Pickleball Net:

1. **Unpack Components:** Remove all parts from the carrying bag and lay them out on a clean, flat surface. Identify all labeled poles and connectors.
2. **Assemble Base:** Connect the horizontal base poles to the vertical support poles. Ensure the wide, folded feet are securely attached to the bottom of the vertical supports for stability.
3. **Connect Horizontal Bar:** Assemble the long horizontal bar that will support the bottom of the net. This bar typically consists of several interlocking sections.
4. **Attach Net to Frame:** Slide the net onto the assembled frame. The net should have sleeves or loops that fit over the vertical and horizontal poles. Ensure the net is centered and taut.
5. **Adjust Tension:** Use the integrated tension adjuster (if applicable) to achieve the desired net tension and ensure the net maintains regulation height at the center (86.4 cm or 34 inches).
6. **Final Placement:** Position the assembled net on your chosen playing surface. Ensure the base is stable and not prone to tipping.

# REGULATION SIZE

## GREAT FOR RECREATIONAL AND COMPETITIVE PLAY



This image illustrates the regulation dimensions of the JOOLA pickleball net: 3 feet (91.4 cm) height at the posts, 34 inches (86.4 cm) height at the center, and a total length of 22 feet (6.7 meters).

# PORTABLE CONVENIENT STORAGE



ALL NET PIECES FIT IN A SINGLE

**CONVENIENT, DURABLE  
CARRYING BAG**

BAG WEIGHS UNDER 20 LBS (WITH ALL NET PIECES INSIDE)

The JOOLA pickleball net system is highly portable. All net pieces fit into the durable carrying bag, which weighs under 20 lbs (9 kg) when packed, making it easy to transport.

## 5. OPERATING INSTRUCTIONS


Once assembled, the JOOLA Elemental Pickleball Net is ready for use. Ensure the net is properly tensioned and stable before play. This net is suitable for both indoor and outdoor environments.

- Court Placement:** Place the net across the center of your chosen playing area, ensuring it is perpendicular to the sidelines.
- Stability Check:** Before starting play, gently push on the net posts to confirm they are stable and the base supports are firmly on the ground.
- Wind Conditions:** While designed to be stable, in very strong winds, consider securing the net further or disassembling it to prevent damage.

# ALL-WEATHER

## PERFECT FOR INDOOR AND OUTDOOR USE

JOOLA® PICKLEBALL



The JOOLA pickleball net is designed for all-weather use, suitable for both outdoor courts, as shown on a green court with a player, and indoor courts, depicted on a blue court.

## 6. MAINTENANCE

Proper maintenance will extend the life of your JOOLA Elemental Pickleball Net:

- **Cleaning:** Wipe down the net and frame with a damp cloth to remove dirt and debris. For stubborn stains, a mild soap solution can be used. Avoid harsh chemicals.
- **Drying:** Ensure the net and frame are completely dry before disassembling and storing to prevent mold, mildew, or rust.
- **Storage:** When not in use, disassemble the net and store all components in the provided carrying bag. Store the bag in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect all poles, connectors, and the net for any signs of wear, damage, or loose parts. Replace any damaged components as needed.

## 7. TROUBLESHOOTING

Here are some common issues and their solutions:

Problem	Possible Cause	Solution
Net is not taut or sags in the middle.	Improper assembly; tension not adjusted; net not fully stretched.	Ensure all poles are fully connected. Use the tension adjuster to tighten the net. Verify the net is correctly attached to all frame points.
Net system is unstable or wobbles.	Base supports not fully extended; uneven ground; loose connections.	Ensure base feet are fully unfolded and flat on the surface. Move to a level playing area. Check all pole connections for tightness.
Difficulty disassembling poles.	Dirt or debris in joints; poles stuck due to pressure.	Gently twist and pull. Clean joints if visible dirt is present. Avoid forcing connections.

## 8. SPECIFICATIONS

<b>Brand</b>	JOOLA
<b>Model Number</b>	18233
<b>Material</b>	Aluminum (frame), PVC (net)
<b>Color</b>	Black
<b>Net Height (Sides)</b>	91.4 cm (36 inches / 3 feet)
<b>Net Height (Center)</b>	86.4 cm (34 inches)
<b>Net Length</b>	6.7 m (22 feet)
<b>Item Weight</b>	8.3 Kilograms (approx. 18.3 lbs)
<b>Recommended Use</b>	Pickleball

## 9. WARRANTY AND SUPPORT

JOOLA products are manufactured to high-quality standards. For information regarding warranty coverage, product support, or replacement parts, please refer to the official JOOLA website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

