



[Manuals.plus](#) /

> [AVERA](#) /

> AVERA HEL01 Electric Built-in Oven User Manual

AVERA HEL01

AVERA HEL01 Electric Built-in Oven User Manual

Model: HEL01 | Capacity: 67 Liters

1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation, installation, and maintenance of your AVERA HEL01 Electric Built-in Oven. Please read this manual thoroughly before using the appliance and keep it for future reference.



Figure 1: Front view of the AVERA HEL01 Electric Built-in Oven. This image displays the sleek black design with control knobs and the oven door.

2. SAFETY INFORMATION

- Ensure the oven is installed by a qualified technician.
- Verify your electrical installation supports **220-240V**. Incorrect voltage can damage the appliance and pose a safety risk.
- Do not touch hot surfaces. Always use oven mitts.
- Keep children away from the appliance during operation.
- Do not use abrasive cleaners or sharp objects on the oven's surfaces.
- Unplug the oven before cleaning or maintenance.

3. INSTALLATION AND DIMENSIONS

The AVERA HEL01 is designed for built-in installation. Proper ventilation is crucial for optimal performance and safety.

3.1 Electrical Requirements

This oven requires a **220-240V** electrical connection. It is essential to confirm that your home's electrical system can support this requirement. Consult a certified electrician for installation to ensure compliance with local electrical codes.

3.2 Product Dimensions

Refer to the diagram below for the precise dimensions of the oven and the required cutout for built-in installation.




Figure 2: Dimensional diagram of the AVERA HEL01 oven. The diagram shows the oven's length (59.5 cm), depth (57 cm), and height (59.8 cm), along with the recommended built-in measurements (58.5 x 56.4 x 55.5 cm).

Product Dimensions: 59.8 cm (Height) x 59.5 cm (Width) x 57 cm (Depth)

Weight: 32 kg

Recommended Built-in Dimensions: 58.5 cm (Height) x 56.4 cm (Width) x 55.5 cm (Depth)

4. OPERATING INSTRUCTIONS

Your AVERA HEL01 oven features 9 versatile cooking functions and a user-friendly control panel.




Figure 3: Overview of key features including 9 integrated functions, a 120-minute timer, adjustable temperature from 50°C to 250°C, and construction from stainless steel and tempered glass.

4.1 Control Panel

The oven is controlled via intuitive knobs for temperature, function selection, and timer settings. The halogen light inside the oven provides clear visibility of your food during cooking.

4.2 Cooking Functions

The HEL01 offers 9 distinct cooking functions, allowing for a wide range of culinary preparations. The temperature can be adjusted from **50°C to 250°C**.




Figure 4: Diagram illustrating the oven's function dial and descriptions of various cooking modes, including defrost, conventional roasting, rotisserie with fan, half grill, double grill with rotisserie, double grill with rotisserie and fan, bottom grill with fan, and top/bottom element with rotisserie and fan.

- **Defrost:** Gentle air circulation for thawing food.
- **Rotisserie Kit + Conventional:** Ideal for roasting chicken, duck, veal, and lamb.
- **Rotisserie Kit with Heating Fan:** For meats, fish, and delicate pastries.
- **Half Grill:** Suitable for fillets or sausages.
- **Double Grill + Rotisserie Kit:** For chicken, duck, lamb, beef, and hamburgers.
- **Double Grill + Rotisserie Kit + Fan:** Enhanced roasting for chicken, duck, veal, and lamb.
- **Bottom Grill + Fan:** Perfect for pizzas.
- **Top Element + Bottom Element + Rotisserie Kit + Fan:** For faster roasting and grilling.
- **Timer:** Set cooking duration up to 120 minutes.



AVERA

¡Puedes solicitar factura de tu compra!

Para ello necesitamos:

- Razón social o nombre
- RFC
- Régimen fiscal
- Código postal
- Forma de pago
- Uso del CFDI
- Fecha de compra

Condiciones



Por favor, ten presente que la información que nos compartas deberá coincidir con la que indica tu constancia de situación fiscal.



Solo podremos generar tu factura hasta 30 días naturales después de tu compra.

Figure 5: The AVERA HEL01 oven installed in a modern kitchen, showcasing food being cooked inside, highlighting its operational use.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and optimal performance of your oven.

5.1 Cleaning the Oven Interior and Exterior

- Allow the oven to cool completely before cleaning.
- Use a soft cloth and mild detergent for the exterior surfaces.
- For the interior, use oven-safe cleaners as directed by the product manufacturer. Avoid harsh abrasives.

5.2 Removable Glass Panels

The oven door features removable glass panels for easier cleaning. To remove them:

1. Open the oven door fully.
2. Press the buttons on the top part of both sides of the door's upper seal and pull it forward.
3. Carefully remove the glass panels.
4. Clean the glass with a soft cloth and multi-purpose liquid or glass cleaner.

5. After cleaning, reinsert the glass panels in the same position, ensuring the "TERMOGLASS" inscription faces the inside of the door.
6. Replace the upper seal, making sure the side buttons click into place.

6. INCLUDED ACCESSORIES

Your AVERA HEL01 oven comes with a set of accessories to enhance your cooking experience:



Figure 6: A visual representation of all accessories included with the AVERA HEL01 oven: a handle for tray/rack, a baking tray, a large wire rack, a small rack, and a rotisserie kit.

- **Handle for Tray/Rack:** For safe handling of hot trays and racks.
- **Baking Tray:** For various baking and roasting needs.
- **Large Wire Rack:** For supporting dishes and bakeware.
- **Small Rack:** Additional support for smaller items.
- **Rotisserie Kit:** For perfect rotisserie cooking.

7. TROUBLESHOOTING

If you encounter issues with your oven, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|----------------------------|--|---|
| Oven does not turn on. | No power supply; incorrect voltage. | Check power connection. Ensure the oven is connected to a 220-240V outlet. Consult an electrician if unsure. |
| Oven not heating properly. | Incorrect temperature setting; door not closed properly. | Verify temperature setting. Ensure the oven door is fully closed. |
| Uneven cooking. | Improper rack placement; overloaded oven. | Refer to cooking guidelines for optimal rack positions. Avoid overcrowding the oven. |

For issues not listed here, please contact AVERA customer support.

8. SPECIFICATIONS

| Feature | Detail |
|----------------------------|---------------------------------------|
| Brand | AVERA |
| Model Number | HEL01 |
| Capacity | 67 Liters |
| Heating Method | Electric |
| Functions | 9 (Bake, Grill, Roast, Defrost, etc.) |
| Temperature Range | 50°C to 250°C |
| Timer | Up to 120 minutes |
| Voltage | 220-240V |
| Material | Stainless Steel, Tempered Glass |
| Color | Black |
| Product Dimensions (HxWxD) | 59.8 x 59.5 x 57 cm |
| Weight | 32 kg |

9. WARRANTY AND SUPPORT

Your AVERA HEL01 Electric Built-in Oven is covered by a **2-year warranty** from the date of purchase. For warranty claims, technical assistance, or any questions regarding your product, please contact AVERA customer support through their official channels. Keep your proof of purchase for warranty validation. You can visit the AVERA store on Amazon for more information: [AVERA Store](#)