Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MYNTA MC1612

MYNTA M1612 Massage Chair User Manual

Model: MC1612

Product Overview

This manual provides essential instructions for the safe and effective use of your MYNTA M1612 Full Body Massage Chair. Please read this manual thoroughly before operation and retain it for future reference.

Key Features:

- Newly upgraded larger intelligent massage rollers with a 52-inch SL Track, providing massage from neck to hips.
- Full body air compression massage with airbags in the shoulder, arms, lumbar, calves, and feet.
- Lumbar and calf heating functions to promote improved blood circulation.
- Foot roller massage for targeted foot relief.
- Two control methods: an armrest quick control panel and an LCD touchscreen tablet.
- Four-stage zero gravity recline: Initial Step, Reclining Step, Comfort Step, and Deep Step.
- Twelve automatic massage modes and customizable manual modes for a personalized experience.
- Thai Stretch function for full body extension.
- Integrated HD Bluetooth speakers for audio playback.

Important Safety Information

For your safety and to prevent damage to the product, please adhere to the following guidelines:

- Always follow the weight capacity guidelines specified in the product specifications.
- Do not use the chair while sleeping or under the influence of alcohol.
- Ensure proper handling and placement to prevent tipping or damage to the chair.
- Keep the chair away from heat sources and flammable materials.
- Do not operate the chair if the power cord is damaged or if the chair shows any signs of damage.
- Always turn off the chair and unplug it from the power outlet when not in use or before cleaning.
- Consult the complete user manual for detailed safety instructions and warnings.

Setup Guide

The MYNTA M1612 massage chair is designed for minimal assembly. It arrives largely pre-assembled. Follow these steps for initial setup:

1. **Unpacking:** Carefully remove the chair from its packaging. Ensure all components are present and undamaged.
2. **Placement:** Position the massage chair on a flat, stable surface. Ensure there is sufficient space around the chair for reclining and zero-gravity functions (refer to dimensions).
3. **Power Connection:** Connect the power cord securely to the chair's power inlet and then plug it into a grounded electrical outlet.
4. **Initial Check:** Before first use, inspect the chair for any loose connections or visible damage.



Image: MYNTA M1612 Massage Chair dimensions and packaging. This image illustrates the chair's dimensions, including seat width, height, and overall length in both upright and reclined positions. It also shows the chair being unboxed from its packaging, highlighting its largely pre-assembled state.

Operating Instructions

Your MYNTA M1612 massage chair offers various functions for a customized massage experience. Familiarize yourself with the controls and features below.

Control Methods:

- **Armrest Quick Control Panel:** Located on the armrest for easy access to basic functions like power, zero gravity, and recline adjustments.
- **LCD Touchscreen Tablet:** Provides comprehensive control over all massage programs, intensity levels, heating, and other settings.



Image: Intelligent Touchscreen and Shortcut Button. This image displays the detailed LCD touchscreen interface for advanced control and the convenient shortcut buttons located on the armrest for quick adjustments.

Zero Gravity Function:

The zero-gravity feature elevates your legs above your heart, reducing pressure on your spine and enhancing the massage experience. The M1612 offers four stages:

1. Initial Step

2. Reclining Step
3. Comfort Step
4. Deep Step



Image: Three-Stage Zero Gravity Recline. This graphic illustrates the different recline angles for the zero-gravity positions, showing the transition from a standard recline to a deeper, more elevated position.

Massage Programs and Techniques:

The chair features a 52-inch SL-Track system, providing comprehensive massage coverage from your neck to your hips. Choose from 12 auto modes or customize your massage using various techniques.



Image: SL-Track System. This diagram shows the extended SL-Track path within the massage chair, illustrating how the rollers follow the natural curve of the spine from the neck down to the hips and glutes.



Image: Twelve Auto Modes and Six Massage Techniques. This image displays the various preset massage programs available, such as "Athletic," "Deep Tissue," and "Rest & Sleep," along with the six core massage techniques including Shiatsu, Kneading, and Tapping.

- **Auto Modes:** Select from 12 pre-programmed massage routines tailored for different needs (e.g., Recovery, Deep Tissue, Thai Stretch).
- **Manual Modes:** Customize your massage by selecting specific techniques (Shiatsu, Kneading, Knocking, Rubbing, Tapping, Knead & Knock) and adjusting intensity, speed, and roller width.
- **Air Compression:** Activate airbags in the shoulders, arms, lumbar, calves, and feet for a full-body compression massage. Adjust intensity as desired.
- **Heating Function:** Engage lumbar and calf heating for soothing warmth.
- **Foot Roller:** Activate the foot rollers for a targeted foot massage.



Image: Full Body Air Compression and Heating Zones. This internal view of the massage chair highlights the locations of the shoulder, back, arm, and calf airbags, as well as the lumbar and calf heating elements and foot rollers.

Thai Stretch Function:

The Thai Stretch program gently stretches your back and legs, promoting flexibility and relieving tension. The back and leg sections can be controlled separately for personalized stretching.



Image: Thai Stretch Function. This image depicts a user in the massage chair undergoing the Thai Stretch, with arrows indicating the upward movement of the leg and back sections to create a gentle stretching sensation.

Bluetooth Speakers:

Connect your mobile device via Bluetooth to the chair's integrated HD speakers for an immersive audio experience during your massage session.



Image: HD Bluetooth Speakers. This image shows the integrated speakers within the headrest area of the massage chair, with a smartphone connected via Bluetooth playing music, illustrating the audio feature.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your massage chair.

- **Cleaning:** Wipe the chair's surface with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the faux leather material.
- **Power Cord:** Regularly inspect the power cord for any signs of damage. If damaged, contact customer support for assistance.
- **Storage:** When not in use for extended periods, unplug the chair and store it in a clean, dry environment away from direct sunlight and extreme temperatures.
- **Moving the Chair:** If you need to move the chair, ensure it is unplugged. Refer to the setup guide for safe handling practices to prevent damage or injury.

Troubleshooting

If you encounter any issues with your MYNTA M1612 massage chair, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Chair does not power on.	Power cord not properly connected; power outlet issue; main power switch off.	Ensure the power cord is securely plugged into both the chair and a working electrical outlet. Check if the main power switch (if present) is in the "ON" position. Try a different outlet.
Massage functions are not working.	Chair is not fully reclined; program not selected; safety sensor activated.	Ensure the chair is in an appropriate position for massage. Select an auto mode or manual program from the control panel/tablet. Check for any obstructions that might activate safety sensors.
Remote control/tablet is unresponsive.	Low battery (if applicable); connection issue.	If the remote uses batteries, replace them. Ensure the tablet is securely connected (if wired) or within range (if wireless). Restart the chair by unplugging and replugging it.
Unusual noises during operation.	Loose components; normal operational sounds.	Some operational sounds are normal. If the noise is loud, grinding, or unusual, power off the chair immediately and contact customer support.

If the problem persists after attempting these solutions, please contact MYNTA customer service for further assistance.

Product Specifications

Feature	Detail
Brand	MYNTA
Model Name	MC1612E
Color	Brown
Material	Faux Leather (Seat), Alloy Steel (Frame)
Item Dimensions (L x W x H)	57 x 30 x 43 inches
Item Depth	62 inches
Chair Backrest Width	83.82 centimeters
Maximum Weight Recommendation	150 kg
Massage Track	52-inch SL-Track
Zero Gravity Stages	4 (Initial, Reclining, Comfort, Deep)
Auto Massage Modes	12
Massage Techniques	Shiatsu, Kneading, Knocking, Rubbing, Tapping, Knead & Knock

Feature	Detail
Heating Zones	Lumbar, Calf
Air Compression	Shoulder, Arms, Lumbar, Calves, Feet
Control Methods	Armrest Quick Control Panel, LCD Touchscreen Tablet
Additional Features	HD Bluetooth Speakers, Thai Stretch Function
Product Care Instructions	Wipe Clean

Warranty and Customer Support

MYNTA is committed to providing excellent customer service. Your massage chair comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions.
For any questions, technical assistance, or warranty claims, please contact MYNTA customer service. Our team is available to assist you.

- **Customer Service Availability:** 24 hours.
- **Contact Information:** Please refer to the contact details provided in your product packaging or on the official MYNTA website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C5H55LY2

More documents and user manuals: **https://manuals.plus/**