

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Braun](#) /
- › [Braun Series 9 Pro+ 9517s Electric Shaver User Manual](#)

Braun 9517s

Braun Series 9 Pro+ 9517s Electric Shaver User Manual

Model: 9517s

1. INTRODUCTION

Welcome to the Braun Series 9 Pro+ 9517s Electric Shaver user manual. This guide provides essential information for the safe and effective use, maintenance, and troubleshooting of your new shaver. Please read all instructions carefully before first use and keep this manual for future reference.

Safety Warning:

Use the device with caution to avoid injury or skin irritation. Clean the device according to instructions and ensure it is completely dry before charging. Do not use the device near water.

2. PRODUCT OVERVIEW

The Braun Series 9 Pro+ 9517s is a premium electric shaver designed for ultimate closeness and skin comfort. It features advanced shaving elements and a precision trimmer for versatile grooming.

Key Components:

- Shaver Unit
- ProShave Elements (Foil & Cutter Cassette)
- ProTrimmer
- Power Button
- Display (Battery & Head Status)
- Charging Stand
- Travel Case
- Cleaning Brush
- Charging Cable



Figure 2.1: Braun Series 9 Pro+ 9517s Electric Shaver and Accessories.

Ultimativer Präzisions-ProTrimmer



Figure 2.2: Detailed view of the 5 ProShave elements.

3. SETUP

Before first use, fully charge your Braun Series 9 Pro+ shaver.

Charging:

Connect the charging cable to the charging stand and plug it into a power outlet. Place the shaver in the charging stand. The display will indicate the charging status. A full charge provides up to 60 minutes of cordless shaving.



Figure 3.1: Charging the shaver on its stand.

4. OPERATING INSTRUCTIONS

General Shaving:

For optimal results, hold the shaver at a right angle (90°) to your skin and shave against the direction of hair growth. Stretch your skin with your free hand to ensure a smooth surface.

The Series 9 Pro+ is suitable for both dry and wet shaving. For wet shaving, you can use shaving foam or gel.

5 perfekt aufeinander abgestimmte Rasiererelemente



Figure 4.1: Achieving a close and comfortable shave.



Figure 4.2: Shaving with sonic vibrations for efficiency.



Figure 4.3: Flexible head movement for contour adaptation.

Using the ProTrimmer:

The integrated ProTrimmer with surgical steel blades is ideal for precise trimming of sideburns, mustaches, and longer hairs. Slide the trimmer up to activate it.

**Précision
optimale**
même sur les poils longs

PRO✓
Désormais avec
ProTrimmer

Figure 4.4: Precision trimming with the ProTrimmer.



Figure 4.5: Shaving effectiveness on different beard lengths.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene.

Daily Cleaning:

After each use, rinse the shaver head under warm running water. You can also use the included cleaning brush to remove hair particles.

Deep Cleaning:

For a more thorough clean, detach the shaving head and rinse both the head and the shaver body under running water. Ensure all parts are completely dry before reassembling or charging.

Foil & Cutter Cassette Replacement:

To maintain 100% shaving performance, replace the foil and cutter cassette approximately every 18 months, or

when worn. The shaver's display may indicate when replacement is due.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver not turning on	Low battery or no power connection.	Ensure the shaver is charged. Place it on the charging stand. Try a different power outlet.
Poor shaving performance	Clogged or worn foil/cutter cassette.	Clean the shaver head thoroughly. Consider replacing the foil and cutter cassette if it's old or damaged.
Skin irritation	Improper shaving technique or sensitive skin.	Ensure your skin is clean before shaving. Shave against the direction of hair growth. If using wet shaving, ensure adequate foam/gel. Avoid pressing too hard.

7. SPECIFICATIONS

Feature	Detail
Brand	Braun
Model Number	9517s
Power Source	Battery Powered (Li-ion)
Battery Life	60 minutes
Special Features	Waterproof, Rechargeable
Blade Material	Stainless Steel
Item Weight	455 Grams
Package Dimensions	25.1 x 13.9 x 7.1 cm
Country of Origin	Germany
Components Included	Electric shaver, charging station, travel case, charging cable, cleaning brush

8. WARRANTY AND SUPPORT

Your Braun Series 9 Pro+ 9517s shaver comes with a manufacturer's warranty. Please refer to Braun's official website ([Braun.com](https://www.braun.com)) for detailed warranty conditions and registration.

For technical support, spare parts, or service, please contact Braun customer service or visit their official website.



Figure 8.1: Up to 5 Years Warranty.