VONROC TB502XX

VONROC Telescopic Washing Brush TB502XX User Manual

Model: TB502XX | Brand: VONROC

1. Product Overview

The VONROC TB502XX Telescopic Washing Brush is a versatile cleaning tool designed for efficient and gentle cleaning of various high and hard-to-reach surfaces. Its extendable pole, integrated water flow, and included attachments make it ideal for tasks such as cleaning solar panels, windows, roofs, walls, and large vehicles.

Included Components:

- Telescopic Pole (1.30m to 6.50m extension)
- Multi-purpose Brush Head
- 2-in-1 Window Cleaner Attachment (squeegee and scrubbing pad)
- Water Hose
- In-line Soap Dispenser
- Ball Valve for water control





This image displays the complete VONROC telescopic washing brush system, featuring the extendable pole, the primary brush head, a coiled hose for water supply, an in-line soap dispenser, and a separate 2-in-1 window cleaning attachment with a squeegee and scrubbing pad.

2. Setup Instructions

1. **Assemble the Pole:** Extend the telescopic pole to your desired length by twisting the locking mechanisms counter-clockwise to loosen, extending the sections, and then twisting clockwise to secure. Ensure all sections are firmly locked before use.
2. **Attach Cleaning Head:** Select either the multi-purpose brush head or the 2-in-1 window cleaner attachment. Align the attachment with the end of the pole and secure it firmly.
3. **Connect Water Hose:** Connect one end of the provided water hose to the inlet on the telescopic pole. Connect the other end of the hose to the in-line soap dispenser (if using), and then to your garden hose or water source. Ensure all connections are tight to prevent leaks.




This image shows a close-up of the water connection point, featuring an in-line filter and a ball valve, connected to a garden hose. This component ensures clean water supply to the brush and allows for water flow control.

4. **Fill Soap Dispenser (Optional):** If using soap, unscrew the cap of the in-line soap dispenser and fill it with your preferred cleaning solution. Re-attach the cap securely.

3. Operating Instructions

1. **Adjust Pole Length:** Adjust the telescopic pole to the appropriate length for the surface you are cleaning. The pole extends from 1.30 meters to a maximum of 6.50 meters.





This diagram visually represents the minimum and maximum extension capabilities of the telescopic pole, showing it can extend from 1.6 meters to 6.5 meters, providing significant reach for high surfaces.

2. **Control Water Flow:** Turn on the water supply from your tap. Use the ball valve on the hose connection to control the water flow to the brush head.
3. **Apply Soap (if using):** If the soap dispenser is filled, activate the soap flow by adjusting the dispenser's setting.

4. **Cleaning Surfaces:**
    - **General Cleaning (Brush Head):** Use the multi-purpose brush head with its soft bristles for gentle yet effective cleaning of solar panels, walls, and large vehicles. Move the brush in a consistent motion across the surface.



A person is shown using the fully extended VONROC telescopic washing brush to clean solar panels located on the roof of a two-story house. The long reach of the pole allows for effective cleaning of high and hard-to-reach surfaces.



A detailed view of the main brush head in action on a window surface. Water streams are visible, indicating the integrated water flow feature that aids in washing and rinsing during cleaning.

- **Window Cleaning (2-in-1 Attachment):** For windows, use the scrubbing pad side to apply cleaning solution and scrub the glass. Then, flip the attachment to use the squeegee for streak-free drying.



This image shows the scrubbing pad side of the 2-in-1 window cleaner attachment being used on a window, highlighting its soft material designed for gentle yet effective cleaning.



The image focuses on the squeegee attachment, demonstrating its use on a window. Water is seen running off the glass, indicating effective cleaning and drying with the squeegee.

5. **Rinsing:** Once cleaning is complete, turn off the soap flow (if applicable) and continue with plain water to rinse the surface thoroughly.

4. Maintenance

- **Clean Attachments:** After each use, rinse the brush head and window cleaner attachment thoroughly with clean water to remove any dirt or soap residue. Allow them to air dry completely.
- **Drain Pole:** Disconnect the hose and allow any remaining water to drain from the telescopic pole. This prevents water stagnation and potential damage.
- **Store Properly:** Retract the telescopic pole to its shortest length for compact storage. Store the brush and all accessories in a clean, dry place, away from direct sunlight and extreme temperatures.
- **Check Connections:** Periodically inspect all hose connections and locking mechanisms for wear or damage. Replace any worn parts to ensure optimal performance and safety.

5. Troubleshooting

Problem	Possible Cause	Solution
Low or no water flow	Tap not fully open, hose kinked, connections loose, filter clogged.	Ensure tap is fully open. Straighten any kinks in the hose. Tighten all connections. Check and clean the in-line filter.
Soap not dispensing	Dispenser empty, dispenser setting incorrect, dispenser clogged.	Refill the soap dispenser. Adjust the dispenser setting to allow soap flow. Clean the dispenser if clogged.
Pole sections not locking securely	Locking mechanisms not tightened, dirt in joints.	Ensure locking mechanisms are twisted clockwise until tight. Clean any dirt or debris from the pole joints.
Brush leaves streaks on windows	Dirty squeegee blade, insufficient rinsing, hard water.	Clean the squeegee blade. Ensure thorough rinsing after washing. Consider using distilled water or a water softener if hard water is an issue.

6. Specifications

Feature	Detail
Brand	VONROC
Model Number	TB502XX
Color	Black
Pole Extension Length	1.30 m to 6.50 m (130 cm to 650 cm)
Material	Plastic
Item Weight	3.12 Kilograms
Handle Material	Rubber (Softgrip)
Specific Uses	Roofs, Solar Systems, Winter Gardens, Windows, Facade Panels, Walls, Large Vehicles
Included Components	Multi-purpose brush, Water hose, Soap dispenser, Ball valve, 2-in-1 window cleaner

7. Customer Support Policy

VONROC is committed to providing reliable tools and excellent customer service. In most cases, if a product is found to be defective, VONROC aims to send a replacement directly to the customer without requiring the return of the faulty unit, thereby minimizing environmental impact and inconvenience.

For any questions, issues, or support needs regarding your VONROC Telescopic Washing Brush, please refer to the official VONROC website or contact their customer service directly. Always ensure you have your model number (TB502XX) ready for faster assistance.

VONROC's philosophy is to empower you to *Build Your Future* with quality tools and dependable support.

© 2025 VONROC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question