

[Manuals.plus](#) /

› [Nespresso](#) /

› Nespresso Vertuo Lattissima by De'Longhi User Manual

Nespresso ENV300W

Nespresso Vertuo Lattissima by De'Longhi User Manual

MODEL: ENV300W

Brand: Nespresso

Introduction

Welcome to the Nespresso Vertuo Lattissima by De'Longhi user manual. This guide provides essential information for setting up, operating, maintaining, and troubleshooting your new coffee and espresso machine. The Vertuo Lattissima is designed to offer a seamless coffee experience, allowing you to create a variety of coffee and milk recipes with a single touch.

Your machine supports various coffee formats in 6 sizes, including 5, 8, 12, and 18 fl. oz coffees, as well as single and double espressos, brewed hot or over ice. It features an integrated milk solution for creating cappuccinos, lattes, and hot foam effortlessly.



Image: The Nespresso Vertuo Lattissima machine in white, showcasing its sleek design, integrated milk frother, and a brewed coffee.

Important Safety Instructions

Please read all instructions before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.


- **Electrical Safety:** Do not immerse the appliance, power cord, or plug in water or other liquids. Ensure the voltage rating matches your power supply. Unplug the machine when not in use or before cleaning.
- **Hot Surfaces and Liquids:** The machine produces hot water and steam. Avoid contact with hot surfaces and liquids. Use handles and knobs.
- **Child Safety:** Keep the appliance out of reach of children. Close supervision is necessary when the appliance is used by or near children.
- **Proper Use:** Use the machine only for its intended purpose of brewing coffee and preparing milk. Do not operate with a damaged cord or plug.
- **Maintenance:** Refer to the maintenance section for proper cleaning and descaling procedures.

Components Overview

Familiarize yourself with the main parts of your Nespresso Vertuo Lattissima machine:



Water Reservoir: Removable 57 fl. oz capacity for water supply. Located at the back of the machine.



Milk Tank: Detachable 16 fl. oz tank for milk, used for frothing and milk-based recipes. Easily attaches to the side of the machine.

Brewing Head: Where the Vertuo capsule is inserted for brewing. Features a one-touch operation button.

Drip Tray: Adjustable and removable tray to accommodate various cup sizes and collect drips.

Used Capsule Container: Automatically collects used capsules after brewing.

Setup and First Use

1. **Unpacking:** Carefully remove the machine from its packaging. Retain packaging for future transport if needed.
2. **Initial Cleaning:** Wash the water reservoir, milk tank, and drip tray with warm water and mild detergent. Rinse thoroughly.
3. **Fill Water Reservoir:** Fill the water reservoir with fresh drinking water and place it back on the machine.
4. **Power On:** Plug the machine into a grounded power outlet. The machine will begin to heat up, indicated by a blinking light. It heats up in approximately 30 seconds.
5. **First Rinse Cycle:** Before first use, perform a rinse cycle. Fill the water tank, place a large container under the coffee outlet, and press the brew button. Repeat this process 2-3 times to clean the internal system.
6. **Attach Milk Tank:** If preparing milk recipes, fill the milk tank with fresh milk and attach it securely to the machine.



\$20 OF VALUE INSIDE THE BOX

Capsule tasting pack included.
Capsule assortment may vary.

Image: The Nespresso Vertuo Lattissima machine shown with a complimentary capsule tasting pack, ready for first use.

Operating Instructions

Brewing Coffee or Espresso

1. Ensure the water reservoir is filled.
2. Open the brewing head by lifting the lever.
3. Insert a Nespresso Vertuo capsule into the machine with the dome side down.
4. Close the brewing head by pushing the lever down until it locks.
5. Place a cup of appropriate size on the drip tray. The drip tray is adjustable to fit different cup heights.
6. Press the brew button. The machine will automatically recognize the capsule and brew the coffee or espresso to the optimal size and parameters.
7. Once brewing is complete, the machine will automatically eject the used capsule into the container.

Vertuo brews
espresso + coffee



Image: The Vertuo Lattissima machine demonstrating its ability to brew both espresso and coffee, with different cup sizes shown.

Preparing Milk Recipes (Cappuccino, Latte Macchiato, Milk Foam)

1. Fill the milk tank with fresh, cold milk (dairy or non-dairy). Do not exceed the 'max' fill line.
2. Attach the milk tank to the machine. Ensure it is securely connected.
3. Insert your desired Vertuo coffee or espresso capsule into the brewing head and close it.
4. Place your cup under the coffee and milk spouts.
5. Select your desired milk recipe by pressing the corresponding button on the control panel (e.g., Cappuccino, Latte Macchiato, or Milk Foam).
6. The machine will first froth and dispense the milk, then brew the coffee into your cup.
7. After use, detach the milk tank and clean it immediately.

ONE TOUCH AWAY FROM BARISTA PERFECTION

Vertuo Lattissima is a machine created specially for those who love coffee with milk.

Now you can prepare indulgent cappuccinos, lattes, and coffees at the touch of a button, across a wide range of sizes and styles.



Versatility

From dessert-inspired flavors to blends perfectly formulated to mix with milk



Three milk options

Two milk-based preparations—cappuccino and latte macchiato—and one milk foam option



Convenient coffee

A one-touch coffee and milk solution

Image: The machine's control panel and milk frother in action, illustrating the one-touch preparation of milk-based beverages.

Maintenance and Cleaning

Regular cleaning and maintenance ensure optimal performance and longevity of your Nespresso Vertuo Lattissima machine.

Daily Cleaning

- **Milk System:** After each milk preparation, detach the milk tank and rinse all components (tank, lid, milk spout) under running water. The milk tank is dishwasher safe.
- **Drip Tray and Used Capsule Container:** Empty and rinse the drip tray and used capsule container daily. Wipe down the machine exterior with a damp cloth.

Descaling

The machine has a descaling alert. When the descaling light illuminates, it's time to descale your machine to remove mineral buildup and maintain coffee quality.

1. Refer to the Nespresso descaling kit instructions for the specific procedure.
2. Typically, this involves emptying the water tank, filling it with the descaling solution and water, and running the descaling cycle as per the machine's instructions.
3. Rinse the machine thoroughly after descaling by running several cycles with fresh water.

Capsule Recycling

Nespresso capsules are fully recyclable. Participate in Nespresso's free recycling program to dispose of your used aluminum capsules responsibly.

RE-RE-RE-RECYCLE



All aluminium pods collected
by **Nespresso** are recycled.



IT'S WHAT'S INSIDE THAT COUNTS



Nespresso pods are filled with
freshly roasted ground coffee, and
hermetically sealed with aluminium
to protect the high-quality aroma
and freshness over time.

Image: Illustration highlighting the recyclability of Nespresso aluminum capsules and the origin of coffee beans.

Troubleshooting

Problem	Possible Cause	Solution
No coffee flow / Machine not brewing	Water tank empty; Machine not heated; Brewing head not properly closed; Descaling needed.	Fill water tank; Wait for machine to heat up (solid light); Ensure brewing head is fully locked; Perform descaling.
Poor milk foam quality	Milk tank or components dirty; Incorrect milk type/temperature; Milk tank not properly attached.	Clean all milk system components thoroughly; Use fresh, cold milk (preferably whole milk for best foam); Ensure milk tank is securely attached.
Machine leaking onto counter	Drip tray full or misplaced; Internal vacuum issue (as per user review).	Empty and correctly place the drip tray. <i>User tip:</i> After brewing, leave the brewing head lid open or partially latched to prevent a partial vacuum from siphoning water from the reservoir into the used pod holder.
Used capsules not ejecting	Used capsule container full; Capsule jammed.	Empty the used capsule container; Carefully check for and remove any jammed capsules.

Specifications

Feature	Detail
Brand	Nespresso
Model Name	Vertuo Lattissima
Model Number	ENV300W
Color	White
Product Dimensions (D x W x H)	16"D x 7.5"W x 12.4"H
Item Weight	14 pounds
Coffee Maker Type	Espresso Machine
Operation Mode	Fully Automatic
Voltage	120 Volts
Water Reservoir Capacity	57 fl. oz (approx.)
Milk Tank Capacity	16 fl. oz
Heat-up Time	30 seconds
Special Features	Auto Shut-Off, Milk Frother, One-button Operation, Descaling Alert
Compatible Capsules	Nespresso Vertuo capsules only
Country of Origin	Hungary
UPC	044387303002

Warranty and Support

Your Nespresso Vertuo Lattissima machine comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions.

For further assistance, troubleshooting, or to order Nespresso Vertuo capsules and accessories, please visit the official Nespresso website or contact Nespresso customer support.

Nespresso also offers a free recycling program for its aluminum capsules, contributing to environmental sustainability.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C5KP15DK>

More documents and user manuals: **<https://manuals.plus/>**