

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [HOCO](#) /

› [HOCO E64 Mini Wireless Bluetooth Headset User Manual](#)

## HOCO E64

# HOCO E64 Mini Wireless Bluetooth Headset

## USER MANUAL

### Introduction

Thank you for choosing the HOCO E64 Mini Wireless Bluetooth Headset. This manual provides essential information for the safe and efficient use of your new device. Please read it carefully before use and retain it for future reference.

### Safety Information

- Do not disassemble, repair, or modify the product. This may cause fire, electronic breakdown, or complete product damage.
- Keep the device away from water, moisture, and other liquids.
- Avoid exposing the device to extreme temperatures (below 0°C or above 45°C).
- Do not use the device during charging.
- Keep out of reach of children.
- Dispose of the product responsibly according to local regulations.

### Package Contents

Please check the package for the following items:

- 1 x HOCO E64 Mini Wireless Bluetooth Headset
- 1 x Charging Cable
- Multiple Ear Tips (various sizes)
- 1 x User Manual

### Product Overview

The HOCO E64 is a compact, single-sided wireless Bluetooth headset designed for clear communication and audio playback. It features a multi-function touch control button and a built-in microphone.



Figure 1: HOCO E64 Mini Wireless Bluetooth Headset, showing the charging port.



Figure 2: HOCO E64 earbud in use with a smartphone, demonstrating its compact size.



Figure 3: HOCO E64 product packaging, front and back views.

## Setup

### 1. Charging the Headset

Before first use, fully charge the headset. The battery capacity is 50 mAh, and a full charge takes approximately 50 minutes.

1. Connect the charging cable to the charging port on the headset (refer to Figure 1).
2. Connect the other end of the charging cable to a USB power source (e.g., computer, wall adapter).
3. The indicator light will show charging status (refer to product packaging or quick start guide for specific light behavior).
4. Once fully charged, disconnect the headset from the power source.

### 2. Pairing with a Device

The HOCO E64 uses Bluetooth 5.3 for a stable connection.

1. Ensure the headset is charged and turned off.

2. Press and hold the multi-function button on the headset until the indicator light flashes rapidly (usually blue and red alternately), indicating it is in pairing mode.
3. On your smartphone or other Bluetooth-enabled device, go to the Bluetooth settings.
4. Search for available devices and select "HOCO E64" from the list.
5. Once connected, the indicator light on the headset will typically flash slowly or turn off.
6. If prompted for a password, enter "0000" (four zeros).

## Operating Instructions

---

### Power On/Off

- **Power On:** Press and hold the multi-function button for approximately 3 seconds until you hear a power-on prompt or see the indicator light.
- **Power Off:** Press and hold the multi-function button for approximately 5 seconds until you hear a power-off prompt or see the indicator light turn off.

### Music Playback

- **Play/Pause:** Single-tap the multi-function button.
- **Next Track:** Double-tap the multi-function button.
- **Previous Track:** Triple-tap the multi-function button.

### Call Management

- **Answer/End Call:** Single-tap the multi-function button during an incoming call or active call.
- **Reject Call:** Press and hold the multi-function button for approximately 2 seconds during an incoming call.
- **Redial Last Number:** Double-tap the multi-function button when not on a call.

### Language Switch

To switch between Chinese and English voice prompts:

- When the headset is not paired with any device, double-click the multi-function button to cycle through available languages.

### Maintenance

---

- Clean the headset regularly with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Store the headset in a cool, dry place when not in use.
- Avoid dropping or subjecting the headset to strong impacts.
- Do not expose the charging port to dust or debris.

### Troubleshooting

---

Problem	Possible Solution
Headset does not power on.	Ensure the headset is fully charged. Press and hold the multi-function button for a longer duration.

Problem	Possible Solution
Cannot pair with device.	Ensure the headset is in pairing mode (flashing indicator light). Turn off and on your device's Bluetooth. Move the headset closer to the device.
No sound during playback/calls.	Check the volume level on both the headset and your connected device. Ensure the headset is properly paired.
Poor sound quality.	Ensure the headset is within range of your device. Avoid obstacles between the headset and device. Check for interference from other wireless devices.

## Specifications

Feature	Detail
Model Name	E64
Material	Acrylonitrile Butadiene Styrene (ABS)
Dimensions (L x W x H)	26 x 17 x 24 mm
Item Weight	4.5 grams
Bluetooth Version	5.3
Bluetooth Chip	JL AC6983D
Battery Capacity	50 mAh
Charging Time	Approximately 50 minutes
Talk/Music Time	Up to 10 hours
Standby Time	Up to 100 hours
Connectivity Technology	Wireless (Bluetooth)
Compatible Devices	Tablets, Phones, Mobile phones
Control Type	Media Control, Touch Control
Special Features	Includes Microphone
Water Resistance Level	Not water resistant
Ear Placement	In Ear
Noise Control	None

## Warranty Information

This product is covered by a standard manufacturer's warranty. Please refer to the warranty card included in your package or contact your retailer for specific warranty terms and conditions. The warranty typically

covers defects in materials and workmanship under normal use.

## **Customer Support**

---

For further assistance, technical support, or warranty claims, please contact the retailer where you purchased the product. You may also visit the official HOCO website for more information and support resources.