Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Zymise JYTC05

Zymise Neck Fan Air Conditioner User Manual

Model: JYTC05

Introduction

The Zymise Neck Fan Air Conditioner (Model JYTC05) is a portable, wearable cooling device designed to provide personal comfort in various environments. It integrates a cooling plate, powerful airflow, and a large capacity rechargeable battery, offering a convenient and effective solution for staying cool on the go. This manual provides essential information for the safe and efficient operation of your device.



Image: The Zymise Neck Fan Air Conditioner in Deep Blue, showcasing its ergonomic design and cooling vents.

Product Features

- **Cooling Plate & Instant Cooling:** Features a built-in refrigerating chip and aluminum cold plate for rapid cooling, achieving temperatures 50℉-54℉ lower than ambient.
- **Powerful Airflow with 5 Turbines:** Equipped with 5 air vents and 5 turbines, providing 360° powerful airflow and double the rotation speed of traditional fans.
- **10000mAh Battery & 3 Modes:** Includes a large capacity 10000 mAh battery with three adjustable speed modes (soft, medium, high) for customized comfort.
- **Ergonomic & Lightweight Design:** Made with soft silicone material, adjustable to fit various neck sizes, and weighs approximately 0.88 LB for comfortable, hands-free wear.
- **Low Noise & Wide Application:** Designed with a multi-stage air duct to significantly reduce fan noise, making it suitable for office use, travel, camping, and household chores.



Image: An illustrative diagram highlighting the internal components of the Zymise Neck Fan, including the cooling plate, turbo fans, high-capacity battery, and easy-to-use buttons.

Package Contents

Please check the box for the following items:

- 1 x Zymise Neck Fan Air Conditioner (Model JYTC05)
- 1 x USB Type-C Charging Cable
- 1 x User Manual



Image: The Zymise Neck Fan Air Conditioner, its packaging box, and the included USB Type-C charging cable, demonstrating the complete package contents.

Setup Guide

1. Charging the Device

1. Locate the Type-C charging port on the device.
2. Connect the provided USB Type-C charging cable to the device and a compatible USB power adapter (not included).
3. The indicator light will show charging status (refer to the device's specific light indicators for full charge). A full charge typically takes 2-2.5 hours.

2. Wearing the Neck Fan

1. Gently open the neck fan to fit around your neck. The soft silicone material allows for adjustment to various neck sizes.
2. Position the fan so that the air vents are directed towards your face and neck for optimal cooling.

Operating Instructions

Power On/Off

Press and hold the power button (usually marked with a power symbol) for 2-3 seconds to turn the device on or off.

Adjusting Fan Speed

Once powered on, short press the fan speed button (often indicated by a fan icon) to cycle through the three available fan speeds: Soft, Medium, and High. The indicator lights may change to reflect the current speed setting.

Activating Cooling Plate

To activate the cooling plate feature, press the dedicated cooling mode button (if available, or it might be integrated with the power/fan button). The cooling plate will begin to chill the back of your neck, providing an additional cooling sensation.

Your browser does not support the video tag.

Video: This video demonstrates the Zymise Neck Fan Air Conditioner in various usage scenarios, including during sports, office work, and cooking, highlighting its portability and cooling effectiveness.

Specifications




Image: A visual representation of the product specifications, including battery capacity, charging time, net weight, fan modes, and cooling modes.

Feature	Detail
Brand	Zymise
Model Name	JYTC05
Color	Deep Blue
Electric Fan Design	Wearable Fan
Power Source	Battery Powered
Product Dimensions	7.08"D x 8.66"W x 1.9"H
Item Weight	0.88 Pounds (14.1 ounces)
Wattage	5 watts
Control Method	Touch
Blade Material	Plastic
Reusability	Rechargeable
Number of Power Levels	3
Batteries	2 Lithium Ion batteries required (included)
Recommended Uses	Office work, driving, traveling, camping, doing housework

Maintenance and Care

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the device. Do not use harsh chemicals or abrasive cleaners. Ensure the device is powered off and unplugged before cleaning.
- **Storage:** Store the neck fan in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in constant use.
- **Avoid Water:** This device is not waterproof. Avoid exposing it to water or high humidity to prevent damage.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Low battery; Power button not pressed correctly.	Charge the device fully. Press and hold the power button for 2-3 seconds.
Weak airflow.	Low battery; Fan speed set too low; Vents obstructed.	Recharge the device. Increase the fan speed. Ensure vents are clear of debris.
Cooling plate not cooling.	Cooling mode not activated; Device not fully charged.	Ensure the cooling mode button is pressed. Charge the device.

Problem	Possible Cause	Solution
Device not charging.	Faulty cable or adapter; Loose connection.	Try a different USB Type-C cable and power adapter. Ensure the cable is securely connected to both the device and the power source.

Warranty and Support

For warranty information, technical support, or any inquiries regarding your Zymise Neck Fan Air Conditioner, please refer to the contact details provided on the product packaging or contact the seller directly. Keep your purchase receipt for warranty claims.

© 2023 Zymise. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C5LJJPQ3

More documents and user manuals: **https://manuals.plus/**