

Manuals.plus /

› AULCMEET /

› AULCMEET N2QAYC000123 Remote Control User Manual for Panasonic Sound Bars

AULCMEET N2QAYC000123

AULCMEET N2QAYC000123 Remote Control User Manual for Panasonic Sound Bars

Model: N2QAYC000123

1. INTRODUCTION

This manual provides comprehensive instructions for the AULCMEET N2QAYC000123 infrared remote control. It is designed as a replacement for various Panasonic Sound Bar models. Please read this manual carefully to ensure proper use and to understand the features and functions of your new remote control.

2. PRODUCT OVERVIEW

The AULCMEET N2QAYC000123 is an infrared replacement remote control, specifically designed for compatibility with Panasonic Sound Bar systems. It requires no programming or complex setup, offering immediate functionality upon battery insertion.

Key Features:

- **No Setup Required:** Functions immediately with compatible devices.
- **Ergonomic Design:** Comfortable to hold and operate.
- **Durable Construction:** Made from robust ABS material.
- **Responsive Buttons:** Soft and durable buttons with good elasticity for sensitive operation.
- **Infrared Technology:** Ensures reliable signal transmission.

Compatible Panasonic Sound Bar Models:

- SC-HTB200EGK, SC-HTB200EBK, SC-HTB200
- SC-HTB258, SC-HTB250
- SC-HTB208, SC-HTB208EB-K
- SC-HTB200EB-K, SC-HTB200EG-K
- SC-HTB208EBK, SCSHTB200EBK, SCSHTB200EGK, SCSHTB200GNK



DIMMER

SOUND

+
VOL
▲
—

MUTE

HDMI(ARC)

OPTICAL



—PAIRING

Figure 2.1: Front view of the AULCMEET N2QAYC000123 remote control, showing the power button, volume controls, and input selection buttons.

3. SETUP

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely.

Note: This remote control operates using infrared technology and does not require any programming or pairing with your Panasonic Sound Bar. Once batteries are installed, it is ready for use.



Figure 3.1: Back view of the remote control, showing the battery compartment.

4. OPERATING INSTRUCTIONS

To operate your Panasonic Sound Bar, point the remote control directly towards the sound bar's infrared receiver. Ensure there are no obstructions between the remote and the sound bar.

Button Functions:



Figure 4.1: Detailed view of the remote control buttons.

- **Power Button** (): Turns the sound bar on or off.
- **VOL + / -**: Increases or decreases the volume level.
- **MUTE**: Mutes or unmutes the sound.
- **DIMMER**: Adjusts the brightness of the sound bar's display.
- **SOUND**: Cycles through various sound modes or settings.
- **HDMI(ARC)**: Selects the HDMI ARC input source.
- **OPTICAL**: Selects the Optical input source.
- **- PAIRING**: Initiates Bluetooth pairing mode for compatible sound bars.

5. MAINTENANCE

5.1 Cleaning the Remote Control

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as these can damage the remote's finish or internal components.

5.2 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type (AAA). Do not mix old and new batteries, or different types of batteries, as this can lead to leakage or malfunction.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote control not working.	Dead or incorrectly inserted batteries.	Check battery orientation. Replace batteries with new ones.
Limited range or intermittent response.	Obstruction between remote and sound bar; weak batteries.	Ensure a clear line of sight. Replace batteries.
Specific button not responding.	Button malfunction or sound bar not in correct mode.	Ensure the sound bar is powered on and in a state where the button function is applicable. If problem persists, contact support.

7. SPECIFICATIONS

- **Brand:** AULCMEET
- **Model:** N2QAYC000123
- **Connectivity Technology:** Infrared (IR)
- **Compatible Devices:** Panasonic Sound Bars (specific models listed in Section 2)
- **Power Source:** 2 x AAA Batteries (not included)
- **Product Dimensions:** 16 x 4 x 1 cm
- **Item Weight:** 30 g
- **Maximum Range:** 10 Meters
- **Material:** ABS
- **Color:** Black

8. WARRANTY AND SUPPORT

This AULCMEET remote control comes with a **3-month free refund guarantee**. If you encounter any issues or have questions regarding the compatibility or functionality of your remote control, please contact the seller or manufacturer's customer service for assistance.

For further support, please refer to the contact information provided with your purchase or visit the AULCMEET

official support channels.