

Raybee 4D1HZX

Raybee Freestanding Clothes Rack with 4 Drawers and Shelves

Model: 4D1HZX

Brand: Raybee

1. INTRODUCTION

Thank you for choosing the Raybee Freestanding Clothes Rack. This heavy-duty clothing rack is designed to provide versatile storage for your garments and accessories, featuring a hanging rod, adjustable shelves, and four fabric drawers. Its sturdy metal construction ensures durability, while the thoughtful design allows for flexible configuration to suit various spaces and needs. Please read this manual carefully before assembly and use to ensure proper installation and safe operation.

2. SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the unit on a soft, clean surface to prevent scratches.
- Do not overload the rack. Refer to the 'Specifications' section for maximum load capacities.
- Keep children and pets away from the assembly area.
- For added stability, utilize the provided anti-fall locks to secure the rack to a wall, especially if placed in high-traffic areas or if heavy items are stored on upper shelves.
- Adjust the leveling feet to ensure the rack is stable and level on uneven floors.

3. PACKAGE CONTENTS

Please verify that all components listed below are included in your package:

- Metal Poles (various lengths)
- Wire Shelves (top, middle, bottom)
- Hanging Rod
- Fabric Drawers (x4)
- Plastic Clips (for shelf installation)
- Adjustable Leveling Feet
- Anti-fall Locks (x2)
- Assembly Tool (screwdriver)
- Instruction Manual

4. SETUP AND ASSEMBLY

Assembly of the Raybee Clothes Rack is designed to be straightforward and typically takes less than 10 minutes, utilizing a slip-sleeve locking system without the need for bolts, screws, or nuts for the main frame. A screwdriver is provided for attaching drawer handles.

Assembly Steps:

1. **Install Clips on Poles:** Locate the grooves on the metal poles. Snap two plastic clips together around each pole at your desired shelf height. Ensure the clips are at the same height on all poles for a level shelf. Do not lock clips on double grooves.
2. **Attach Shelves:** Slide the wire shelves down over the poles until they firmly rest on the installed plastic clips. You should hear a 'ting' sound when it's perfectly locked.
3. **Install Hanging Rod:** Secure the hanging rod between the designated poles at the upper section of the rack.
4. **Prepare Drawers:** Unfold the fabric drawers and insert the bottom panel to create a sturdy base. Attach the handles using the provided screwdriver.
5. **Insert Drawers:** Place the assembled fabric drawers onto the lower wire shelves.
6. **Adjust Leveling Feet:** Turn the adjustable feet at the bottom of the poles to stabilize the rack on uneven surfaces.
7. **Secure with Anti-fall Locks:** For enhanced safety, especially in homes with children or pets, use the anti-fall locks to secure the rack to a wall.

01

Q: What is the overall size of the product?

A: 71"H x 35.8"W x 15.7"D.

02

Q: Are there 4 drawers included in the item?

A: Yes.

03

Q: Can the height of the shelf be adjusted?

A: Yes.

04

Q: Does it fit next to the washer or dryer?

A: Yes. Portable size is suitable for any corner where more storage space is needed.

Figure 4.1: Visual guide for installing clips and shelves.



Figure 4.2: Example configurations for the adjustable clothes rack.

Your browser does not support the video tag.

Video 4.1: This video demonstrates the assembly process and shows the rack being set up with its drawers and hanging clothes.

5. OPERATING INSTRUCTIONS

The Raybee Clothes Rack offers versatile storage options to keep your items organized.

Using the Hanging Rod:

The upper hanging rod is ideal for clothes that require hanging, such as dresses, coats, shirts, and pants, to prevent wrinkles. The special heightening design accommodates longer garments.

Utilizing the Shelves:

- **Top Shelf:** Use the top shelf for storing boxes, luggage, or other larger items to maximize vertical space.
- **Adjustable Shelves:** The metal shelf height can be adjusted in 1-inch increments to customize your storage layout. This allows you to create space for more boxes, suitcases, or to adjust the hanging area.

Using the Fabric Drawers:

The four folding fabric drawers are perfect for organizing smaller items such as pants, socks, underwear, and accessories. They are designed for easy installation and smooth operation.



Figure 5.1: Fabric drawers showcasing their capacity for various items.

Your browser does not support the video tag.

Video 5.1: This video highlights the depth and capacity of the four fabric drawers, demonstrating how various items can be stored efficiently.

Your browser does not support the video tag.

Video 5.2: This video demonstrates the sturdiness of the drawers, showing they can hold heavy items like books without deforming.



Figure 5.2: The clothes rack in a bedroom, demonstrating its full storage potential.

6. MAINTENANCE

To ensure the longevity and appearance of your Raybee Clothes Rack, follow these simple maintenance guidelines:

- **Cleaning the Metal Frame:** Wipe the metal frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish. Dry immediately to prevent rust.
- **Cleaning Fabric Drawers:** The fabric drawers can be spot cleaned with a mild detergent and a damp cloth. Allow them to air dry completely before returning them to the rack. Do not machine wash or tumble dry.
- **Regular Checks:** Periodically check all connections and ensure the shelves are securely seated on the clips. Re-tighten any loose components if necessary.

7. TROUBLESHOOTING

If you encounter any issues with your clothes rack, please refer to the following common solutions:

- **Rack is Unstable/Wobbly:**

- Ensure all plastic clips are installed at the same height on each pole and that shelves are fully seated.
- Adjust the leveling feet at the bottom of the poles to compensate for uneven flooring.
- Verify that the anti-fall locks are properly installed and secured to a wall if applicable.

- **Shelves are Not Level:**

- Recheck the placement of the plastic clips on the poles. They must be aligned perfectly at the same height for each corner of the shelf.

- **Drawers are Difficult to Open/Close:**

- Ensure the drawers are not overloaded.
- Check that the drawer's bottom panel is fully inserted and flat.
- Verify that the rack frame is square and level.

8. SPECIFICATIONS

Brand	Raybee
Model Number	4D1HZX
Product Dimensions (D x W x H)	15.7" x 35.8" x 71"
Material	Metal (Frame), Fabric (Drawers)
Color	Black (Frame), Grey (Drawers)
Total Load Capacity	435 lbs
Shelf Load Capacity	94 lbs (per shelf)
Hanging Rod Load Capacity	73 lbs
Number of Drawers	4
Installation Type	Free Standing
Assembly Required	Yes (approx. 10 minutes)
Special Features	Adjustable Shelves, Anti-fall Locks, Adjustable Feet, Portable, Heavy Duty, Rust-Proof, Scratch Resistant



Figure 8.1: Product dimensions and load capacities.

9. WARRANTY AND SUPPORT

Raybee is committed to providing high-quality products. While specific warranty details are not provided in this manual, please retain your proof of purchase. For any product-related inquiries, missing parts, or support needs, please contact Raybee customer service through the retailer where the product was purchased or visit the official Raybee website for contact information.