

[Manuals.plus](#) /

> [Hiaksedt](#) /

> Hiaksedt Baby Playpen with Mat (50x50 inch) - Instruction Manual

## Hiaksedt BWL001

# Hiaksedt Baby Playpen with Mat (50x50 inch) - Instruction Manual

Model: BWL001

## 1. INTRODUCTION

This manual provides comprehensive instructions for the safe assembly, operation, and maintenance of your Hiaksedt Baby Playpen with Mat. Please read all instructions carefully before use and retain this manual for future reference. This playpen is designed to provide a secure and engaging play area for babies and toddlers, promoting independent play while offering parents peace of mind.



*Image: Mother and baby enjoying the spacious Hiaksedt playpen.*

## 2. SAFETY INFORMATION

**WARNING: Infants can suffocate.**

- In gaps between a mattress too small or too thick and product sides.

- On soft bedding.
- NEVER add a mattress, pillow, comforter, or padding.
- Always ensure the playpen is fully assembled and all connections are secure before placing a child inside.
- Do not leave children unattended in the playpen.
- Keep small items and choking hazards out of reach.
- Ensure the playpen is placed on a flat, stable surface away from stairs, windows, and other potential hazards.
- The playpen is constructed with non-toxic fabric and stainless steel for durability and safety.



*Image: Visual comparison of a safe playpen environment versus hazardous home areas.*

### 3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- Fabric Playpen Enclosure (with mesh sides and padded top rails)
- Stainless Steel Tubes (various lengths for frame construction)
- Plastic Connectors (for assembling the frame)
- Play Mat (50x50 inch, included)
- Anti-Skid Suction Cups (for base stability)
- Instruction Manual

### 4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly typically takes 5-10 minutes. No tools are required.

1. Unpack all components and lay them out on a clean, flat surface.
2. Connect the stainless steel tubes using the plastic connectors to form the base frame. Ensure all connections are secure.
3. Insert the vertical tubes into the base connectors and then attach the upper connectors and top rails.

4. Slide the fabric playpen enclosure over the assembled frame, ensuring the mesh sides are taut and the padded top rails cover the frame.
5. Secure the fabric to the frame using any integrated Velcro straps or fasteners.
6. Place the included play mat inside the playpen.
7. Attach the anti-skid suction cups to the bottom of the playpen frame for enhanced stability.

*Video: Demonstrating the easy assembly of the playpen, highlighting the connection points and overall structure.*



*Image: Detailed view of the playpen's construction and safety features.*

## 5. OPERATING INSTRUCTIONS

- **Creating a Safe Play Area:** The playpen provides a designated space for your child to play independently. The 50x50 inch dimensions offer ample room for movement and toys.
- **360° Visibility:** The transparent mesh sides allow for full visibility of your child from any angle, ensuring constant supervision.

- **Zipper Door Access:** The playpen features a convenient zipper door for easy entry and exit. This allows children to crawl in and out as they grow, or for parents to join them inside. Ensure the zipper is fully closed when you need to contain your child.
- **External Storage Pocket:** Utilize the external mesh pocket for storing small essentials like wipes, pacifiers, or small toys, keeping them within easy reach but outside the play area.

## 360° Visibility Playpen Keep Baby Stay Safety



*Image: Baby enjoying the playpen with clear visibility through the mesh.*

## Avoid Hazardous Environments



*Image: Demonstrating the convenient zipper door for child access.*

## 6. MAINTENANCE AND CARE

- **Cleaning:** The fabric and mesh materials can be wiped clean with a damp cloth and mild soap. Allow to air dry completely.
- **Mat Care:** The included play mat is washable. Refer to the mat's specific care instructions for best results.
- **Inspection:** Regularly inspect all parts for wear, damage, or loose connections. Discontinue use if any part is broken or missing.
- **Storage:** If disassembling for storage, ensure all components are clean and dry. Store in a cool, dry place away from direct sunlight.

## 7. TROUBLESHOOTING

- **Playpen feels unstable:** Ensure all stainless steel tubes are fully inserted into their respective plastic connectors. Verify that the anti-skid suction cups are properly attached to the bottom frame and are making good contact with the floor.
- **Fabric is loose:** Check that the fabric is correctly aligned with the frame and all Velcro or other fasteners are securely attached.
- **Difficulty zipping/unzipping:** Ensure the fabric around the zipper is not caught. Apply a small amount of zipper lubricant if necessary.

## 8. SPECIFICATIONS

- **Product Dimensions:** 50 x 50 x 26 inches (L x W x H)
- **Inner Size:** 49 x 49 inches
- **Item Model Number:** BWL001
- **Material Type:** Fabric (non-toxic, skin-friendly), Stainless Steel (201 grade)
- **Item Weight:** 9.15 pounds
- **Age Range (Description):** Kid (suitable for babies and toddlers)
- **Certifications:** CPC Certified, CPSIA Certified

## 27 Inch High Fence Prevent Baby Under 40 Inch



Image: Playpen with key dimensions indicated.

### 9. WARRANTY AND SUPPORT

For any questions, concerns, or warranty claims regarding your Hiaksedt Baby Playpen, please contact the manufacturer directly through their official support channels. Please refer to your purchase documentation for specific warranty terms and contact information.