



Manuals.plus /

› Zyyini /

› Zyyini Big Tongue Shaped Fixed Telephone User Manual

Zyyini Zyyinip73f4uncxm

Zyyini Big Tongue Shaped Fixed Telephone User Manual

Model: Zyyinip73f4uncxm

1. INTRODUCTION

Thank you for choosing the Zyyini Big Tongue Shaped Fixed Telephone. This unique corded telephone combines a distinctive design with essential communication features. This manual provides detailed instructions for proper setup, operation, and maintenance to ensure optimal performance.

Package Contents

- 1 x Zyyini Big Tongue Shaped Corded Telephone
- 1 x Telephone Line Cord
- 1 x Instruction Manual (this document)

2. SETUP

The Zyyini Big Tongue Shaped Fixed Telephone is designed for simple "Plug and Play" installation. Follow these steps to set up your telephone:

2.1 Connecting the Telephone Line

1. Locate the telephone line port on the bottom of the telephone base.
2. Insert one end of the provided telephone line cord into this port.
3. Insert the other end of the telephone line cord into your wall telephone jack.




Image: Bottom view of the Zyyini telephone, highlighting the telephone line port for connection to the wall jack.

2.2 Connecting the Handset

1. Locate the coiled cord. One end is typically pre-attached to the handset.
2. Insert the other end of the coiled cord into the designated handset port on the telephone base.



Image: Top view of the Zyyini telephone, showing the keypad and the connection point for the handset's coiled cord.

Your telephone is now ready for use.

3. OPERATION

This section details the basic functions and special features of your Zyyini telephone.

3.1 Making a Call

1. Lift the handset from the base.
2. Listen for a dial tone.
3. Dial the desired telephone number using the keypad.
4. Once the call is complete, place the handset back on the base to hang up.

3.2 Receiving a Call

1. When the telephone rings, lift the handset to answer the call.
2. To end the call, place the handset back on the base.

3.3 Special Functions

The telephone includes several useful functions:

- **Number Storage:** Allows you to save frequently dialed numbers. (Specific instructions for programming are not provided in the product details; refer to the included manual for detailed steps if available.)

- **Flash Break Line Pickup:** Used for accessing network services or transferring calls (if supported by your telephone service provider).
- **Dialing Pause:** Inserts a pause during dialing, useful for accessing extensions or specific services.
- **Redial:** Press the "REDIAL" button to automatically dial the last number called.
- **Ringtone Switch:** Allows adjustment of the ringtone. (Specific controls for this function are not detailed in the product information.)



Image: Close-up of the telephone keypad, showing number buttons and function buttons like PAUSE, FLASH, and REDIAL.

4. MAINTENANCE

Proper care will extend the life of your telephone.

- **Cleaning:** Wipe the telephone surface with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Placement:** Place the telephone on a stable, flat surface. Avoid direct sunlight, excessive heat, or moisture.
- **Handling:** Handle the telephone and its cords gently to prevent damage.

5. TROUBLESHOOTING

If you encounter issues with your telephone, try the following solutions:

- **No Dial Tone:**
 - Ensure the telephone line cord is securely connected to both the telephone and the wall jack.
 - Test the wall jack with another working telephone, if available, to confirm the line is active.
- **Unclear Sound / Static:**
 - Check all cable connections for tightness.
 - Ensure the handset cord is securely connected.
 - Avoid placing the telephone near other electronic devices that might cause interference.
- **Telephone Not Ringing:**
 - Verify that the ringtone switch (if present and accessible) is not set to silent or off.
 - Confirm the telephone line is active.

If problems persist, contact customer support or your telephone service provider.

6. SPECIFICATIONS

Brand	Zyyini
Model	Zyyinip73f4uncxm
Power Source	Wired Electric
Batteries Required	No
Material Type	Plastic
Dimensions (Package)	20.3 x 14.1 x 10.5 cm
Weight (Package)	490 g
Caller ID	No
Visual Function	No

7. WARRANTY AND SUPPORT

Information regarding specific warranty terms or dedicated customer support contact details is not provided in the product description. Please refer to the packaging or your purchase receipt for any warranty information or contact the retailer where the product was purchased for support inquiries.