

SUPERLEX Dampfreiniger

SUPERLEX 12-in-1 1500W Multifunction Steam Cleaner User Manual

Model: Dampfreiniger

INTRODUCTION

The SUPERLEX 12-in-1 1500W Multifunction Steam Cleaner provides hygienic deep cleaning without the need for harmful chemicals. This versatile appliance can be used as an upright steam mop or a portable handheld steamer, featuring an ergonomic flexible hinge for reaching under furniture. With a 380 ml water tank, it delivers up to 15 minutes of continuous steam, making it suitable for various cleaning tasks.

Please read this manual thoroughly before operating the appliance and retain it for future reference.

SAFETY INSTRUCTIONS

- Always ensure the appliance is unplugged before filling with water, cleaning, or performing maintenance.
- Do not immerse the steam cleaner in water or any other liquid.
- Keep the appliance out of reach of children and pets.
- Use only distilled or demineralized water to prevent mineral buildup and prolong the life of the appliance.
- Do not direct steam at people, animals, or electrical appliances.
- Exercise caution when using the steam cleaner on delicate surfaces. Test on an inconspicuous area first.
- Ensure the water tank cap is securely closed before operating.

COMPONENTS AND ACCESSORIES

The SUPERLEX 12-in-1 Steam Cleaner comes with a range of accessories to tackle various cleaning needs:

- Main Steam Unit (Upright/Handheld)
- Angled Nozzle
- Straight Nozzle
- 2 Mop Heads
- Grout Tool
- Scraper Tool
- Carpet Glider
- 2 Brushes
- Garment/Upholstery Steamer Cloth
- Window/Mirror Cleaning Accessories
- Measuring Cup (for filling water)



Image: The SUPERLEX 12-in-1 Steam Cleaner shown with its main unit and a selection of included accessories, highlighting its versatility for both floor and handheld cleaning tasks.

SETUP

1. **Unpacking:** Carefully remove all components from the packaging. Check for any damage.
2. **Assembly (Upright Mode):**
 - Attach the handle to the main body of the steam cleaner until it clicks into place.
 - Securely attach the desired mop head to the base of the unit.
 - Place a clean microfiber cloth onto the mop head, ensuring it is properly secured.
3. **Assembly (Handheld Mode):**
 - Detach the main body from the handle and floor head.
 - Attach the desired accessory (e.g., angled nozzle, brush) directly to the handheld unit.
4. **Filling the Water Tank:**
 - Ensure the appliance is unplugged.
 - Unscrew the water tank cap.
 - Using the provided measuring cup, fill the 380 ml tank with distilled or demineralized water. Do not overfill.
 - Securely replace the water tank cap.



Image: The main unit of the SUPERLEX 12-in-1 Steam Cleaner, illustrating its upright configuration for floor cleaning.

OPERATING INSTRUCTIONS

1. **Power On:** Plug the steam cleaner into a suitable electrical outlet (230V). The indicator light will illuminate.
2. **Heating Time:** Allow approximately 30 seconds for the water to heat up and produce steam. The indicator light may change or turn off when ready.
3. **Steam Control:** Adjust the variable steam control according to the surface being cleaned and the desired steam intensity.
4. **Cleaning Surfaces:**
 - **Floors (Upright Mode):** Move the steam mop slowly and steadily across the floor surface. For stubborn stains, hold the mop over the area for a few seconds.
 - **Handheld Cleaning:** Direct the steam from the attached accessory onto the target area. Use brushes for scrubbing and the scraper tool for tough residue.
 - **Garments/Upholstery:** Use the garment steamer cloth attachment and hold the steamer a few inches away from the fabric, moving it gently.
 - **Windows/Mirrors:** Attach the window cleaning accessory and wipe the surface with steam, then use a clean cloth to remove excess moisture.

5. **Refilling:** If steam production stops, unplug the unit, allow it to cool for a few minutes, and then refill the water tank as described in the Setup section.
6. **Power Off:** When finished, unplug the appliance from the power outlet.



Image: The SUPERLEX steam cleaner in its handheld configuration, demonstrating its use with a nozzle for targeted cleaning.

MAINTENANCE

- **Cleaning the Unit:** After each use, ensure the unit is unplugged and cooled. Wipe the exterior with a damp cloth.
- **Emptying the Water Tank:** Always empty any remaining water from the tank after use to prevent mineral buildup.
- **Cleaning Accessories:** Wash mop cloths and other washable accessories with mild detergent and allow them to air dry. Clean nozzles and brushes as needed.
- **Descaling (Periodic):** If you notice reduced steam output or mineral residue, descale the unit. Consult the manufacturer's website or contact support for specific descaling instructions.
- **Storage:** Store the steam cleaner in a cool, dry place, away from direct sunlight and out of reach of children.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam production	Water tank empty; Unit not plugged in; Unit not heated sufficiently; Mineral buildup.	Refill water tank; Check power connection; Allow adequate heating time (approx. 30 seconds); Perform descaling.
Low steam output	Low water level; Mineral buildup; Clogged nozzle.	Refill water tank; Perform descaling; Clean or replace nozzle.
Water leaking from unit	Water tank cap not secured; Overfilled water tank; Damaged seal.	Ensure cap is tightly closed; Do not overfill; Contact customer support if seal is damaged.
Appliance not turning on	No power; Faulty power cord/plug.	Check power outlet; Inspect power cord for damage. If damaged, do not use and contact support.

If the problem persists after attempting these solutions, please contact SUPERLEX customer support.

SPECIFICATIONS

- **Model Name:** Multifunktional Dampfreiniger
- **Item Model Number:** Dampfreiniger
- **Brand:** SUPERLEX
- **Power:** 1500 Watts
- **Voltage:** 230 Volts
- **Water Tank Volume:** 380 Milliliters
- **Power Source:** Corded Electric
- **Special Feature:** Portable, 12-in-1 Functionality
- **Surface Recommendation:** Tile, Hardwood, Floors
- **Dimensions (Package):** 48 x 20 x 18 cm
- **Weight (Package):** 2.8 kilograms

WARRANTY AND SUPPORT

For warranty information, product registration, or technical support, please refer to the warranty card included with your purchase or visit the official SUPERLEX website. Please have your model number (Dampfreiniger) and purchase date available when contacting support.

VIDEO RESOURCES

No official product videos were found in the provided data. For visual guides or demonstrations, please check the manufacturer's official website or support channels.