

TAURUS 24132021

TAURUS Aroma De Cafe Automatic Coffee Maker (Model 24132021) User Manual

Your guide to perfect coffee, every time.

[Introduction](#) [Safety](#) [Overview](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty](#)
& [Support](#)

1. INTRODUCTION

Welcome to the TAURUS Aroma De Cafe Automatic Coffee Maker experience. This appliance is designed to provide a convenient and high-quality coffee brewing process in your home. Featuring an integrated coffee bean grinder, a touch panel interface, and Wi-Fi connectivity, this machine allows for personalized coffee preparation.

This manual provides essential information for the safe and efficient use of your new coffee maker. Please read it thoroughly before first use and retain it for future reference.



Image 1.1: TAURUS Aroma De Cafe Coffee Maker branding.

2. IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, and/or injury, basic safety precautions should always be followed when using electrical appliances. These include:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.

- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
- Do not use appliance for other than intended use.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your TAURUS Aroma De Cafe coffee maker.



Image 3.1: Front view of the coffee maker, showing the touch display and dispensing area.



Image 3.2: Angled view of the coffee maker, illustrating its compact design on a countertop with two prepared coffee cups.



Image 3.3: Detailed view of the intuitive touch screen display, showing various coffee selections like Espresso, Americano, Lungo, Cappuccino, Latte Macchiato, and Latte Coffee.



Image 3.4: Exploded view of the milk frother components, including the lid, frothing mechanism, and milk container.



Image 3.5: The transparent water tank with a 'MAX' fill line, indicating its capacity and ease of monitoring water levels.



Image 3.6: The integrated coffee bean grinder compartment, filled with fresh coffee beans, ready for grinding.

Key Components:

- **Touch Panel Display:** For selecting drink types and adjusting settings.
- **Integrated Coffee Grinder:** Grinds fresh beans for each brew.
- **Water Tank:** Removable for easy refilling.
- **Milk Frother:** For preparing milk-based coffee drinks.
- **Drip Tray:** Collects excess liquid and removable for cleaning.
- **Coffee Bean Hopper:** Holds whole coffee beans.
- **Grounds Container:** Collects used coffee grounds.

4. INITIAL SETUP

Follow these steps to set up your coffee maker for the first time:

1. **Unpack the Appliance:** Carefully remove all packaging materials and ensure all components are present.
2. **Position the Machine:** Place the coffee maker on a stable, level surface, away from heat sources and direct sunlight. Ensure adequate ventilation around the unit.
3. **Clean Components:** Wash the water tank, milk frother components, and drip tray with warm soapy water. Rinse thoroughly and dry.
4. **Fill Water Tank:** Remove the water tank (Image 3.5), fill it with fresh, cold water up to the 'MAX' line, and securely place it back into the machine.
5. **Add Coffee Beans:** Open the coffee bean hopper lid and fill it with your preferred whole coffee beans (Image 3.6). Close the lid securely.
6. **Connect Power:** Plug the power cord into a grounded electrical outlet.
7. **First Use Cycle:** The machine may prompt you to perform a rinsing cycle. Follow the on-screen instructions to flush the system with hot water. This primes the system and cleans any manufacturing residues.
8. **Wi-Fi Setup:** Your coffee maker is Wi-Fi enabled. Follow the instructions on the touch panel to connect to your home Wi-Fi network. This enables app control features.

5. OPERATING INSTRUCTIONS

Your TAURUS Aroma De Cafe coffee maker offers a variety of options for brewing your favorite coffee.

5.1 Brewing Coffee

1. **Turn On:** Press the power button. The touch panel will illuminate.
2. **Select Drink:** On the touch panel (Image 3.3), select your desired coffee type (e.g., Espresso, Americano, Lungo).
3. **Adjust Settings (Optional):** For some drinks, you can adjust coffee strength, volume, or temperature via the on-

screen options.

4. **Place Cup:** Position a cup under the coffee dispenser. For milk-based drinks, ensure the milk frother is correctly assembled and positioned with a milk container.
5. **Start Brewing:** Press the 'Start' icon on the display. The machine will grind beans, brew, and dispense your coffee.



Image 5.1: Coffee being dispensed from the machine into a glass cup, illustrating the brewing process.



Image 5.2: A hand interacting with the touch screen to select a coffee beverage, highlighting the user-friendly interface.

5.2 Using the Milk Frother

For Cappuccinos, Latte Macchiatos, and Latte Coffees:

1. **Assemble Frother:** Ensure the milk frother components (Image 3.4) are correctly assembled and attached to the machine.
2. **Add Milk:** Fill the milk container with cold milk. Do not exceed the maximum fill line.
3. **Select Milk-Based Drink:** Choose your desired milk-based coffee from the touch panel.
4. **Start:** The machine will automatically froth the milk and then dispense the coffee.

5.3 Wi-Fi Connectivity and App Control

Once connected to Wi-Fi, you can control your coffee maker remotely using the dedicated TAURUS app. This allows you to:

- Start brewing from anywhere.
- Customize drink settings.
- Receive maintenance alerts.

Refer to the app's instructions for detailed usage.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your coffee maker. The machine features an **Auto Clean Function** for convenience.

6.1 Daily Cleaning

- **Drip Tray:** Empty and rinse the drip tray daily.
- **Coffee Grounds Container:** Empty the used coffee grounds container when prompted or daily. Rinse and dry.
- **Milk Frother:** After each use, run a quick rinse cycle for the milk frother. Disassemble and wash components (Image 3.4) with warm soapy water regularly.
- **Water Tank:** Rinse the water tank (Image 3.5) and refill with fresh water daily.

6.2 Weekly / Bi-Weekly Cleaning

- **Brew Unit:** The brew unit may be removable for rinsing under tap water. Consult the on-screen instructions or a more detailed manual for specific steps.
- **Exterior:** Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners.

6.3 Descaling

The machine will indicate when descaling is required. Use a descaling solution specifically designed for coffee machines and follow the on-screen instructions or the descaling agent's directions carefully.

7. TROUBLESHOOTING

If you encounter issues with your coffee maker, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
No coffee dispensed	Water tank empty; coffee beans empty; brew unit clogged.	Refill water tank; refill coffee beans; clean brew unit.
Coffee is too weak/strong	Incorrect grind setting; incorrect coffee strength setting.	Adjust grind fineness; adjust coffee strength on display.
Milk not frothing correctly	Milk frother dirty; milk type unsuitable; milk too warm.	Clean milk frother thoroughly; use cold, fresh milk (dairy or suitable plant-based); ensure milk is cold.
Machine not turning on	No power; power cord not properly connected.	Check power outlet; ensure power cord is securely plugged in.
Wi-Fi connection issues	Incorrect password; router too far; network interference.	Re-enter Wi-Fi password; move machine closer to router; restart router.

If the problem persists after attempting these solutions, please contact customer support.

8. TECHNICAL SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Brand	TAURUS
Model Number	24132021
Colour	Silver (Note: Product images show black, but specification lists silver. Please verify product color upon receipt.)
Product Dimensions	42.5 x 24.5 x 32 cm
Item Weight	11.4 kg
Capacity	1.5 Liters (Water Tank)
Power / Wattage	1480 watts
Material	18/8 Stainless Steel
Auto Shutoff	Yes
Special Features	App-Controlled, Auto Clean Function, Integrated Coffee Grinder, Milk Frother, Removable Tank
Coffee Maker Type	Espresso Machine
Specific uses for product	Cappuccino, Espresso, Latte

9. WARRANTY AND SUPPORT

9.1 Warranty Information

This TAURUS coffee maker comes with a **1 Year Retail Warranty**, plus an additional **1 Year Extended Warranty**. Please retain your proof of purchase for warranty claims.


For detailed terms and conditions of the warranty, please refer to the warranty card included with your product or visit the official TAURUS website.






9.2 Customer Support

Should you require assistance with your product, have questions about its operation, or need to report a fault, please contact TAURUS customer support. Contact details can typically be found on the TAURUS website or on the product packaging.

When contacting support, please have your product model number (24132021) and proof of purchase readily available.

Related Documents - 24132021

	<p>Taurus Aromatic Molinillo de Café - Manual de Usuario e Instrucciones</p> <p>Manual de usuario detallado e instrucciones de seguridad para el molinillo de café Taurus Aromatic. Aprenda a usar, limpiar y mantener su molinillo para un rendimiento óptimo.</p>
---	---

	<p>Taurus Rowzer Plus Frozen Food Processor with Brushless Motor</p> <p>Discover the Taurus Rowzer Plus, a professional frozen food processor featuring a powerful 1000W brushless motor. Ideal for creating velvety ice creams, sorbets, mousses, and more, it offers easy operation, precise portion control, and fast processing at -22°C. Learn about its advanced design, technical specifications, and step-by-step process for professional culinary applications.</p>
	<p>Manual de Instrucciones Taurus Ultimate Go Ultimate Digital</p> <p>Guía completa para el aspirador vertical sin cable Taurus Ultimate Go Ultimate Digital, cubriendo uso, carga, limpieza y mantenimiento.</p>
	<p>Taurus Homeland Unique: Manual de Instrucciones y Seguridad</p> <p>Descubra el manual de instrucciones y seguridad para el aspirador Taurus Homeland Unique (HVCA7229B). Información detallada sobre uso, mantenimiento y precauciones para un hogar seguro y eficiente.</p>
	<p>Manual de Usuario y Consejos de Seguridad del Ventilador de Techo FRESKO INVISIBLE Taurus Alpatec</p> <p>Descubra el manual de usuario y las instrucciones de seguridad para el ventilador de techo Taurus Alpatec FRESKO INVISIBLE. Información detallada sobre instalación, funcionamiento, mantenimiento y especificaciones técnicas para un uso seguro y eficiente.</p>
	<p>Manual de Instrucciones Taurus HB1700X / HBA1700X: Batidora de Varilla</p> <p>Manual completo de instrucciones para la batidora de varilla Taurus HB1700X y HBA1700X. Aprenda a usar, cuidar y limpiar su electrodomestico de cocina de forma segura y eficiente.</p>