

[Manuals.plus](#) /

› [Tribesigns](#) /

› Tribesigns Shoe Cabinet Instruction Manual

Tribesigns XK00312/313

Tribesigns Shoe Cabinet Instruction Manual

Model: XK00312/313

1. PRODUCT OVERVIEW

The Tribesigns Shoe Cabinet is a heavy-duty, freestanding storage solution designed to organize your footwear efficiently. With 9 tiers, it can accommodate 32-35 pairs of adult shoes or 40-45 pairs of kids' shoes, making it ideal for entryways, bedrooms, or living rooms. Its tall, narrow design maximizes vertical space, providing ample storage without occupying a large footprint.

This cabinet features a sleek black finish and is constructed from quality E1 particle board, ensuring durability and stability. The design includes open shelving for easy access and display of your shoe collection. Some shelves are movable, offering flexibility for storing taller items like boots.



Figure 1.1: The Tribesigns 9-Tier Black Shoe Cabinet, showcasing its capacity and design in a typical home setting.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Two-Person Assembly:** Always assemble this product with two persons to ensure stability and prevent injury due to its height and weight.
- **Pinch Points:** Be cautious of pinch points during assembly, especially when handling and connecting panels.
- **Overloading:** Do not overload the cabinet. Distribute weight evenly across shelves to maintain stability.
- **Anti-Tip Kit:** For enhanced safety, especially in households with children or pets, it is highly recommended to secure the cabinet to a wall using the provided anti-tip hardware.
- **Stable Surface:** Place the cabinet on a flat, level, and stable surface to prevent wobbling or tipping.



Figure 2.1: Example of an anti-tip bracket for securing the cabinet to a wall.

3. PACKAGE CONTENTS

Before beginning assembly, ensure all parts and hardware are present and accounted for. If any items are missing or damaged, please contact customer support.

3.1. Components

- Side Panels (2)
- Top Panel (1)
- Bottom Panel (1)
- Fixed Shelf Panels (e.g., 1-2)
- Adjustable Shelf Panels (e.g., 7-8)
- Back Panels (multiple sections)
- Base/Legs (if applicable)

3.2. Hardware

- Screws (various types and sizes)
- Dowel Pins
- Cam Locks and Cam Bolts
- Anti-Tip Kit (bracket, screws, wall anchors)
- Assembly Tool (e.g., screwdriver, Allen wrench)
- Non-slip feet pads

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to have a clear, spacious area for assembly.

1. **Unpack and Identify Parts:** Lay out all components and hardware on a soft, clean surface. Refer to the parts list to ensure everything is present.
2. **Attach Cam Bolts and Dowel Pins:** Insert cam bolts and wooden dowel pins into the designated holes on the side panels and fixed shelf panels. Ensure they are fully seated.
3. **Assemble Base:** Connect the bottom panel to the side panels using cam locks and cam bolts. Tighten cam locks securely. Attach non-slip feet pads to the base.
4. **Install Fixed Shelves:** Carefully align and insert fixed shelf panels into the grooves or pre-drilled holes on the side panels. Secure with cam locks. Note that the red structural board shown in some diagrams cannot be moved.
5. **Attach Back Panels:** Secure the back panels to the rear of the cabinet using the provided screws. Ensure the

panels are flush and square.

6. **Install Top Panel:** Place the top panel onto the assembled structure, aligning with cam bolts and dowel pins. Secure with cam locks.
7. **Insert Adjustable Shelves:** Place the movable blue boards (adjustable shelves) into the desired slots. These shelves can be removed or repositioned to accommodate items of different heights, such as boots.
8. **Secure to Wall (Recommended):** Attach the anti-tip bracket to the top rear of the cabinet and then to a wall stud using appropriate wall anchors and screws. This step is crucial for stability and safety.




Figure 4.1: Cabinet dimensions and shelf adjustability. Note the fixed structural board (red) and movable shelves (blue).



Figure 4.2: Illustration of how movable shelves create space for taller items like boots.

5. OPERATING INSTRUCTIONS

The Tribesigns Shoe Cabinet is designed for straightforward use and organization.

- **Shoe Placement:** Place shoes directly onto the shelves. The open design allows for easy visibility and access.
- **Capacity:** The cabinet can hold approximately 32-35 pairs of adult shoes or 40-45 pairs of children's shoes, depending on shoe size and arrangement.
- **Adjustable Shelves:** Utilize the movable shelves to customize storage space. Remove a shelf to create taller compartments for boots or larger items.
- **Versatile Storage:** While primarily designed for shoes, the cabinet's open shelves can also be used to store other daily items, small decorations, or storage bins.



Figure 5.1: Two cabinets combined for extended storage, demonstrating versatile use.

6. MAINTENANCE

Proper care will extend the life and appearance of your shoe cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust the shelves and panels to prevent buildup.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood finish.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure, which can cause fading or discoloration over time.
- **Moisture:** Keep the cabinet away from excessive moisture or humidity to prevent warping or damage to the engineered wood.
- **Hardware Check:** Periodically check all screws and cam locks to ensure they remain tight. Retighten if necessary.

7. TROUBLESHOOTING

If you encounter any issues with your Tribesigns Shoe Cabinet, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Cabinet is wobbly or unstable.	Uneven floor; loose hardware; not secured to wall.	Ensure cabinet is on a level surface. Tighten all screws and cam locks. Secure the cabinet to the wall using the anti-tip kit.
Parts do not fit together.	Incorrect orientation of panels; misaligned hardware.	Double-check the assembly diagrams and ensure panels are oriented correctly. Realign hardware if necessary. Do not force parts.
Missing or damaged parts.	Packaging error; shipping damage.	Contact Tribesigns customer support with your product model and a description of the missing/damaged parts.
Shoes do not fit on shelves.	Shoes are too tall for current shelf height.	Adjust the movable shelves to create taller compartments. For very tall boots, consider placing them on the bottom shelf or removing a shelf entirely.

8. SPECIFICATIONS

- Brand:** Tribesigns
- Model Name:** XK00312/313
- Color:** Black
- Product Dimensions:** 11.81"D x 31.49"W x 70.86"H
- Material:** Engineered Wood (E1 Particle Board)
- Number of Shelves:** 9 (including fixed and adjustable)
- Capacity:** Approximately 32-35 adult pairs / 40-45 kids pairs
- Mounting Type:** Freestanding (Wall mount recommended with anti-tip kit)
- Assembly Required:** Yes
- Item Weight:** 93.5 pounds
- Special Feature:** Adjustable Shelf
- Included Components:** Hardware, Non-slip feet pads, Anti-tip kit

9. WARRANTY AND SUPPORT

Tribesigns products are designed for quality and durability. For specific warranty information, please refer to the documentation included with your purchase or visit the official Tribesigns website. If you have any questions, require replacement parts, or need assistance with assembly or troubleshooting, please contact Tribesigns customer support.

Customer Support Contact: Please refer to the contact information provided in your product packaging or on the official Tribesigns website ([Visit Tribesigns Store on Amazon](#)).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C5RMQZ47>

More documents and user manuals: <https://manuals.plus/>