SERVOMASTER SM01

SERVOMASTER SM01 Cordless Handheld Vacuum Cleaner User Manual

Model: SM01 | Brand: SERVOMASTER

1. Introduction

Thank you for choosing the SERVOMASTER SM01 Cordless Handheld Vacuum Cleaner. This portable and lightweight device is designed for efficient cleaning in various environments, including your car, home, and office. Its powerful suction and versatile attachments make it ideal for tackling fine particles, small debris, and pet hair. Please read this manual thoroughly before use to ensure proper operation and maintenance.



Image: The SERVOMASTER SM01 Cordless Handheld Vacuum Cleaner, a compact black device.

2. Safety Information

To ensure safe operation and prevent damage, please observe the following safety guidelines:

- Read all instructions before using the appliance.
- Keep the vacuum cleaner away from water or other liquids.
- Do not vacuum flammable or combustible materials, hot ashes, or sharp objects.

- Ensure the filter is properly installed before operation.
- Do not allow children to operate the vacuum cleaner.
- Use only the provided charging cable for recharging.
- Do not operate the vacuum cleaner if it is damaged or malfunctioning.

3. Product Overview

The SERVOMASTER SM01 comes with essential components and accessories to enhance your cleaning experience:

- SM01 Handheld Vacuum Cleaner
- Extra HEPA Filter
- Crevice Tool
- Dust Brush
- Drawstring Bag
- User Manual
- TYPE-C Charging Cable



Image: An illustration showing all components included in the SERVOMASTER SM01 package.

4. Setup

4.1 Initial Charging

Before first use, fully charge the vacuum cleaner. Connect the provided TYPE-C charging cable to the charging port on the vacuum and plug the other end into a compatible USB power source. The charging indicator light will illuminate. A full charge typically takes 3-4 hours.



Image: The SERVOMASTER SM01 vacuum cleaner connected to a Type-C charging cable.

4.2 Filter Installation

Ensure the HEPA filter is correctly placed inside the dust cup before attaching the dust cup to the main vacuum unit. The filter helps capture fine dust and allergens.

Your browser does not support the video tag.

Video: An overview of the SERVOMASTER SM01 Cordless Handheld Vacuum Cleaner, demonstrating unboxing, assembly, and basic features.

5. Operating Instructions

5.1 Power On/Off

Press the power button located on the handle to turn the vacuum cleaner on or off.

5.2 Using Attachments

The SM01 comes with two specialized attachments for different cleaning needs:

- **Crevice Tool:** Attach this tool for cleaning narrow gaps, corners, and hard-to-reach areas in your car or home.
- **Brush Tool:** Use the brush tool to loosen and vacuum up pet hair, dust from keyboards, and debris from carpets or upholstery.



Image: The vacuum cleaner with the crevice tool attached, demonstrating its use for tight spaces.



Image: The vacuum cleaner with the brush tool attached, suitable for pet hair and upholstery.



Image: The SERVOMASTER SM01 effectively vacuuming different types of debris, including pet food, paper scraps, and dirt.

6. Maintenance

6.1 Emptying the Dust Cup

To maintain optimal suction, empty the dust cup regularly. Press the release button to detach the dust cup from the main unit, then discard the collected debris.

6.2 Cleaning the HEPA Filter

The built-in HEPA filter is removable and washable. After detaching the dust cup, remove the filter. Wash it under running water until clean. Ensure the filter is completely dry before re-inserting it into the dust cup and reattaching it to the vacuum cleaner. Regular cleaning extends the filter's life and maintains suction power.



Image: A close-up of the washable HEPA filter, showing it being cleaned with water.

7. Troubleshooting

- **Reduced Suction:** Check if the dust cup is full and needs emptying. Ensure the HEPA filter is clean and properly installed. Verify there are no blockages in the nozzle or attachments.
- **Short Battery Life:** Ensure the vacuum is fully charged (3-4 hours). If the issue persists, the battery may need replacement (contact customer support).
- **Vacuum Not Turning On:** Confirm the battery is charged. Check that the power button is pressed firmly.

8. Specifications

Feature	Detail
Brand	SERVOMASTER
Model Name	SM01
Motor Horsepower	120 Watts
Battery Life	More than 20 minutes
Charging Time	3-4 hours
Filter Type	HEPA Filter (Washable)
Product Dimensions	11.8"L x 3.9"W x 3.9"H
Item Weight	1.23 pounds
Noise Level	75 Decibels
Special Features	Cordless, Lightweight, Portable, Type-C Charging

9. Warranty and Support

For warranty information, technical support, or any product-related inquiries, please refer to the contact information provided with your purchase or visit the official SERVOMASTER website. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question