

[Manuals.plus](#) /

› [Lamshaw](#) /

› Lamshaw Bling Watch Band Instruction Manual (18mm, 20mm, 22mm)

Lamshaw Bling Watch Band (18mm, 20mm, 22mm)

Lamshaw Bling Watch Band Instruction Manual

Models: 18mm, 20mm, 22mm Quick Release Metal Watch Bands

1. INTRODUCTION

Thank you for choosing the Lamshaw Bling Watch Band. This manual provides essential information for the proper installation, adjustment, and care of your new watch band. These bands are designed for compatibility with various smartwatches and traditional watches that use 18mm, 20mm, or 22mm quick-release pins.



Figure 1: Lamshaw Bling Watch Band (Black variant shown). This image displays the full watch band with its quick-release pins and decorative crystal elements.

2. SETUP AND INSTALLATION

2.1. Determining the Correct Band Size

Before installing your new band, accurately measure the lug width of your watch. The lug width is the

distance between the two points where the watch band connects to the watch case. This band is available in 18mm, 20mm, and 22mm sizes.

SHOPPING GUIDELINE

Step 1: Accurately measure the distance between your watch lug and determine which band you'll need to purchase




Figure 2: Illustration of measuring watch lug width using a ruler and the quick-release pin mechanism for easy band changes.

2.2. Attaching the Watch Band

1. Locate the quick-release pins on the back of the watch band.
2. Insert one end of the quick-release pin into the lug hole on your watch.
3. Slide the small lever on the pin to retract the other end, then align it with the opposite lug hole.
4. Release the lever to secure the pin in place. Gently tug on the band to ensure it is firmly attached.



Figure 3: A Lamshaw Bling Watch Band correctly installed on a compatible smartwatch, showcasing the secure connection.

2.3. Adjusting Band Length

The watch band is adjustable to fit wrist sizes between 5.5 and 8.1 inches. A resizing tool is included to help you remove or add links for a perfect fit.

1. Place the band in the resizing tool with the arrow on the link pointing downwards.
2. Turn the tool's handle to push the pin out of the link.
3. Remove the desired number of links.
4. Reassemble the band by inserting the pins back into the links, ensuring the arrows on the links point in the correct direction for reinsertion.




Figure 4: Visual guide demonstrating the process of removing links from the watch band using the provided tool to achieve the desired length.




Figure 5: Comparison showing the watch band before and after links have been removed, illustrating the adjustable nature of the band.

3. USAGE

Once installed and adjusted, your Lamshaw Bling Watch Band is ready for daily wear. The jewelry clasp ensures a secure fit. Avoid exposing the band to harsh chemicals, extreme temperatures, or prolonged immersion in water to preserve its finish and crystal integrity.



Figure 6: The watch band comfortably worn on a wrist, demonstrating its appearance during use.

4. MAINTENANCE

To maintain the appearance of your watch band, follow these simple cleaning instructions:

- Wipe the band regularly with a soft, dry cloth to remove dust and oils.
- For more thorough cleaning, lightly dampen a soft cloth with water and a mild, non-abrasive soap. Gently wipe the band, then dry immediately with a clean, dry cloth.
- Avoid using abrasive cleaners, solvents, or ultrasonic cleaners, as these can damage the metal finish or dislodge the crystals.

5. TROUBLESHOOTING

Issue	Possible Cause	Solution
-------	----------------	----------

Issue	Possible Cause	Solution
Band detaches from watch	Quick-release pin not fully engaged or incorrect band size.	Ensure the quick-release pins are securely seated in both lug holes. Verify the band size matches your watch's lug width.
Band feels too loose or too tight	Incorrect number of links for wrist size.	Adjust the band length by adding or removing links using the provided tool (refer to Section 2.3).
Crystals appear dull or dirty	Accumulation of dirt, oils, or residue.	Clean the band as described in Section 4.

6. SPECIFICATIONS

- **Material:** Metal alloy with crystal embellishments
- **Clasp Type:** Jewelry Clasp
- **Available Sizes:** 18mm, 20mm, 22mm (lug width)
- **Adjustable Wrist Size:** 5.5 - 8.1 inches (140mm - 205mm)
- **Compatibility:** Designed for watches with corresponding lug widths and quick-release pin mechanisms.



Figure 7: A display of various Lamshaw Bling Watch Bands, showcasing the range of available colors and finishes.

7. WARRANTY AND SUPPORT

Lamshaw provides a 30-day warranty from the date of purchase for quality-related issues. If you receive a defective item, please contact our customer support team for a replacement or refund.

For support inquiries, please contact us through the platform where you purchased the product. Please provide your order number and a detailed description of the issue.

