

[manuals.plus](#) /› [Edifier](#) /› [Edifier WH950NB Wireless Headphones User Manual](#)

## Edifier WH950NB

# Edifier WH950NB Wireless Headphones User Manual

Model: WH950NB

## 1. INTRODUCTION

Thank you for choosing the Edifier WH950NB Wireless Headphones. These headphones are designed to provide a high-quality audio experience with advanced features such as Active Noise Cancellation, Hi-Res Audio support, and Google Fast Pairing. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your device.

## 2. PACKAGE CONTENTS

Please ensure all items are present in the package:

- Edifier WH950NB Wireless Headphones
- Audio Cable
- USB Charging Cable
- Carrying Case (if included with your specific model)
- User Manual (this document)

## 3. PRODUCT OVERVIEW

Familiarize yourself with the main components and controls of your Edifier WH950NB headphones.



**Figure 1:** A pair of black Edifier WH950NB over-ear wireless headphones, showcasing their sleek design.

### Key Features:

- **Hi-Res Audio Wireless:** Supports LDAC certification for detailed and clear sound.
- **Active Noise Cancellation (ANC):** Two modes for ambient sound or wind reduction.
- **Crystal-Clear Calls:** Integrated 4-microphone system for enhanced voice clarity.
- **40mm Dynamic Driver:** Delivers natural and balanced audio.
- **Google Fast Pairing:** Quick and effortless Bluetooth pairing with Android devices.
- **Long Playtime:** Up to 55 hours of playback.

- **Dual-Device Connection:** Connect to two devices simultaneously.

## 4. SETUP

### 4.1 Charging the Headphones

1. Connect the USB charging cable to the charging port on the headphones.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The indicator light will show charging status. A full charge typically takes approximately 2 hours.
4. A 10-minute charge can provide up to 7 hours of playtime.



**Figure 2:** This image emphasizes the headphones' extended playtime and fast charging capability, providing 7 hours of listening from just 10 minutes of charging.

### 4.2 Bluetooth Pairing

1. Ensure the headphones are powered off.
2. Press and hold the power button until the indicator light flashes rapidly, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "Edifier WH950NB" from the list of devices.
5. Once connected, the indicator light will stop flashing and remain solid blue.

## Google Fast Pairing:

For Android devices, the WH950NB supports Google Fast Pairing. Simply turn on the headphones near your Android device, and a pairing notification will appear on your screen for quick connection.



**Figure 3:** The headphones are shown alongside a smartphone, indicating the Google Fast Pairing feature for quick and effortless Bluetooth connection with Android devices.

## 5. OPERATING INSTRUCTIONS

### 5.1 Active Noise Cancellation (ANC) and Ambient Sound

The WH950NB offers two active noise cancellation modes and an ambient sound mode to adapt to your environment.

- Press the ANC button to cycle through modes: ANC On, Ambient Sound, and Standard (ANC Off).
- **ANC On:** Reduces external noise for an immersive listening experience.
- **Ambient Sound:** Allows you to hear your surroundings while listening to audio.
- **Standard:** Disables noise cancellation and ambient sound.



## Clearly Hear & Be Heard Clearly

Via active noise cancellation and 4-Mic for environmental noise cancellation



**Figure 4:** This image demonstrates the active noise cancellation feature and the 4-microphone system designed for clear voice calls, effectively reducing environmental noise for both listening and speaking.

### 5.2 Call Functions

The integrated 4-microphone system ensures clear voice calls.

- **Answer/End Call:** Press the multi-function button once.
- **Reject Call:** Press and hold the multi-function button for 2 seconds.

### 5.3 Dual-Device Connection

The headphones can be connected to two Bluetooth devices simultaneously.

1. Connect the headphones to the first device as described in section 4.2.
2. Disconnect the headphones from the first device (or put them back into pairing mode).
3. Connect the headphones to the second device.
4. Reconnect the headphones to the first device. The headphones will now be connected to both devices.
5. Audio playback will switch automatically between devices.

### 5.4 Edifier Connect App

Download the Edifier Connect app from your device's app store to unlock additional features and customization

options, including:

- Equalizer (EQ) adjustments.
- ANC mode customization.
- Firmware updates.



**Figure 5:** This image illustrates the headphones' support for Hi-Res Audio Wireless with LDAC certification, allowing for detailed and clear sound. Users can customize their audio experience via the Edifier app.

## 6. MAINTENANCE AND CARE

Proper maintenance ensures the longevity and performance of your headphones.

- Clean the headphones regularly with a soft, dry cloth. Do not use liquid cleaners.
- Avoid exposing the headphones to extreme temperatures, humidity, or dust.
- Store the headphones in their carrying case when not in use to protect them from damage.
- Do not attempt to disassemble or modify the headphones, as this will void the warranty.
- Keep the charging port free of debris.

## 7. TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions.

| Problem                          | Solution   |
|----------------------------------|--|
| No sound                         | Ensure headphones are charged and connected. Check volume levels on both headphones and device.                        |
| Cannot pair via Bluetooth        | Ensure headphones are in pairing mode. Turn off and on Bluetooth on your device. Clear previous Bluetooth connections. |
| Noise cancellation not effective | Ensure ANC mode is activated. Adjust headphone fit for a proper seal.  |
| Poor call quality                | Ensure microphone is not obstructed. Move to a quieter environment.  |
| Headphones not charging          | Check charging cable and power source. Ensure charging port is clean.  |

## 8. SPECIFICATIONS

Technical specifications for the Edifier WH950NB Wireless Headphones.

- **Model:** WH950NB
- **Bluetooth Version:** 5.3
- **Audio Driver:** 40mm Dynamic Driver
- **Frequency Response:** 20Hz - 20kHz
- **Charging Time:** Approximately 2 hours
- **Playtime:** Up to 55 hours (ANC off), up to 34 hours (ANC on)
- **Connectivity:** Bluetooth 5.3, 3.5mm Audio Jack
- **Noise Control:** Active Noise Cancellation
- **Weight:** 1.54 pounds (approx.)
- **Material:** Plastic



**Figure 6:** A close-up view of the headphone's ear cup, highlighting the 40mm composite titanium film dynamic driver responsible for delivering exceptional and balanced audio across all music genres.

## 9. SAFETY INFORMATION

Please read and follow these safety guidelines:

- Do not use headphones at high volume for extended periods to prevent hearing damage.
- Do not use headphones in situations where inability to hear ambient sounds could be dangerous (e.g., driving, cycling, walking in traffic).
- Keep the product away from water and moisture.
- Dispose of the product and its battery responsibly according to local regulations.

## 10. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the official Edifier website or contact their customer service directly. Keep your proof of purchase for warranty claims.

## Related Documents - WH950NB

[Edifier WH950NB Wireless Noise Cancelling Headphones User Manual](#)



WH950NB  
Wireless Noise Cancelling Over-ear Headphones  
Model ED950NB

— Manual — BC

EN 1. Power ON/OFF



2. First pairing



3. Pairing for new device



4. Controls



4. Controls



4. Controls



5. Multipoint connection



5. Multipoint connection

1. Pair device A with the headphones successfully.  
2. Turn on device B and connect to the headphones in Bluetooth pairing mode, and then select 'EDIFIER WH950NB' in device B settings.  
3. Select 'TOP 8.8 HYPNOTIC' again in device A settings to complete the connection.  
Note: If two devices use the headphones to automatically reconnect to the last device used, turn off the headphones.

6. Wired listening



6. Wired listening

Connect to the headphones via AUX audio cable.  
Wired listening will automatically switch to Bluetooth mode.

7. Reset



7. Reset

1. In ON state, press '+' and '-' buttons for 5 seconds, while LED will blink.  
2. Then the headphones will automatically enter Bluetooth pairing mode.

8. Charging





8. Charging

Connect the headphones to a power source via the USB-C cable for charging.  
Note: The USB-C port is compatible with most devices.

EN 1003-2:  
Built-in microphones for hands-free smartphone calls.

User manual for the Edifier WH950NB Wireless Noise Cancelling Over-ear Headphones, covering power on/off, Bluetooth pairing, controls, multipoint connection, wired listening, reset, and charging.

|   |  |
|---|--|
|    | <p><a href="#">Edifier MT6 Over-ear Active Noise Cancelling Bluetooth Headphones User Manual</a></p> <p>User manual for the Edifier MT6 over-ear active noise cancelling Bluetooth headphones, detailing operation, Bluetooth pairing, factory reset, and care instructions for the ear pads.</p>  |
|   | <p><a href="#">EDIFIER ES850NB Active Noise Cancelling Headphones User Manual</a></p> <p>Comprehensive user manual for the EDIFIER ES850NB active noise cancelling over-ear headphones, covering setup, pairing, controls, charging, and troubleshooting.</p>  |
|  | <p><a href="#">EDIFIER W820NB Headphones User Manual</a></p> <p>Comprehensive user manual for the EDIFIER W820NB headphones, covering product description, accessories, power on/off, charging, user guide (Bluetooth connection, music playback, calls, media controls), and user guide (factory reset, music playback, calls, media controls).</p> |





- Comprueba si funciona en el móvil.
- Comprueba si el volumen del auricular está al nivel adecuado.
- Comprueba si el auricular está correctamente conectado al móvil.
- Comprueba si funciona el auricular dentro de la distancia normal de funcionamiento.

**El efecto de llamada del auricular es malo.**

- Comprueba si tu teléfono móvil está en una zona con buena señal.
- Asegúrate de que el auricular tiene una distancia efectiva (DTE) y que no haya ningún obstáculo entre auricular y móvil.

**Cuando se reproduce música, no se puede controlar pasos/ reproducción/pista anterior/siguiente con el auricular.**

- Comprueba que el dispositivo embebido sea compatible con el perfil A2DP (Audio Video Remote Control Profile) (Perfi de control remoto audiovisual).

## 6. Mantenimiento

- Si no se utiliza durante largos períodos de tiempo, para fumar, coagúlate el tabaco y el humo que se libera de cada tres meses.
- Mantén el tabaco lejado de lugares húmedos para que no afecten a las circulaciones internas.
- No cojas el producto en lugares expuestos al sol o a las temperaturas altas.
- Las altas temperaturas aumentan la degradación de las componentes elementales del producto y las agresivas componentes de plástico.
- No cojas el producto en lugares fríos para no dañar a las pieles de circulaciones internas.
- No lo dejes en el medio ambiente. Si lo maneja personal no profesional, se debe tener en cuenta que es un producto tóxico.
- No lo dejas que vuelve húmedo, ni lo dejénes en un ambiente húmedo.
- No te dediques a encender intermitentemente.
- No te dediques a quemarlos al revés para limpiar los envases.
- No lo utilices durante largos períodos de tiempo para evitar dañar la circulación exterior y que afecte al aspecto.

Model: EDF200046  
Edifier International Limited  
P.O. Box 6294  
General Post Office  
Hong Kong  
[www.edifier.com](http://www.edifier.com)  
©2021 Edifier International Limited. Todos los derechos reservados.  
Impreso en China

DF 1: Produktbeschreibung und Zubehör



Zubehör: Ohrlöcher x1, Ladekabel x1, Bedienungsanleitung x1

Hinweis:

- Die Abbildungen dienen ausschließlich zur Veranschaulichung und können vom tatsächlichen Produkt abweichen.
- Um Hi-Fi-Audio zugeleitet zu erhalten, schließen Sie dieses Headset bitte mit einem Typ-C-Datenkabel an Audiotausgabeleitung an.

## 2. Einschalten/Ausschalten

- **Einschalten:**  
Halten Sie den Ein-/Ausschalter etwa 3 Sekunden lang gedrückt. Das blaue Licht leuchtet auf.
- **Ausschalten:**  
Halten Sie den Ein-/Ausschalter etwa 3 Sekunden lang gedrückt. Das rote Licht leuchtet auf und die Anzeige leuchtet.



3. Aufladen



**⚠ Achtung:** Die aufladbaren Batterien, die Strom für dieses Produkt zur Verfügung stellen, müssen korrekt für das Recycling entsorgt werden. Werfen Sie Altbatterien nicht ins Feuer, um der Gefahr einer Explosion vorzubeugen.

4. Bedienungsanleitung

- Haben Sie bei der ersten Anwendung den Ein-/Ausschalter etwa 3 Sekunden lang gedrückt, um das Headset einzuschalten. Das blaue und

- Stellen Sie das Modellleben so ein, dass es nach **JORDAN WHISKEY** steht und eine Verbindung zu diesem herstellt. Nach erfolgreicher Kupplung blinzelt ein blaue Licht zweimal. Für die spätere Verwendung wird das Headset mit dem zuletzt verwendeten Gerät verbunden.
- Verbindung zu neuen Bluetooth-Geräten herstellen: Wenn das Headset eingeschaltet ist, halten Sie die Multifunktions tasten für die Gerätewahlung etwa 5 Sekunden lang gedrückt. Das blaue und grüne Licht blinken abwechselnd und schnell.

gleichzeitig etwa 5 Sekunden gedrückt, bis das blaue Licht sechs Mal schnell hintereinander blinkt, um die letzten Kopplungen zu löschen.



#### → Anruftätigkeiten



#### • Medusenhalter@Bluetooth-Kopplung



5. FAQs

- Anstatt der blauen Leuchte blinkt die rote Leuchte.  
• Der Stand des in dem Ohrhöher verbaute Akkus ist niedrig. Laden Sie die Ohrhöher wieder auf.
- Kein Ton  
• Überprüfen Sie, ob die Ohrhöher eingeschaltet sind.

- Überprüfen Sie, ob die Ohrhörer eingeschaltet sind.
- Prüfen Sie, ob die Lautstärke der Ohrhörer auf einen angemessenen Pegel eingestellt ist.
- Kontrollieren Sie, ob die Ohrhörer ordnungsgemäß mit Ihrem Mobiltelefon verbunden sind.
- Vergegenwärtigen Sie sich, dass sich die Ohrhörer innerhalb der maximal vorgesehene Reichweite zum Gerät befinden.

Die Gesprächsschärfe der Ohrhörer ist ausschließlich:

- Kontrollieren Sie, ob das Mobiltelefon über ein ausreichend starkes Empfangssignal verfügt.
- Melden Sie sich an, dass der Abstand zwischen den Ohrhörern und Ihrem Mobiltelefon nicht größer als 10 Meter ist.

Edifier W820NB Headphones: User Manual and Features

Comprehensive guide to the Edifier W820NB headphones, covering setup, Bluetooth connectivity, music playback, troubleshooting, and maintenance. Learn about active noise cancelling and Hi-Res audio.







ご了承  
この取扱説明書は日本語で記載されています。製品を購入された後、必ずお読みください。  
日本語の取扱説明書は、日本語で記載されています。  
この取扱説明書は、日本語で記載されています。  
この取扱説明書は、日本語で記載されています。

Model: ED70054


Edifier International Limited  
P.O. Box 1204  
General Post Office  
Hong Kong

[www.edifier.com](http://www.edifier.com)

Edifier International Limited は日本語版


日本語

ご注意  
本取扱説明書は、機器の操作、構造の確認、システムのアップグレードなどのため、必ずお読みください。  
必ずお読みください。この取扱説明書は、日本語で記載されています。  
必ずお読みください。この取扱説明書は、日本語で記載されています。  
必ずお読みください。この取扱説明書は、日本語で記載されています。



## [Edifier WH950NB Wireless Noise Cancellation Headphones User Manual](#)

This user manual provides instructions for the Edifier WH950NB Wireless Noise Cancellation Over-Ear Headphones, covering power on/off, pairing, resetting, status lights, and controls. It also includes product specifications and company information.



## [Edifier WH950NB Wireless Noise Cancellation Headphones - User Manual](#)

User manual for the Edifier WH950NB Wireless Noise Cancellation Over-Ear Headphones, covering power on/off, pairing, reset, status lights, and controls.

