



Manuals.plus /

› YMYNY /

› YMYNY Kitchen Baker's Rack UHBR001B Instruction Manual

YMYNY UHBR001B

YMYNY Kitchen Baker's Rack Instruction Manual

MODEL: UHBR001B

Introduction

Thank you for choosing the YMYNY Kitchen Baker's Rack, Model UHBR001B. This manual provides essential information for the safe assembly, operation, and maintenance of your new baker's rack. Please read these instructions carefully before beginning assembly and retain them for future reference.

Safety Information

Warning: Use on stable, even surfaces. Do not overload shelves or use S-hooks improperly to avoid injury or damage.

- Ensure all components are securely fastened before use.
- Do not exceed the weight limit of 20 kilograms (44 pounds) per shelf.
- Keep small parts away from children during assembly.
- Avoid placing hot items directly on the shelves without protective padding.

Parts List

Please verify that all parts are present and undamaged before beginning assembly. Refer to the included parts list and hardware package provided with your product for a complete inventory. If any parts are missing or damaged, please contact customer service.

Setup and Assembly

Assembly is required for this product. Follow the clear picture instructions and number-labeled hardware provided in your package. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out. Identify each component using the provided parts list.
2. **Assemble Frame:** Connect the metal frame components according to the diagram in your instruction booklet. Ensure all screws are finger-tightened initially.
3. **Attach Shelves:** Secure the particleboard shelves to the metal frame. The wine rack section is height adjustable; position it as desired before fully tightening.
4. **Install X-Frame Brackets:** Attach the X-frame brackets to the rear of the unit for enhanced stability.
5. **Attach S-Hooks and Top Bar:** Install the top bar and S-hooks as shown in the diagrams.
6. **Adjust Feet:** Once assembled, place the rack in its desired location. Adjust the anti-skid, adjustable feet pads to ensure the unit is stable and level on uneven floors.
7. **Final Tightening:** Systematically tighten all screws and bolts using the provided tool. Do not overtighten.



Figure 1: Product Dimensions. The rack measures 56.3 inches (143 cm) in height, 15.7 inches (40 cm) in width, and 23.2 inches (59 cm) in depth. This image provides a detailed dimensional overview of the assembled baker's rack, including shelf heights and overall footprint.



Figure 2: X-Frame Brackets. This image highlights the X-shaped brackets on the back of the rack, which are designed to enhance stability and prevent vertical separation of the shelves.



Figure 3: Adjustable Feet. A detailed view of the anti-skid, adjustable feet pads, which allow for leveling the rack on uneven surfaces, ensuring stability.

Operating Instructions

The YMYNY Kitchen Baker's Rack is designed for versatile storage in various settings.

- **Shelf Usage:** Utilize the four tiers of shelves for storing kitchen appliances such as microwave ovens, toasters, and coffee machines, as well as plates, spices, and other kitchen utensils.
- **Wine Holders:** The integrated wine holders are designed to securely store wine bottles horizontally.
- **S-Hooks:** The included S-hooks can be attached to the upper bar or side frames to hang cooking tools, mugs, or other small items for easy access.
- **Adjustable Features:** The wine rack section can be adjusted in height during assembly to accommodate different storage needs.





Figure 4: Fully Assembled Rack. This image displays the YMYNY Kitchen Baker's Rack in a kitchen setting, showcasing its capacity to hold various items like a coffee machine, mugs, wine bottles, a toaster oven, and a basket on its multiple shelves and hooks.



Figure 5: S-Hooks Detail. A close-up view of the S-hooks provided with the rack, demonstrating how they can be used to hang kitchen utensils or mugs from the upper bar.

Maintenance

- **Cleaning:** Wipe the surfaces with a dry cloth to remove dust and spills. Avoid using abrasive cleaners or harsh chemicals that may damage the finish.
- **Inspection:** Periodically check all connections and fasteners to ensure they remain tight. Retighten if necessary.
- **Placement:** To prolong the life of the product, avoid prolonged exposure to direct sunlight or excessive moisture.

Troubleshooting

Problem	Possible Cause	Solution
Rack is wobbly or unstable.	Uneven floor surface or loose connections.	Adjust the leveling feet pads on the bottom of the rack. Ensure all screws and bolts are securely tightened.
Missing parts or damaged components.	Packaging error or shipping damage.	Refer to the parts list and contact YMYNY customer service for assistance.
Difficulty assembling.	Instructions not followed correctly.	Review the assembly instructions carefully, paying attention to diagrams and labeled hardware. Ensure components are oriented correctly.

Specifications

Brand: YMYNY

Model Name: UHBR001B (999HBR001B)

Product Dimensions: 23.2"D x 15.7"W x 56.3"H (59 x 40 x 143 cm)

Material: Particleboard and Metal Frame

Number of Shelves: 4

Weight Limit: 20 Kilograms (44 pounds) per shelf

Special Feature: Waterproof (finish), Adjustable Wine Rack, S-Hooks, X-frame brackets

Assembly Required: Yes

Product Care Instructions: Wipe with Dry Cloth

Warranty and Support

YMYNY provides professional customer service before and after purchase. For any issues, questions, or concerns regarding your YMYNY Kitchen Baker's Rack UHBR001B, please contact our customer service department. While specific warranty details are not provided in this manual, please refer to your purchase documentation or contact customer service for warranty information.

You can typically find contact information on the YMYNY official website or through your retailer's support channels.