

Bobtot B48

Bobtot Surround Sound Speakers Home Theater Systems

Model: B48 | Brand: Bobtot

INTRODUCTION

The Bobtot B48 Home Theater System delivers an immersive audio experience with its 5.1/2.1 channel surround sound capabilities and powerful 700 Watts peak power. Featuring a 5.25-inch subwoofer with a built-in receiver, this system is designed to provide professional sound quality and excellent bass. It offers versatile connectivity options including Bluetooth 5.0, HDMI ARC, Optical, Coaxial, USB, and Auxiliary inputs, ensuring compatibility with a wide range of devices such as Ultra HD 4K TVs, game consoles, home DVDs, computers, laptops, and projectors. Its simple plug-and-play setup makes it easy to integrate into any home theater environment.



Figure 1: The Bobtot B48 Home Theater System, showcasing the central subwoofer unit, five satellite speakers, and remote control.

WHAT'S IN THE BOX

Upon unboxing your Bobtot B48 Home Theater System, please ensure all the following components are present:

- 1 x Main Subwoofer Unit (with built-in receiver)
- 1 x Center Channel Speaker
- 2 x Front Satellite Speakers
- 2 x Rear Satellite Speakers
- 1 x Full Function Remote Control
- 3 x RCA Video Audio Cables
- 1 x Optical Stereo Cable
- 1 x TV ARC Cable (HDMI)
- 1 x FM Antenna Cable
- 1 x Coaxial Cable
- 1 x 3.5mm to 2-Male RCA Audio Stereo Cable
- 1 x Quick Setup Guide (User Manual)



Figure 2: All components neatly laid out, including the subwoofer, satellite speakers, remote, and various connection cables.

SETUP GUIDE

Follow these steps to set up your Bobtot B48 Home Theater System for optimal performance.

1. Speaker Connection

The Bobtot B48 system features wired connections for all satellite speakers to the main subwoofer unit. This ensures stable audio transmission and allows for flexible placement within your room.

- Front Speakers (L/F): 13 feet cable length.
- Rear Speakers (L/R): 31 feet cable length.
- Center Speaker: 13 feet cable length.

Connect each satellite speaker to its corresponding output port on the rear panel of the subwoofer unit. Ensure a secure connection for clear audio.




Figure 3: Speaker placement and wired connections, highlighting the generous cable lengths for flexible setup.

2. Power On and Mode Selection

Before connecting to any input devices, ensure all speakers are connected to the subwoofer. Then, press the **ST.BY** button on the remote control or the front panel to turn on the system.

Your browser does not support the video tag.

Video 1: "How to set up B48 Home Theater Systems" - This video provides a comprehensive guide to setting up your Bobtot B48 system, including speaker connections and input mode selection.

3. Input Connections

The Bobtot B48 offers multiple input options to connect to various audio sources. Refer to the rear panel diagram for port locations.



Multimedia Supported



HDMI/TV ARC



FM



USB



FM



OPT/COA/AUX



BT



MIC

Figure 4: Detailed view of the subwoofer's rear panel, showing all available audio input and output ports.

HDMI ARC Input

Use the provided HDMI ARC cable to connect your TV's HDMI ARC port to the ARC input on the subwoofer. This allows audio from your TV to be sent directly to the sound system.

Optical Input (OPT)

For digital audio connection, use the optical cable. Connect one end to your TV's optical output and the other to the OPTICAL INPUT on the subwoofer. Remember to remove any protective caps from the optical cable ends before connecting.

Coaxial Input (COAX)

Connect a coaxial cable from your TV's coaxial audio output to the COAXIAL INPUT on the subwoofer. This is another digital audio option, often found on older TV models.

Auxiliary Input (AUX)

For analog audio devices, use the RCA to Aux cable (3.5mm to 2-Male RCA) or RCA to RCA cables. Connect the RCA

ends to the AUX AUDIO INPUT (L/R) on the subwoofer and the 3.5mm jack or other RCA ends to your audio device (e.g., smartphone, MP3 player, DVD player).

USB/SD Input

Insert a USB flash drive or SD card containing audio files into the respective ports on the front panel of the subwoofer. The system will automatically detect and play compatible audio files.

Bluetooth Connection (BT)

Switch the system to Bluetooth mode using the remote or front panel. On your mobile device, search for "Bobtot B48" in the Bluetooth settings and pair. Once connected, you can stream audio wirelessly.



Figure 5: The system features advanced Bluetooth 5.0 technology for stable wireless audio streaming.

OPERATING INSTRUCTIONS

The Bobtot B48 system can be controlled via the included full-function remote control or the intuitive front panel controls.

Remote Control Functions

The remote control provides comprehensive command over your home theater system:

- **Power (ST.BY):** Turns the system on or off.
- **Input:** Cycles through available input modes (HDMI ARC, Optical, Coaxial, AUX, USB/SD, Bluetooth).
- **Volume Control:** Adjusts the master volume. Individual speaker volumes (Front L/R, Center, Rear L/R, Subwoofer) can be controlled from -10 to +10.
- **5.1/2.1 Mode:** Switches between 5.1 channel surround sound and 2.1 stereo modes.
- **Mute:** Mutes or unmutes the audio output.
- **Playback Controls (USB/SD):** Play/Pause, Next/Previous Track.
- **FM Radio:** Scan, Tune, and preset stations (if applicable).




Figure 6: The full-function remote control provides easy access to all system settings and modes.

Front Panel Controls

The front panel of the subwoofer unit offers essential controls:

- **Digital Display:** Shows current input mode, volume level, and other status indicators.
- **Volume Knob/Input Selector:** Rotates to adjust master volume. Press to cycle through input modes.
- **CH+/CH-:** Adjusts individual channel volumes.
- **Play/Pause:** For USB/SD playback.
- **5.1/2.1 Function Key:** Toggles between 5.1 and 2.1 channel modes.
- **USB Socket:** For USB flash drive input.
- **SD/MMC Card Socket:** For SD card input.



Figure 7: The front panel provides convenient access to essential controls and displays system status.

KEY FEATURES

- **5.1 Channel Surround Sound:** Experience truly immersive audio with dedicated channels for front left, front right, center, rear left, rear right, and a powerful subwoofer. The system also supports 2.1 channel stereo mode, switchable via remote or front panel.
- **700 Watts Peak Power:** The 5.25-inch subwoofer, acting as the central receiver, delivers robust and clear sound with deep bass, ensuring a dynamic audio experience for movies, music, and games.



5.25 Inches Subwoofer

Figure 8: The powerful 5.25-inch subwoofer is the heart of the system, providing deep and resonant bass.

- **Wired Connection for Speakers:** All satellite speakers connect to the subwoofer via wired cables, ensuring a stable and high-quality audio signal without interference. The generous cable lengths (Front L/F: 13Ft, Rear L/R: 31Ft, Center: 13Ft) allow for flexible speaker placement.
- **Bluetooth 5.0 Technology:** Seamlessly connect your Bluetooth-enabled devices for wireless audio streaming with enhanced stability and range.
- **Simple Setup & Wide Compatibility:** Designed for plug-and-play convenience, the system is compatible with a broad array of devices including Ultra HD 4K TVs, game consoles, home DVD players, computers, laptops, and projectors, making it a versatile addition to any entertainment setup.



Wide Compatibility

Ultra HD 4K TV

Game Console

Home DVD

Computer

Projector

Figure 9: The system offers wide compatibility, connecting to various entertainment devices for an enhanced audio experience.

Your browser does not support the video tag.

Video 2: "Bobtot B48 Surround Sound Speakers 5.25\ Subwoofer" - This video highlights the key features and components of the Bobtot B48 system.

SPECIFICATIONS

Feature	Detail
Model Name	B48
Brand	Bobtot
Speaker Type	Surround Sound, Subwoofer
Surround Sound Channel Configuration	5.1

Feature	Detail
Speaker Maximum Output Power	700 Watts (Peak)
Subwoofer Diameter	5.25 Inches
Connectivity Technology	RCA, Bluetooth, Auxiliary, USB, Optical, HDMI, Coaxial
Wireless Communication Technology	Bluetooth 5.0
Power Source	Corded Electric
Material	Wood
Color	Black
Product Dimensions	16"D x 13.8"W x 13.4"H
Item Weight	22.2 pounds
Manufacturer	MOSWS INTERNATIONAL LIMITED
Date First Available	May 22, 2023

MAINTENANCE

To ensure the longevity and optimal performance of your Bobtot B48 Home Theater System, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the surfaces of the speakers and subwoofer. Avoid using liquid cleaners, aerosols, or abrasive materials, as they may damage the finish or internal components.
- **Ventilation:** Ensure adequate airflow around the subwoofer unit, especially the rear panel where heat is dissipated. Do not block ventilation openings.
- **Placement:** Place the system on a stable, flat surface away from direct sunlight, heat sources, and excessive moisture. Avoid placing it in enclosed cabinets without proper ventilation.
- **Cable Management:** Keep cables organized and untangled to prevent damage and ensure safety. Avoid placing heavy objects on cables.

TROUBLESHOOTING

If you encounter any issues with your Bobtot B48 Home Theater System, refer to the following common troubleshooting tips:

- **No Power:**
 - Ensure the power cable is securely plugged into both the subwoofer and a working power outlet.
 - Check if the power switch on the rear panel of the subwoofer is in the "ON" position.
 - Verify that the power outlet is functional by plugging in another device.
- **No Sound:**
 - Confirm that the correct input source is selected on the system (e.g., HDMI ARC, Optical, Bluetooth).
 - Check the volume level on both the system and your connected device. Ensure the system is not muted.

- Verify that all speaker cables are securely connected to the subwoofer and the satellite speakers.
- If using optical/coaxial, ensure your TV's audio output is set to PCM/Stereo, not Bitstream/Dolby Digital, as the system may not decode these formats.

- **Distorted Sound:**

- Reduce the volume level on both the system and the connected device.
- Check for loose speaker connections.
- Ensure the audio source is not distorted. Try a different audio source.

- **Bluetooth Connection Issues:**

- Ensure the system is in Bluetooth pairing mode.
- Disable and re-enable Bluetooth on your device.
- Move your device closer to the subwoofer to ensure it's within range.
- Forget "Bobtot B48" from your device's Bluetooth list and try pairing again.

WARRANTY AND SUPPORT

The Bobtot B48 Home Theater System comes with a Limited Warranty. For detailed information regarding warranty coverage, terms, and conditions, please refer to the complete User Manual (PDF) provided with your product or available for download.

For further assistance, technical support, or any inquiries, please visit the official Bobtot Store on Amazon or refer to the contact information provided in your User Manual.

[Download Full User Manual \(PDF\)](#)

[Visit Bobtot Store on Amazon](#)

IMPORTANT SAFETY INFORMATION

Please read and follow all safety instructions carefully before using your Bobtot B48 Home Theater System to prevent electric shock, fire, or injury:

- Do not expose this appliance to dripping or splashing liquids.
- Do not place objects filled with liquids, such as vases, on the apparatus.
- Ensure proper ventilation. Do not block any ventilation openings.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question