



Manuals.plus /

- › Fisher-Price /
- › Fisher-Price Soothing Motions Bassinet (Model GNV76) Instruction Manual

Fisher-Price GNV76

Fisher-Price Soothing Motions Bassinet

Model: GNV76

Brand: Fisher-Price

1. INTRODUCTION

The Fisher-Price Soothing Motions Bassinet is designed to provide a comfortable and calming environment for your newborn. It features gentle swaying motions, a variety of soothing options including light projection, calming vibrations, and gentle songs and sounds. This manual provides essential information for the safe and effective use of your bassinet.



Image: The Fisher-Price Soothing Motions Bassinet, fully assembled with its mobile and control unit.

2. SAFETY INFORMATION

- **Maximum Weight:** This bassinet is suitable for newborns up to 20 lb (9.1 kg). Discontinue use when

the infant begins to push up on hands and knees or has reached 20 lb (9.1 kg), whichever comes first.

- **Safe Sleep:** Always place your baby on their back to sleep. Do not use additional padding or bedding in the bassinet.
- **Breathability:** The bassinet features breathable mesh sides to ensure proper airflow and visibility.
- **Assembly:** Ensure all parts are correctly assembled and securely fastened before each use.

WARNING: Suffocation Hazard - Infants have suffocated in bassinets. NEVER add a pillow, comforter, or another mattress for padding.

3. PACKAGE CONTENTS

Verify that all components are present before assembly:

- Bassinet Frame
- Sleeping Pad with Removable Cover
- Overhead Toy Mobile
- Electronic Control Unit (Lights, Music, Vibrations)
- Storage Shelf (for bottom of bassinet)

4. SETUP AND ASSEMBLY

The bassinet features a snap-in design for easy assembly and disassembly. Follow the manufacturer's instructions provided in the box for detailed steps. Ensure all connections click into place securely.



Image: The Fisher-Price Soothing Motions Bassinet, fully assembled, showcasing its structure and storage shelf.

5. OPERATING INSTRUCTIONS

5.1 Sway Motion

The bassinet is designed to sway gently with your baby's natural motions or with a gentle push from you. An optional lock-out feature is available to keep the bassinet stationary if preferred. To activate the stationary mode, adjust the leg mechanism as per the assembly instructions.

5.2 Electronic Control Unit

The electronic control unit provides various soothing features:

- **Power Button:** Press to turn the unit on/off.
- **Music & Nature Sounds:** Toggle through a selection of gentle melodies and nature sounds (e.g., babbling brook, gentle rain, birds chirping).
- **Volume Control:** Adjust the sound level to your preference.
- **Light Projection:** Activates a starlight pattern that projects onto the ceiling.
- **Night Light:** Provides a soft, gentle light inside the bassinet for visibility without disturbing your baby.
- **Calming Vibrations:** Activates a subtle vibration in the sleeping pad to help soothe your baby. This feature typically runs for 30 minutes before automatically turning off.



Image: The electronic control unit showing illuminated buttons for various soothing functions.

5.3 Toy Mobile

The deluxe overhead mobile features engaging toys (e.g., a monkey, stars) to entertain your baby. The mobile can be easily removed if not desired.




Image: A close-up view of the bassinet's mobile, featuring a monkey toy and star-shaped mirrors.

5.4 Official Product Videos

Video: Why I love this Fisher Price Bed side Sleeper!

Description: This video provides a detailed overview of the Fisher-Price Bedside Sleeper, highlighting its features and benefits from a user's perspective. It demonstrates the bassinet's functionality and design.

Video: Baby Bassinet that has power vibration and manual sway

Description: This video showcases the bassinet's power vibration and manual sway features, illustrating how they contribute to soothing a baby. It offers a practical demonstration of these key functionalities.

6. MAINTENANCE

6.1 Cleaning the Sleeping Pad

The sleeping pad features a removable cover that is machine washable. Always follow the care instructions on the label. For best results, hand wash only.



Image: The removable sleeping pad cover being placed into a washing machine for cleaning.

6.2 Cleaning the Frame and Mesh

Wipe down the bassinet frame and mesh sides with a damp cloth and mild soap. Rinse thoroughly and allow to air dry completely before reassembly or use.

7. TROUBLESHOOTING

- **Electronic Unit Not Working:** Check if batteries are correctly installed and not depleted. Replace

batteries if necessary.

- **Sway Motion Feels Unstable:** Ensure the bassinet frame is fully assembled and all locking mechanisms are engaged. If using the stationary mode, confirm the legs are properly adjusted.
- **Unusual Noises:** Inspect all connections and moving parts for any obstructions or loose components.

8. SPECIFICATIONS

- **Model Number:** GNV76
- **Brand:** Fisher-Price
- **Color:** Multi Color (Snugamonkey style)
- **Material Composition:** Fabric
- **Item Weight:** 27.4 pounds (12.45 Kilograms)
- **Product Dimensions:** 27.01 x 37.01 x 48.03 inches
- **Maximum Weight Recommendation:** 20 Pounds
- **Assembly Required:** Yes
- **Batteries Required:** Yes
- **Product Care Instructions:** Hand Wash Only (for pad cover)

9. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please refer to the documentation included with your product or visit the official Fisher-Price website. Keep your purchase receipt for warranty claims.