

manuals.plus /

> [Richmat](#) /

> [Richmat Wireless Remote Control Model HJH55 Instruction Manual for Adjustable Beds](#)

Richmat HJH55

Richmat Wireless Remote Control Model HJH55 Instruction Manual

For Adjustable Beds

1. INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your Richmat Wireless Remote Control, Model HJH55. Please read this manual thoroughly before use to ensure proper functionality and to avoid potential issues. This remote is designed as a replacement for compatible adjustable bed bases.

2. PRODUCT OVERVIEW

The Richmat Model HJH55 is a wireless remote control designed for use with adjustable bed bases. It serves as a direct replacement for existing HJH55 remotes, including both black and white versions. Ensure your current remote or bed control box specifies 'HJH55' for compatibility before attempting to pair.





Image 2.1: Front view of the Richmat HJH55 wireless remote control. This image displays the general appearance of the remote, which is black with various control buttons for adjustable bed functions.

3. SETUP AND PAIRING INSTRUCTIONS

3.1 Battery Installation

The remote requires two (2) AAA batteries (not included). To install batteries:

1. Open the battery compartment cover on the back of the remote.
2. Insert two AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
3. Close the battery compartment cover securely.



5-6 6AAGC0011

Richmat

Model: HJH55

Contains FCC ID: 2AJJGHJRF

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1)

this device may not cause harmful interference, and (2)

this device must accept any interference received,

including interference that may cause undesired

operation.

C121480H550044
SN: 2022050700005





Image 3.1: Back view of the Richmat HJH55 remote control with the battery compartment open. This image shows the two slots for AAA batteries and the polarity markings.

3.2 Pairing the Remote with Your Adjustable Bed

The remote does not come pre-paired and must be synced with your adjustable bed base. Follow these steps carefully:

1. **On the Remote:** Press and hold the "Head Up" button and the "Foot Up" button simultaneously for approximately 10 seconds.
2. **On the Control Box:** Locate the control box underneath your bed. Press the button on the side of the control box that is typically labeled "Learn" or "Reset Coding." *Do not press and hold this button; a single, brief press is sufficient.*
3. **Confirmation:** Listen for an audible beep from the control box. This beep indicates that the remote has successfully synced with the bed base.

If the remote does not pair, ensure batteries are correctly installed and repeat the steps. If issues persist, refer to the Troubleshooting section.

4. OPERATING INSTRUCTIONS

Once paired, your Richmat HJH55 remote control allows you to adjust your bed to various positions. The specific functions of each button will correspond to the features of your adjustable bed base. Common functions include:

- **Head Up/Down:** Adjusts the head section of the bed.
- **Foot Up/Down:** Adjusts the foot section of the bed.
- **Flat:** Returns the bed to a flat position.
- **Memory Presets:** Some remotes may have buttons to save and recall preferred positions.

Refer to your adjustable bed base's original manual for detailed descriptions of all available functions and button layouts.

5. MAINTENANCE

5.1 Battery Replacement

If the remote's performance degrades or it stops responding, replace the two AAA batteries. Follow the battery installation steps in Section 3.1.

5.2 Cleaning

To clean the remote, use a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

6. TROUBLESHOOTING

- **Remote not responding:**
 - Check if the batteries are correctly installed and have sufficient charge. Replace if necessary.
 - Ensure the remote is within range of the bed's control box.
 - Re-attempt the pairing process as described in Section 3.2.
- **Remote paired but functions incorrectly:**
 - Verify that the remote model (HJH55) matches your original remote or bed control box specifications. Incompatible remotes may pair but not function correctly.

- Try re-pairing the remote.

- **Interference:**

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. If interference occurs, try moving the bed or remote to a different location.

If you continue to experience issues, contact the seller or manufacturer for further assistance.

7. SPECIFICATIONS

Model Number	HJH55
Manufacturer	Richmat
Power Source	2 x AAA Batteries (not included)
FCC ID	2AJJGHJRF
Serial Number	2022050700005
Compatible Devices	Adjustable Beds

8. WARRANTY AND SUPPORT

Specific warranty information for this Richmat HJH55 remote control is not provided in this manual. For details regarding warranty coverage, returns, or technical support, please contact the original seller or the manufacturer directly. Ensure you have your purchase details and the product model number (HJH55) available when contacting support.