

GreenPan CC010671-001

GreenPan Elite 7-in-1 Multi-Function Contact Grill & Griddle User Manual

Model: CC010671-001 | Brand: GreenPan

INTRODUCTION AND OVERVIEW

The GreenPan Elite 7-in-1 Multi-Function Contact Grill & Griddle is a versatile kitchen appliance designed to simplify your cooking experience. Featuring healthy ceramic nonstick plates, this unit offers multiple cooking functions including contact grilling, panini pressing, open grilling, open griddling, mixed grill and griddle, and a dedicated waffle setting (with optional waffle plates). Its intuitive controls and durable construction ensure reliable performance for a variety of meals.

Key Features:

- **Revolutionary Ceramic Nonstick:** Thermolon Volt, a diamond-infused ceramic nonstick coating, is specially designed for modern appliances, offering durability and easy cleaning. It is free of PFAS, PFOA, lead, and cadmium.
- **7-in-1 Design:** Functions as a contact grill, panini press, grill and griddle (open flat), and waffle maker (waffle plates sold separately).
- **Ample Surface Area:** The versatile design allows the unit to open flat, providing a larger cooking area for multi-surface grilling.
- **Adjustable Cover:** The top cover locks in four height positions, accommodating various food thicknesses from maximum contact to melting.
- **Dual Zone Cooking:** Independent temperature controls allow precise heat settings for each plate.
- **Easy to Clean:** Removable plates are dishwasher safe for convenient cleanup.

CHOOSE YOUR HEAT



UNIQUE SHADE CONTROL

EASILY DIAL IN THE PERFECT TEMPERATURE

Figure 1: Overview of GreenPan Elite Multi-Grill, Griddle & Waffle Maker features, including adjustable cover, dual-zone heating, shade control, dishwasher-safe plates, easy-to-read display, one-touch sear power, integrated drip tray, easy storage, and PFAS-free nonstick.

SETUP

Before first use, carefully unpack all components and remove any packaging materials. Ensure all plates are securely installed. Place the unit on a stable, heat-resistant, and dry surface away from walls and heat sources. Ensure adequate ventilation around the appliance.

Initial Cleaning:

1. Remove the cooking plates by pressing the release buttons located on the side of the unit.
2. Wash the plates with warm, soapy water or place them in the dishwasher.
3. Wipe the exterior of the unit with a damp cloth. Do not immerse the main unit in water.
4. Dry all parts thoroughly before reassembling.



HEALTHY CERAMIC NONSTICK

WHAT YOU COOK ON MATTERS.



AWARD-WINNING NONSTICK

CELEBRATED FOR A LEGACY OF INNOVATION



COOK PFAS-FREE

FREE OF HARMFUL FOREVER CHEMICALS



GROUNDBREAKING TECHNOLOGY

PATENTED INNOVATION FOR TOP PERFORMANCE



MORE WAYS TO COOK PFAS-FREE

COOKWARE, ELECTRICS, OVENWARE & MORE

Figure 2: The adjustable cover allows for various cooking positions, from full contact to hovering for melting cheese or delicate items.

OPERATING INSTRUCTIONS

The GreenPan Elite offers intuitive controls for various cooking modes. Always ensure the correct plates are installed for your desired function.

Powering On and Plate Selection:

1. Plug the appliance into a grounded electrical outlet. The display will illuminate.
2. Press the 'Start/Stop' button to turn the unit on.
3. Use the 'Plate Select' dial to choose your heating preference: 'Upper' (top plate only), 'Lower' (bottom plate only), or 'Both' (both plates).
4. For waffle cooking, ensure waffle plates are installed and select 'Waffle' mode using the 'Plate Select' dial.

Temperature and Time Settings:

- Use the 'Temp/Shade' dial to adjust the cooking temperature. The display will show the selected temperature.
- For waffle mode, the 'Temp/Shade' dial controls the waffle shade (light to dark).
- Use the 'Time' dial to set the cooking duration. The unit will preheat to the set temperature and then begin the countdown.
- The 'Sear' button provides a high-heat burst for searing meats, reaching up to 500°F.

KEEP EVERYTHING ORGANIZED



SIMPLE STORAGE

PLATES STORE IN THE UNIT TO MINIMIZE CLUTTER

Figure 3: Detailed view of the control panel, showing the Start/Stop button, Sear button, Plate Select dial, digital display for temperature and time, and Temp/Shade and Time adjustment dials.

PLATE TYPES AND USAGE

The GreenPan Elite comes with reversible grill/griddle plates and supports optional waffle plates, expanding your cooking possibilities.

Grill Plates:

- Ideal for searing meats, grilling vegetables, and creating grill marks on paninis.
- Can be used in contact mode (closed) or open flat for a larger grilling surface.

Griddle Plates:

- The smooth side of the reversible plates is perfect for pancakes, eggs, bacon, and other flat-surface cooking.
- Use in open flat mode for maximum cooking area.

Waffle Plates (Optional):

- Interchangeable plates designed for making Belgian or classic waffles.
- Ensure the unit is in 'Waffle' mode for optimal results.

6-IN-1 DESIGN

COUNTERTOP CONVENIENCE



OPEN GRILL



OPEN GRIDDLE



MIXED GRILL & GRIDDLE



CONTACT GRILL



CONTACT GRIDDLE



WAFFLE SETTING
(waffle plates sold separately)

Figure 4: The appliance opened flat, showcasing its ample surface area for cooking multiple items simultaneously, such as sausages on the grill side and pancakes on the griddle side.

EASY TO CLEAN



DISHWASHER SAFE PLATES

THE REMOVABLE PLATES POP OUT AND RINSE CLEAN

Figure 5: Visual examples of the 6-in-1 cooking modes: Open Grill, Open Griddle, Mixed Grill & Griddle, Contact Grill, Contact Griddle, and Waffle Setting (waffle plates sold separately).

CLEANING AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your GreenPan Elite Multi-Function Contact Grill & Griddle.

Daily Cleaning:

- Always unplug the appliance and allow it to cool completely before cleaning.
- Remove the cooking plates by pressing the release buttons.
- The Thermolon Volt ceramic nonstick plates are dishwasher safe. For best results and to prolong the nonstick coating, hand washing with warm, soapy water and a soft sponge is recommended.
- Wipe the exterior of the unit with a damp cloth. Do not use abrasive cleaners or scouring pads.
- Empty and clean the integrated drip tray after each use.

FOR EVERY MEAL



ADJUSTABLE COVER

TOP COVER LOCKS IN 4 DIFFERENT HEIGHT POSITIONS

Figure 6: The interchangeable grill and griddle plates are made of cast aluminum for optimal heating and superior performance.

KEEP EVERYTHING ORGANIZED



SIMPLE STORAGE

PLATES STORE IN THE UNIT TO MINIMIZE CLUTTER

Figure 7: The removable plates can be easily popped out and rinsed clean, making cleanup simple and efficient.

SPECIFICATIONS

Feature	Detail
Special Feature	Dual Zone Cooking, Non Stick Coating, Removable Surface, Reversible Grill Griddle Plates, Temperature Control
Color	Graphite
Material	Healthy Ceramic Nonstick, PFAS-Free, Aluminum
Brand	GreenPan
Product Dimensions	10"D x 18"W x 6"H
Wattage	1800 watts
Item Weight	2.95 pounds (1.34 Kilograms)

Included Components	Contact Grill and Reversible Nonstick Plates
Style	Contact Grill
UPC	885837056679, 885837038385
Manufacturer	GreenPan
Item model number	CC010671-001
Date First Available	May 22, 2023

TROUBLESHOOTING

If you encounter any issues with your GreenPan Elite Multi-Function Contact Grill & Griddle, please refer to the following common troubleshooting tips:

- **Appliance not turning on:** Ensure the power cord is securely plugged into a working electrical outlet. Check if the 'Start/Stop' button has been pressed.
- **Plates not heating:** Verify that the correct plate selection (Upper, Lower, Both) is chosen and that a temperature has been set. Allow adequate time for preheating.
- **Food sticking to plates:** Although the plates are nonstick, ensure they are clean and properly seasoned if necessary (refer to initial cleaning instructions). Avoid using metal utensils that can damage the nonstick coating.
- **Uneven cooking:** Ensure food is evenly distributed on the plates. For contact grilling, ensure the adjustable cover is set to the appropriate height.
- **Excessive smoke:** This may occur if there is food residue or grease buildup on the heating elements or plates. Ensure thorough cleaning after each use.

For persistent issues not resolved by these steps, please contact GreenPan customer support.

WARRANTY AND SUPPORT

GreenPan stands behind the quality of its products. For detailed warranty information and customer support, please refer to the official GreenPan website or the warranty card included with your product.

Protection Plans:

- Optional 3-Year Protection Plan
- Optional 4-Year Protection Plan
- Optional Complete Protect Plan (monthly billing)

These plans offer extended coverage beyond the standard manufacturer's warranty. Please check the terms and conditions for specific details.

Manufacturer: GreenPan

For further assistance, visit the [GreenPan Store on Amazon](#).

OFFICIAL PRODUCT VIDEOS

Watch these official videos from GreenPan to learn more about your Multi-Function Contact Grill & Griddle:

Video 1: GreenPan 7-in-1 Multifunction Contact Grill. This video provides an overview of the appliance's various functions and capabilities.

Video 2: 7-in-1 Multi Function Griddler and Waffle Maker. This video demonstrates the versatility of the griddler and its ability to make waffles.

Video 3: GreenPan Elite 7-in-1. This video highlights key features and benefits of the GreenPan Elite appliance.