Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TMEOSK 8x5 Ft Grill Gazebo

TMEOSK 8x5 Ft Grill Gazebo Instruction Manual

Model: 8x5 Ft Grill Gazebo | Brand: TMEOSK

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your TMEOSK 8x5 Ft Grill Gazebo. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Figure 1: Overview of the TMEOSK 8x5 Ft Grill Gazebo.

Safety Information

For your safety and to prevent damage to the product, please observe the following:

- Always secure the shelter to the ground using the provided stakes to prevent it from tipping over.
- Take down the grill gazebo when not in use for extended periods or during bad weather conditions (e.g., strong winds, heavy rain, snow) to prolong its lifespan and ensure safety.
- Do not hang heavy objects on the frame or shelves that exceed their weight capacity.
- Keep open flames and heat sources away from the canopy fabric.
- Ensure proper ventilation when using a grill or other heat-producing appliances under the gazebo.

Parts List

Before assembly, verify that all parts listed below are present. If any parts are missing or damaged, please contact customer support.



Figure 2: All components of the grill gazebo. Refer to the included hardware list for specific quantities and identifiers.

The main components include:

- Main support poles (4)
- Roof frame components
- Double-tier canopy fabric (main and top vent)
- Side shelves (2)
- Hooks (10)
- Bottle opener (1)
- Assembly hardware (screws, nuts, washers, Allen wrench, wrench)

Setup and Assembly

Follow these steps to assemble your TMEOSK 8x5 Ft Grill Gazebo. It is recommended that two people perform the assembly.

Step 1: Assemble the Base Frame

Connect the main support poles (A, B, B1) and attach the foot bases (W) using the provided screws (M) and Allen wrench (T). Ensure all connections are secure.

Your browser does not support the video tag.

Video 1: Installation guide for the TMEOSK Grill Gazebo. This video demonstrates the full assembly process.

Refer to the installation video (0:06 - 0:20) for visual guidance on assembling the base poles and attaching the foot bases.

Step 2: Construct the Upper Frame

Assemble the curved upper frame components (C, D) and attach them to the top of the main support poles. Secure with screws (M) and washers (U) as indicated in the diagram.



Figure 3: The assembled metal frame of the grill gazebo, ready for the canopy.

The installation video (0:21 - 0:55) shows how to connect the upper frame sections and secure them to the main poles.

Step 3: Attach the Canopy Fabric

First, assemble the small top vent canopy (L) by inserting its frame pieces (F, F1, G). Then, place the main canopy fabric (K) over the assembled upper frame. Secure the main canopy to the frame using the ties or fasteners provided. Finally, place the small top vent canopy onto the main canopy and secure it.



Figure 4: Close-up of the double-tiered roof design, providing ventilation and weather protection.

The installation video (0:56 - 1:48) demonstrates the process of assembling the canopy frame and attaching both canopy layers.

Step 4: Install Side Shelves, Hooks, and Bottle Opener

Attach the two metal ventilated side shelves (H) to the main support poles using screws (O) and nuts (N). Install the hooks (I) onto the designated bar on one of the shelves. Finally, attach the bottle opener (Y) to one of the main poles using the provided screw (M).



Figure 5: The integrated side shelves, hooks for grilling tools, and a convenient bottle opener.

The installation video (1:49 - 2:20) provides visual instructions for attaching the side shelves, hooks, and bottle opener.

Operating Instructions

Your TMEOSK Grill Gazebo is designed for outdoor cooking and entertaining. The double-tiered roof provides ventilation, allowing smoke and heat to escape while maintaining shade. The two side shelves offer convenient space for food preparation, serving, or holding grilling accessories. The integrated hooks are ideal for hanging grilling tools, and the bottle opener provides easy access for beverages.

Your browser does not support the video tag.

Video 2: A brief overview of the 8x5 Ft Grill Gazebo, showcasing its features and use.

Maintenance

Regular maintenance will extend the life of your grill gazebo:

- **Cleaning:** Clean the canopy fabric with mild soap and water. Rinse thoroughly and allow to air dry completely before storage. Wipe down metal frames with a damp cloth.
- **Storage:** When not in use for extended periods or during harsh weather, disassemble the canopy and store it in a dry, protected area.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Inspect the fabric for any tears or damage and repair as needed.
- **Weather Protection:** The canopy fabric is sun-protection, water-resistant, and flame-retardant. However, it is not designed for extreme weather conditions. Always take down the gazebo during strong winds, heavy rain, or snow to prevent damage.

Troubleshooting

If you encounter any issues with your grill gazebo, consider the following common solutions:

- **Stability Issues:** Ensure all foot bases are properly anchored to the ground using stakes. Verify that all frame connections are securely tightened.
- **Canopy Sagging:** Check that the canopy fabric is correctly stretched and attached to all frame points. Ensure the frame is fully assembled and stable.
- **Missing Parts:** Refer to the parts list and contact customer support if any components were missing upon delivery.

Specifications

Feature	Detail
Brand	TMEOSK
Model Dimensions (L x W x H)	95"L x 59"W x 97"H
Item Weight	46.3 Pounds
Material	Alloy Steel, Metal, Polyester
Frame Material	Alloy Steel, Metal
Water Resistance Level	Waterproof
Ultraviolet Light Protection	True
Assembly Required	Yes
Features	Double-tier vented roof, 2 side shelves, 10 hooks, bottle opener

Dimension




Figure 6: Detailed dimensions of the grill gazebo.

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official TMEOSK website. Keep your purchase receipt as proof of purchase.

© 2024 TMEOSK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C5ZXY3RM

More documents and user manuals: **https://manuals.plus/**