

[Manuals.plus](#) /

> [AZBME](#) /

> RC-709M Replacement Remote Control for Onkyo Receiver TX-SR606 TX-SR607 TX-SR608 RC-880M TS-XR606 SR507 TX-NR626 TX-NR636 RC-866M RC-764M RC-710M RC-879M TX-SR607 RC-737M TX-NR525 TX-NR535 HT-R391

AZBME RC-709M

AZBME RC-709M Replacement Remote Control User Manual

Model: RC-709M

1. INTRODUCTION

This manual provides essential information for the use and care of your AZBME RC-709M Replacement Remote Control. Designed as a direct replacement for various Onkyo AV receivers, this remote offers seamless operation without the need for complex programming.

2. SETUP

2.1 Battery Installation

The RC-709M remote control requires two (2) AAA batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover off.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.





Figure 2.1: Battery compartment of the RC-709M remote control. Insert two AAA batteries as shown.

3. OPERATING INSTRUCTIONS

3.1 Basic Functions

The RC-709M remote control is designed to function immediately with compatible Onkyo receivers without any setup

or programming.

- **Power On/Off:** Press the 'ON/STANDBY' button to power the receiver on or off.
- **Volume Control:** Use the 'VOL +' and 'VOL -' buttons to adjust the audio volume.
- **Input Selection:** Use the 'REMOTE MODE/INPUT SELECTOR' buttons (e.g., DVD, CBL/SAT, CD, MULTICH, AUX, TAPE, TUNER, DOCK, TV, RECEIVER) to switch between different audio/video inputs.
- **Muting:** Press the 'MUTING' button to temporarily silence the audio.
- **Navigation:** Use the directional arrow buttons and 'ENTER' button for menu navigation and selection.
- **Playback Controls:** Use the play, pause, stop, fast forward, and rewind buttons for media playback.





Figure 3.1: Overview of the RC-709M remote control buttons.

3.2 Compatible Models

This remote control is compatible with a wide range of Onkyo receiver models, including but not limited to:

- TX-SR606
- TX-SR607
- TX-SR608
- RC-880M
- TS-XR606
- SR507
- TX-NR626
- TX-NR636
- RC-866M
- RC-764M
- RC-710M
- RC-879M
- RC-737M
- TX-NR525
- TX-NR535
- HT-R391

RC-709M Remote Control Replacement for **Onkyo** AV Receiver



Figure 3.2: The RC-709M functions as a direct replacement for various Onkyo AV receivers.

3.3 Signal and Range

The RC-709M utilizes infrared (IR) technology for control. Ensure a clear line of sight between the remote control and your Onkyo receiver for optimal performance. The remote is designed for long-distance precise control, effective up to 10 meters (33 feet).

Receiver Remote Control

Direct use without setting

Remote control



Strong Signal



Key sensitive



Figure 3.3: The remote offers strong signal and key sensitivity for direct use.

Long distance precise control

Strongest signal by Infrared technology, further transmission for multi-angle induction. Precisely control far from 10 meters / 33 feet.



Figure 3.4: The remote provides long-distance precise control via infrared technology.

4. MAINTENANCE

To ensure the longevity and proper functioning of your remote control:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** Replace batteries promptly when the remote's performance degrades. Remove batteries if the remote will not be used for an extended period to prevent leakage.

5. TROUBLESHOOTING

If you experience issues with your RC-709M remote control, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Remote not responding	Dead or low batteries	Replace batteries with new AAA batteries, ensuring correct polarity.
Remote works intermittently	Obstruction between remote and receiver	Ensure a clear line of sight. Remove any objects blocking the IR signal.
Remote range is reduced	Weak batteries or interference	Replace batteries. Ensure no strong light sources (e.g., direct sunlight, fluorescent lights) are interfering with the IR signal.
Certain buttons do not work	Remote is not compatible with specific receiver function	Verify your Onkyo receiver model is listed as compatible. Some advanced functions may not be supported if your original remote had unique features.
Remote is physically damaged	Impact or liquid exposure	If the remote has been dropped or exposed to liquids, internal components may be damaged. Replacement may be necessary.

6. SPECIFICATIONS

Detailed specifications for the AZBME RC-709M Replacement Remote Control:

Feature	Detail
Model Number	RC-709M
Brand	AZBME
Color	Black
Material	Plastic (ABS)
Function	Infrared Control
Item Weight	3.52 ounces
Package Dimensions	9.8 x 4.53 x 1.54 inches
Max Number of Supported Devices	1
Compatible Devices	Onkyo AV Receivers (specific models listed above)
Country of Origin	China
Date First Available	April 9, 2023



Product Description

Colour

Black

Material

Plastic

Function

Infrared Control

Brand

AZBME

Button Material

ABS,Plastic

Remote Control

Figure 6.1: Key product specifications.

7. WARRANTY AND SUPPORT

This product is a high-quality replacement remote control. For any queries or assistance, please contact the seller, AZBME, through the platform where you purchased the product. They are committed to helping you with any issues you may encounter.