Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GPEESTRAC DD-EARD3

GPEESTRAC True Wireless Earbuds User Manual

Model: DD-EARD3

Introduction

Thank you for choosing GPEESTRAC True Wireless Earbuds. These in-ear headphones are designed for comfort and performance, featuring Bluetooth 5.0 connectivity, IPX5 waterproofing, and a versatile charging case. This manual provides detailed instructions to help you get the most out of your new earbuds.



Image: GPEESTRAC True Wireless Earbuds in their charging case, showcasing the digital battery display.

What's in the Box

- GPEESTRAC True Wireless Earbuds (Left and Right)
- Wireless Charging Case
- USB-C Charging Cable
- Ear-caps (S/M/L sizes, M pre-installed)
- User Manual (this document)

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The charging case features an LED digital display that clearly shows the power level of the case and individual earbuds.

1. Place the earbuds into the charging case. Ensure they are correctly seated.
2. Connect the USB-C charging cable to the charging port on the case and to a power source.
3. The LED display will indicate charging status. A full charge for the case takes approximately 2 hours.
4. The earbuds support 5 hours of playback on a single charge, and the charging case provides additional charges for a total battery life of up to 20 hours.



Image: The charging case with its LED digital power display, showing battery levels for the case and earbuds.

Note: The charging case can also function as a power bank to charge your phone when its power is low, especially useful during travel.

2. Pairing with a Device

The earbuds feature a built-in Bluetooth 5.0 chip for automatic boot and matching.

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "GPEESTRAC Earbuds" (or similar name) in the list of available Bluetooth devices.
4. Select the earbuds to connect. Once connected, you will hear a confirmation tone.
5. The earbuds will automatically reconnect to the last paired device when taken out of the case.



Image: Visual representation of Bluetooth 5.0 technology, highlighting the advanced connectivity of the earbuds.

3. Wearing the Earbuds

The earbuds are designed for an ergonomic and comfortable fit, suitable for all-day wearing without pain.

1. Choose the correct ear-cap size (S/M/L) for a secure and comfortable fit. The M size is pre-installed.
2. Gently insert each earbud into your ear canal.
3. Rotate the earbud slightly until it feels snug and secure. This ensures optimal sound quality and prevents them from falling out during activities.



Image: A person wearing an earbud, illustrating the ergonomic design for a comfortable and secure fit.

Operating Instructions

The earbuds feature multifunctional button control for easy management of your audio and calls.

1. Power On/Off

- **Power On:** Earbuds automatically power on when removed from the charging case.
- **Power Off:** Place earbuds back into the charging case to automatically power off and begin charging.

2. Music Playback

- **Play/Pause:** Single-click either earbud.
- **Volume Up:** Double-click the Right earbud.
- **Volume Down:** Double-click the Left earbud.
- **Next Track:** Long press the Right earbud.
- **Previous Track:** Long press the Left earbud.




Image: An overview of the earbuds' features, including button control, noise canceling, and HiFi sound.

3. Call Management

The earbuds feature CVC noise reduction for crystal-clear hands-free calls and a built-in microphone.

- **Answer/End Call:** Single-click either earbud when a call comes in.
- **Reject Call:** Long press either earbud when a call comes in.



Image: A person using the earbuds during a workout, demonstrating hands-free calling with noise cancellation.

4. Mono and Twin Mode

You can use either earbud independently (mono mode) or both together (twin mode).

- **Mono Mode:** Simply take one earbud out of the case. It will connect independently.
- **Twin Mode:** Take both earbuds out of the case. They will automatically pair with each other and then with your device.



Image: Illustration of the binaural separation design, showing how the earbuds can be used independently.

5. Voice Assistant

The earbuds support voice control for activating your device's voice assistant (e.g., Siri, Google Assistant).

- **Activate Voice Assistant:** Triple-click either earbud.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your earbuds.

1. Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear-caps and clean them with mild soap and water, then dry thoroughly before reattaching.
- Do not use abrasive cleaners or solvents.

2. Water Resistance (IPX5)

The earbuds are IPX5 daily life waterproof, making them suitable for workouts, outdoor sports, and protection against sweat and light rain.



Image: A person in the rain, illustrating the IPX5 waterproof and dustproof rating of the earbuds.

- **Important Note:** The charging case is **not** waterproof. Avoid exposing the charging case to water or moisture.
- Do not submerge the earbuds in water.
- After exposure to sweat or rain, wipe the earbuds dry before placing them back into the charging case.

3. Storage

Store the earbuds in their charging case when not in use to protect them and keep them charged.

- Avoid storing in extreme temperatures (hot or cold).
- Keep away from direct sunlight and high humidity.

Troubleshooting

If you encounter any issues, please refer to the following common solutions:

Problem	Possible Cause	Solution
Earbuds not pairing with device.	Bluetooth is off on device; earbuds not in pairing mode; interference.	Ensure Bluetooth is on. Place earbuds in case, close, then open to re-enter pairing mode. Move closer to device. Forget device on phone and re-pair.
Only one earbud working.	Earbuds not properly paired with each other (twin mode).	Place both earbuds back into the charging case, close the lid, wait a few seconds, then open the lid and take them out together. They should automatically connect to each other.
No sound or low volume.	Volume too low on device/earbuds; earbuds not properly seated; low battery.	Increase volume on both device and earbuds. Adjust earbud position. Charge earbuds and case.
Charging case not charging.	Cable issue; power source issue.	Try a different USB-C cable and/or power adapter. Ensure connection is secure.
Sound quality is poor.	Improper fit; dirty earbuds; distance from device.	Adjust earbud fit and try different ear-cap sizes. Clean earbuds. Reduce distance between earbuds and device.

Specifications

- **Model Name:** Wireless Earbuds
- **Model Number:** DD-EARD3
- **Brand:** GPEESTRAC
- **Connectivity Technology:** Wireless (Bluetooth 5.0)
- **Wireless Communication Technology:** Bluetooth
- **Ear Placement:** In Ear
- **Form Factor:** In Ear
- **Control Method:** Touch, Voice Control
- **Battery Life (Earbuds):** Up to 5 hours per charge
- **Total Battery Life (with Charging Case):** Up to 20 hours
- **Charging Time (Case):** Approximately 2 hours
- **Water Resistance Rating:** IPX5 (Earbuds only, case is not waterproof)
- **Material:** Plastic
- **Product Dimensions:** 1.26 x 5.35 x 6.06 inches
- **Item Weight:** 3.7 ounces (0.11 Kilograms)
- **UPC:** 611558687256

- **Manufacturer:** GPEESTRAC



Image: Close-up of the Bluetooth 5.0 chip and an illustration emphasizing the lightweight design.

Warranty & Support

For warranty information or technical support, please refer to the product packaging or contact GPEESTRAC customer service directly. Details can often be found on the official GPEESTRAC website or through your point of purchase.
You can also visit the GPEESTRAC Store on Amazon for more product information and support resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C61JK4ZG

More documents and user manuals: **https://manuals.plus/**