

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Amico](#) /

› [Amico 30-inch Low Profile Ceiling Fan with Light and Remote Control Instruction Manual \(Model KFM30PLY03R1\)](#)


## Amico KFM30PLY03R1

# Amico 30-inch Low Profile Ceiling Fan with Light and Remote Control Instruction Manual

Model: KFM30PLY03R1 | Brand: Amico

## INTRODUCTION

This instruction manual provides detailed guidance for the safe and efficient installation, operation, and maintenance of your Amico 30-inch Low Profile Ceiling Fan with Light and Remote Control. Please read all instructions carefully before beginning installation and retain this manual for future reference.



Amico ceiling fan installed in a living room, demonstrating its aesthetic appeal and air circulation.

## SAFETY INFORMATION

- Always turn off power at the circuit breaker before installation or servicing.
- Ensure the mounting structure is securely attached to the building structure and can support the fan's weight.
- Do not connect to dimmer switches or fan speed switches to prevent operational malfunctions.
- Ensure fan blades are at least 7 feet above the floor.

- Avoid direct exposure to rain for outdoor installations.

## PACKAGE CONTENTS

Verify that all items are included in your package:

- Fan Motor Assembly
- LED Light Board
- Lampshade
- Fan Blades (3)
- Remote Control with Wall Cradle
- Remote Control Receiver Module
- Mounting Bracket
- Hardware Kit (screws, wire nuts, etc.)
- Instruction Manual



Components of the Amico ceiling fan, including LED light board, lampshade, fan blade, controller, and remote.

## TOOLS REQUIRED

- Phillips Head Screwdriver
- Flathead Screwdriver
- Wire Strippers
- Pliers
- Electrical Tape
- Ladder
- Safety Goggles

## SETUP / INSTALLATION

---

### 1. Assemble Fan Blades

1. Carefully attach each fan blade to the motor assembly using the provided screws. Ensure they are securely fastened.

### 2. Install LED Light Board

1. Connect the wiring from the LED light board to the motor assembly.
2. Secure the LED light board to the motor assembly with the small bolts.

### 3. Connect Remote Control Receiver

1. Plug the wiring from the motor body into the designated ports on the remote control receiver module.
2. Carefully place the receiver module into the motor assembly housing.

### 4. Mount the Fan to the Ceiling

1. **Before starting, ensure power is OFF at the circuit breaker.**
2. Attach the mounting bracket to a standard ceiling junction box using the provided screws. Ensure it is tightly secured.
3. Hang the fan assembly onto the hook provided on the mounting bracket. This allows hands-free wiring.
4. Connect the fan's wiring to the household wiring: white (neutral) to white, black (hot) to black, and green/bare copper (ground) to green/bare copper. Use wire nuts to secure connections.
5. Carefully tuck all wires into the junction box.
6. Align the fan assembly with the mounting bracket and twist to secure it. Fasten any remaining screws to firmly install the fan.



# Easy & Renter-Friendly Installation

No drilling, no damage, no electrician needed.



Fits standard ceiling junction box

## Easy DIY installation

Clear manual & video guide included

## Renter Friendly — No Drilling Needed

Mounts directly to existing junction box



Do not connect to dimmer or fan gear switch.



Easy installation: Fits standard ceiling junction box. Do not connect to dimmer or fan gear switch.

## 5. Attach Lampshade

1. Twist the lampshade clockwise onto the fan assembly to cover the LED light board.

## OPERATING INSTRUCTIONS

Your Amico ceiling fan is controlled by the included remote. Ensure 2 AAA batteries (included) are installed in the remote.

# Remote Control




Remote control features for the Amico 30-inch ceiling fan.

## Remote Control Functions:

- **Fan ON/OFF:** Press the fan icon button to turn the fan on or off.
- **Light ON/OFF:** Press the light bulb icon button to turn the light on or off.
- **Fan Speed:** Select from 6 fan speeds (1-6) using the numbered buttons.
- **Light Dimming:** Use the '+' and '-' buttons to adjust light brightness (10%-100%).
- **Color Temperature:** Choose from 3000K (warm), 4000K (natural), or 6000K (cool) using the dedicated buttons.
- **Reversible DC Motor:** Press the reversible arrow button to change fan direction for summer (downward airflow) or winter (upward airflow).
- **Timer Setting:** Set the fan to turn off automatically after 1, 2, or 4 hours using the timer buttons.
- **Memory Function:** The fan and light will retain the last brightness, color temperature, and fan speed settings when turned off and on via the wall switch or remote.

# Reversible DC Motor

Warm in winter, cool in summer



Reversible DC motor function for summer and winter use.



# Customizable Light

Meet the light demand in different scenarios



200LM

1000LM

2000LM

10%

Dimmable

100%

Customizable light with 3 color temperatures and dimming.

## MAINTENANCE

- Cleaning:** To clean the fan, use a soft brush or lint-free cloth to avoid scratching the finish. Do not use abrasive cleaners.
- Blade Care:** Hand wash blades if necessary.
- Tightening Screws:** Periodically check all screws for tightness.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; loose wire connections; remote control not paired or batteries dead.	Check circuit breaker; ensure all wire connections are secure; replace remote batteries; pair remote with receiver.

Problem	Possible Cause	Solution
Fan is noisy	Loose screws; unbalanced blades; motor noise.	Tighten all screws; ensure blades are balanced; motor noise up to 35dB is normal.
Light does not work	Loose wire connection; faulty LED light board.	Check light wire connections; contact support for LED light board replacement.
Remote control not working	Dead batteries; remote not paired; interference.	Replace batteries; re-pair remote with receiver; ensure no strong interference sources nearby.

## SPECIFICATIONS

- Brand:** Amico
- Model Name:** KFM30PLY03R1
- Color:** White
- Size:** 30 inch
- Product Dimensions:** 30"D x 30"W x 8.66"H
- Electric Fan Design:** Ceiling Fan
- Power Source:** 120V AC input, DC motor
- Wattage:** 35 watts
- Voltage:** 120 Volts (AC)
- Number of Blades:** 3
- Number of Power Levels:** 6
- Noise Level:** 35 Decibels
- Special Features:** 2/4/8H Timer, 3CCT (3000K/4000K/6000K), 6 Speeds, Dimmable, Reversible
- Control Method:** Remote
- Installation Type:** Flush Mount
- Indoor/Outdoor Usage:** Indoor, Outdoor (Not to be exposed directly to rain)
- Item Weight:** 8.51 pounds

## WARRANTY AND SUPPORT

Amico provides a 10-year warranty for the motor and a 2-year warranty for other parts of the ceiling fan. For technical support or any issues during use or installation, please contact Amico customer service. We offer 24-hour technical support.



Warranty details: 10 years for motor, 2 years for other parts.