

[Manuals.plus](#) /

> [AZ GOGO](#) /

> AZ GOGO Professional Electric Nail Drill 35000 RPM User Manual

AZ GOGO JW500

AZ GOGO Professional Electric Nail Drill 35000 RPM User Manual

Model: JW500

INTRODUCTION

Thank you for choosing the AZ GOGO Professional Electric Nail Drill. This device is designed for efficient and precise nail care, suitable for both home use and professional salon environments. With a powerful motor reaching up to 35,000 RPM, adjustable speed, and reversible rotation, it offers versatility for various manicure and pedicure tasks. Please read this manual thoroughly before use to ensure safe and optimal operation.

SAFETY INFORMATION

- Always disconnect the power cord before cleaning or when not in use.
- Do not use the device near water or in damp environments.
- Keep out of reach of children.
- Do not touch the drill bit during operation.
- Ensure the drill bit is securely locked before turning on the device.
- If you experience any discomfort or pain during use, stop immediately.
- Use only approved accessories and replacement parts.
- Avoid dropping the device or subjecting it to strong impacts.

PACKAGE CONTENTS

Please check the package for the following items:

- 1 x Electric Nail Drill Main Unit
- 1 x Handpiece
- 55 x Sanding Bands
- 7 x 3/32" Nail Drill Bits (including 1 ceramic bit)
- 1 x Power Adapter

- 1 x User Manual

Professionelle Elektrische Nagelfräser

- Nagelfräser x 1
- Handstück x 1
- Schleifbänder x 55
- 3/32 Nagelbohrer x 7
- Adapter x 1
- Benutzerhandbuch x 1



Image: Overview of the AZ GOGO Electric Nail Drill and its included accessories.

PRODUCT OVERVIEW

The AZ GOGO Electric Nail Drill consists of a main control unit and a handpiece. The main unit features a speed controller and a direction switch, while the handpiece holds the drill bits.




Image: Main unit controls including handpiece connection, F/R direction button, and speed dial.

The handpiece is designed for comfortable grip and low vibration, ensuring precise control during nail work.

High Speed Up to 35,000RPM

-  Powerful Motor
-  Low Vibration, Low Noise
-  Low Loss, Low Heat Generation
-  Strong Safety Lock



Image: Internal view of the handpiece showing the motor and its features.

SETUP




1. Connecting the Handpiece

Connect the handpiece cable to the designated port labeled 'MOTOR' on the main control unit.

2. Inserting and Changing Drill Bits

Follow these steps to safely insert or change a drill bit:

1. **Open:** Twist the handpiece barrel clockwise until you hear a 'click' sound to unlock the chuck.
2. **Take Out:** Remove the current drill bit (if any).
3. **Insert:** Select the desired drill bit and fully insert its shaft into the handpiece chuck.
4. **Lock:** Twist the handpiece barrel counter-clockwise until you hear a 'click' sound to securely lock the drill bit in place. Ensure the bit is firmly seated before operation.



Easy to use



Image: Step-by-step guide for changing drill bits.

OPERATING INSTRUCTIONS

1. Powering On/Off

Plug the power adapter into a suitable electrical outlet and then into the main unit. Turn the speed control dial clockwise from the 'OFF' position to power on the device.

2. Adjusting Speed

Rotate the speed control dial on the main unit to adjust the rotation speed from 0 to 35,000 RPM. Start with a lower speed and gradually increase it as needed for your specific task and comfort level.

3. Changing Rotation Direction (F/R)

Press the 'R' button on the main unit to switch between forward (F) and reverse (R) rotation. This feature is convenient for both left-handed and right-handed users, and for working on different nail areas. The device will momentarily pause before changing

direction to protect the motor.

4. Using the Drill Bits

The kit includes various drill bits and sanding bands for different applications:

- **Mandrel with Sanding Bands:** For polishing the nail surface.
- **Large Barrel:** For smoothing and polishing thick nails.
- **Small Barrel:** For smoothing and polishing smaller nails.
- **Cone:** For nail carving and polishing.
- **Safety Nail Bit:** For polishing raised surfaces and nail side edges.
- **Ball Bit:** For smoothing out protrusions on the nail surface.
- **Ceramic Drill Bit:** High hardness, no fading, easy to clean, suitable for removing gel polish and dead skin.




Image: Detailed view of the included drill bits and their primary uses.

This nail drill is suitable for various applications including:

- Acrylic Nails
- Dip Powder Nails
- Gel Nails
- Manicure & Pedicure
- Callus Removal
- Dead Skin Removal
- Nail Preparation and Care



Image: Versatile applications of the nail drill.

MAINTENANCE

1. Cleaning the Device

Always unplug the device before cleaning. Use a soft, dry cloth to wipe the main unit and handpiece. Do not use harsh chemicals

or abrasive cleaners. For the handpiece, you can use a small brush to remove dust and nail debris from the chuck area.

2. Cleaning Drill Bits

After each use, clean the drill bits with a brush and disinfect them with an appropriate sterilizing solution. Ensure bits are completely dry before storing.

3. Storage

Store the nail drill and its accessories in a cool, dry place, away from direct sunlight and moisture. Keep the handpiece and bits in their designated holders or cases to prevent damage.

TROUBLESHOOTING

- **Device Not Turning On:** Ensure the power adapter is securely connected to both the main unit and the electrical outlet. Check if the speed dial is turned past the 'OFF' position.
- **Drill Bit Wobbles or Falls Out:** Make sure the drill bit is fully inserted and the handpiece barrel is securely locked in the counter-clockwise position.
- **Reduced Performance/Weak Rotation:** Check for any debris obstructing the handpiece mechanism. Ensure the power supply is stable.
- **Unusual Noise or Vibration:** Stop operation immediately. Check if the drill bit is bent or damaged, or if it is improperly inserted. If the issue persists, contact customer support.
- **Overheating:** If the handpiece or main unit feels excessively hot, turn off the device and allow it to cool down. Ensure proper ventilation around the unit.

SPECIFICATIONS

Model Number	JW500
Brand	AZ GOGO
Material	Aluminum
Maximum Rotation Speed	35,000 RPM
Input Power	15 Watt
Power Source	Corded Electric
Package Dimensions	17 x 11.8 x 11.6 cm
Weight	630 grams
ASIN	B0C61QTHRB
UPC	680577512689

WARRANTY AND SUPPORT

The AZ GOGO Electric Nail Drill comes with a satisfaction guarantee. In case of any defects or issues, please do not hesitate to contact our customer support. We are committed to providing prompt replacement or refund services to ensure your satisfaction. For support, please refer to the contact information provided with your purchase or visit the official AZ GOGO website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question