W-KING H10

W-KING H10 Bluetooth Speaker User Manual

Model: H10

Introduction

Thank you for choosing the W-KING H10 240W Peak Bluetooth Speaker. This powerful and versatile speaker is designed to deliver high-fidelity audio with deep bass, making it ideal for various indoor and outdoor activities. It features multiple connectivity options, a wireless microphone, and guitar input, transforming your space into a concert hall or karaoke stage. Please read this manual carefully to understand the product's features and ensure proper usage and maintenance.

What's in the Box

- W-KING H10 Bluetooth Speaker
- UHF Wireless Microphone
- Remote Control
- Power Adapter
- AUX Cable
- User Manual

Product Features

240W Peak Power & 3-Way 2.1 Stereo Sound System

The W-KING H10 boasts a 240W peak power output with a sophisticated 3-way 2.1 stereo design. It incorporates a large subwoofer, dual mid-range woofers, dual tweeters, and dual bass reflex tubes to deliver a rich, balanced, and powerful audio experience with monstrous bass, accurate mids, and crisp treble.



Internal view of the W-KING H10 speaker, highlighting its five drivers and three-way stereo system for optimal sound distribution.

Customizable Sound with Bass/Treble Adjustment & Equalizers

Fine-tune your audio experience with dedicated control knobs on the top panel. Adjust bass and treble levels (12 levels each) to suit your preference. Additionally, two equalizer modes allow for quick sound profile changes, perfect for different music genres or listening environments.



The speaker's top panel with illuminated knobs for precise control over audio settings, including bass and treble.

All-In-One Microphone & Accompaniment

The included rechargeable UHF wireless microphone offers adjustable volume, treble, bass, and reverb (echo). Choose from four microphone circumstances (Original, Professional, Pop, Reverb) to enhance your vocals. The 'Microphone Priority' function automatically reduces music volume when you speak or sing, allowing your voice to stand out. An accompaniment feature can reduce vocals in songs for karaoke.



Users enjoying the karaoke features, demonstrating the speaker's ability to prioritize microphone audio and provide musical accompaniment.

Guitar Amplifier Functionality

Connect your guitar directly to the speaker via the dedicated guitar input. The powerful 120W amplifier and advanced speaker configuration ensure clear and realistic guitar sound reproduction, making it a versatile amplifier for musicians.



The speaker functioning as an amplifier for both microphone and guitar, suitable for musical performances.

True Wireless Stereo (TWS) Pairing

Pair two W-KING H10 speakers together for a true wireless stereo experience, doubling the audio output to 240W and creating an immersive soundstage for larger gatherings or enhanced listening.



Two W-KING H10 speakers paired for True Wireless Stereo, providing a wider and more powerful sound experience.

Recording & Headphone Monitoring

Record your speeches or singing directly onto a TF card or USB drive inserted into the speaker. Play back recorded files directly from the speaker. For private listening or monitoring your voice, plug headphones into the dedicated headphone jack.



The speaker's recording function allows users to capture their musical or vocal performances directly to a connected storage device.

Live Streaming & Sound Effects

Connect the speaker to your phone via the live cable to integrate music and microphone output into your live streams, enhancing your broadcast with background music (BGM) and clear vocals. The remote control also provides seven built-in sound effects to add wit and engagement to your live content.



The speaker's live streaming capability, allowing integration of audio into mobile broadcasts.

Versatile Connectivity Options

The W-KING H10 offers multiple ways to connect your audio sources, including Bluetooth for wireless streaming, TF card slot, USB port, and an AUX input for wired connections. A remote control is also included for convenient operation from a distance.



Detailed view of the speaker's comprehensive input panel, supporting various audio sources and functions.

Setup

Initial Charging

Before first use, fully charge the speaker using the provided power adapter. The charging indicator will show the charging status and turn off when fully charged.

Powering On/Off

Press and hold the power button on the top panel to turn the speaker on or off.

Bluetooth Pairing

1. Turn on the W-KING H10 speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing Bluetooth icon on the display.
2. Enable Bluetooth on your device (smartphone, tablet, etc.).
3. Search for "W-KING H10" in your device's Bluetooth list and select it to connect.

4. Once connected, the Bluetooth icon will stop flashing, and you will hear a confirmation sound.

Connecting the Microphone

The included UHF wireless microphone is pre-paired. Simply turn on the microphone, and it will automatically connect to the speaker. For wired microphones, connect them to the 'MIC' input port on the speaker's rear panel.

Connecting a Guitar

Plug your guitar cable into the 'GUITAR' input port on the speaker's rear panel.

Using AUX/USB/TF Card

- **AUX:** Connect an audio device using the provided 3.5mm AUX cable to the 'AUX' input port.
- **USB:** Insert a USB flash drive with audio files into the 'USB' port.
- **TF Card:** Insert a TF (microSD) card with audio files into the 'TF' card slot.

The speaker will automatically switch to the corresponding input mode when a device is connected. You can also manually select input modes using the control panel or remote control.

True Wireless Stereo (TWS) Pairing

1. Ensure both W-KING H10 speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the TWS button (usually indicated by two interlocking circles) until you hear a prompt.
3. The primary speaker will search for the secondary speaker. Once connected, you will hear a confirmation sound, and the TWS indicator will light up on both speakers.
4. Now, connect your device to the primary speaker via Bluetooth. Audio will play through both speakers in stereo.

Operating Instructions

Adjusting Audio Settings

- **Volume:** Use the main volume knob on the top panel or the volume buttons on the remote control.
- **Bass/Treble:** Use the dedicated bass and treble control knobs on the top panel to adjust these frequencies.
- **Echo (Reverb):** Adjust the echo effect for the microphone using the corresponding knob.

Microphone Controls

- **MIC Volume:** Adjust the microphone's volume independently.
- **MIC Treble/Bass:** Fine-tune the microphone's tone.
- **MIC Reverb:** Control the amount of echo applied to the microphone.
- **MIC Circumstances:** Switch between Original, Professional, Pop, and Reverb modes for different vocal effects.
- **Microphone Priority:** Press the dedicated button to enable/disable this feature, which lowers

music volume when the microphone is in use.

Accompaniment Function

Press the 'Accompaniment' button (often indicated by a musical note icon) to reduce or remove the lead vocals from a song, making it suitable for karaoke.

Recording Playback

After recording to a TF card or USB drive, you can play back the recorded files directly through the speaker. Use the navigation buttons (play/pause, next/previous track) to manage playback.

Remote Control Usage

The included remote control provides full functionality, allowing you to control volume, track selection, input mode, EQ settings, microphone settings, and activate sound effects from a distance.

Equalizer Modes

Toggle between preset equalizer modes to optimize sound for different content types (e.g., music, movie, vocal) using the EQ button on the speaker or remote.

Maintenance

- **Cleaning:** Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in use for extended periods. Store in a cool, dry place.
- **Storage:** When storing the speaker for a long time, ensure it is fully charged and power it off. Keep it away from extreme temperatures and humidity.
- **Water Resistance:** This speaker is designed for outdoor use but is not waterproof. Avoid exposing it to heavy rain or submerging it in water.

Troubleshooting

Problem	Possible Cause	Solution
No power	Battery is low or dead; Power adapter not connected properly.	Charge the speaker fully. Ensure the power adapter is securely connected to both the speaker and a power outlet.
No sound	Volume is too low; Incorrect input mode selected; Device not connected properly.	Increase the volume on both the speaker and your connected device. Select the correct input mode (Bluetooth, AUX, USB, TF). Reconnect your device.

Problem	Possible Cause	Solution
Cannot pair via Bluetooth	Speaker is already connected to another device; Speaker is too far from the device; Bluetooth is off on the device.	Disconnect from other devices. Ensure the speaker and device are within 33 feet (10 meters). Turn on Bluetooth on your device. Restart both devices.
Microphone not working	Microphone is off; Microphone battery is low; Microphone not paired (wireless); Incorrect MIC volume.	Turn on the microphone. Charge or replace microphone batteries. Ensure wireless microphone is paired. Increase MIC volume on the speaker.
Remote control not working	Remote battery is dead; Obstruction between remote and speaker; Remote is too far.	Replace the remote control battery. Ensure no obstructions. Use the remote within effective range.

Specifications

Feature	Detail
Output Wattage	120 Watts RMS (240W Peak)
Speaker System	2.1 Channel, 3-Way (Subwoofer, Mid-range Woofers, Tweeters)
Connectivity Technology	Bluetooth, AUX, USB, TF Card
Audio Input	Bluetooth, Wireless Microphone, Wired Microphone (6.35mm), Guitar (6.35mm), AUX (3.5mm)
Power Source	Battery Powered (Built-in rechargeable battery)
Item Weight	15.42 pounds (7.01 Kilograms)
Product Dimensions (L x W x H)	5.85 x 14.74 x 9.91 inches
Recommended Use	Indoor/Outdoor
Country of Origin	China

Warranty and Support

W-KING products are designed and manufactured to the highest quality standards. For warranty information, technical support, or any inquiries regarding your W-KING H10 speaker, please refer to

the warranty card included with your purchase or visit the official W-KING website for customer service contact details. Please retain your proof of purchase for warranty claims.