

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ELYONA](#) /

› [ELYONA 10.2" Hammered Pendant Light Fixture \(Model UP3011-2BRS\) - Installation and Care Guide](#)

## ELYONA UP3011-2BRS

# ELYONA 10.2" Hammered Pendant Light Fixture

Model: UP3011-2BRS | Brand: ELYONA

## 1. SAFETY INFORMATION

Please read these instructions carefully before installation and retain them for future reference. All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). If you are unfamiliar with proper electrical wiring connections, consult a qualified electrician.

- Always turn off the power supply at the main circuit breaker before beginning installation.
- Ensure all wiring connections are secure and properly insulated.
- Do not exceed the maximum wattage specified for the bulb (40W).
- This fixture is designed for indoor use only.
- Handle the glass shade and bulb with care to prevent breakage.

## 2. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Pendant Light Fixture (with hammered metal shade and solid wood accent)
- Ceiling Canopy
- Mounting Hardware (screws, wire nuts, mounting plate)
- Instruction Manual

## 3. SPECIFICATIONS


Feature	Detail
Model Name	UP3011-2BRS
Dimensions	Max 54.5" H x 10.2" W x 10.2" D (Shade: 10.2" W x 7.2" H, Wood: 3.94" H)
Material	FSC Certified Solid Wood, Handmade Hammered Brushed Brass Metal
Bulb Base	E26
Max Wattage	40 Watts
Voltage	110 Volts
Installation Type	Semi Flush Mount / Ceiling Mount

Special Features	Adjustable Height, Dimmable (with compatible bulb and dimmer switch, not included)
Certifications	ETL Listed

The fixture features a brushed brass hammered surface and FSC certified solid wood, ensuring durability and a unique aesthetic. It is compatible with LED, CFL, Edison, or incandescent bulbs with an E26 base (bulbs not included).

# Product Specification

(Bulb Not Included)



Max 59.4"  
Hanging Height  
Adjustable.

3.94"

7.2"

10.2"

**RECOMMEND BULBS (A15/A19)**



<b>VOLTAGE</b>	<b>110-220V</b>
<b>FREQUENCY</b>	<b>40W MAX</b>
<b>BASE</b>	<b>E26 Base</b>
<b>MATERIAL</b>	<b>Metal. Wood</b>
<b>COLOR</b>	<b>Brass</b>
<b>CABLE LENGTH</b>	<b>1500mm /59.4in</b>

Flat/Sloped Ceiling

Image: Detailed product dimensions and electrical specifications for the ELYONA pendant light.



Image: Diagram showing the product specifications including dimensions and recommended bulb types.

## 4. INSTALLATION INSTRUCTIONS

---

Follow these general steps for installing your pendant light. Always ensure power is off at the circuit breaker before starting.

- 1. Prepare the Mounting Plate:** Attach the mounting plate to your ceiling junction box using the provided screws. Ensure it is securely fastened.
- 2. Adjust Cord Length:** Determine the desired hanging height for your pendant light. Refer to Section 5 for detailed instructions on how to adjust the cord length.
- 3. Wire Connections:** Connect the fixture's wires to the corresponding wires from the junction box (black to black, white to white, ground to ground) using wire nuts. Ensure all connections are tight and secure.
- 4. Secure the Canopy:** Carefully push the ceiling canopy up against the ceiling, covering the junction box and wiring. Secure it in place with the provided screws or nuts.
- 5. Install Bulb:** Screw in an E26 base bulb (max 40W, not included) into the socket.
- 6. Restore Power:** Turn the power back on at the main circuit breaker.



Image: Two ELYONA pendant lights installed above a kitchen island, showcasing their aesthetic appeal in a modern kitchen setting.

## 5. ADJUSTING CORD LENGTH

The pendant light features an adjustable cord to customize its hanging height. This adjustment is typically done within the ceiling canopy before final installation.

- 1. Loosen the Flat Plastic Screw:** Locate the flat plastic screw on the side of the ceiling canopy. Use a screwdriver to loosen it.
- 2. Adjust the Cord:** Gently pull the cord through the plastic component to either shorten or lengthen the hanging wire to your desired height.
- 3. Secure the Cord:** Once the desired length is achieved, tighten the flat plastic screw to secure the cord in place. Ensure the cord is firmly held and will not slip.
- 4. Manage Excess Wire:** Coil any excess wire neatly inside the ceiling canopy before mounting it to the ceiling.

Video: A step-by-step guide demonstrating how to adjust the length of the pendant light's cord within the ceiling canopy for customized hanging height.

## 6. OPERATION

---

Once installed, the pendant light operates like any standard light fixture. It can be controlled by a wall switch.

- **On/Off:** Use your existing wall switch to turn the light fixture on or off.
- **Dimming Functionality:** If you wish to use a dimming feature, ensure you install a dimmable E26 bulb and connect the fixture to a compatible dimmer switch (both sold separately).



Image: Illustration highlighting the dimmable capability of the pendant light when used with a compatible dimmer switch and dimmable bulb.

## 7. MAINTENANCE

---

Proper care will ensure the longevity and appearance of your ELYONA pendant light.

- **Cleaning:** Simply wipe the metal shade and wood accent with a damp cloth. Dry immediately with a soft, clean cloth. Avoid using harsh chemicals, abrasive cleaners, or household cleaners as they may damage the finish.
- **Wood Maintenance:** The solid wood component has been coated with mineral oil before packaging. To maintain its texture and appearance, it is recommended to apply mineral or olive oil 1-2 times every 3 months.



Image: Visual reminder for product care, emphasizing gentle cleaning and avoiding harsh chemicals.

## 8. TROUBLESHOOTING

---

If you encounter any issues with your pendant light, refer to the following common problems and solutions:

- **Light does not illuminate:**

- Check if the power is on at the circuit breaker.
- Ensure the bulb is correctly installed and not faulty.
- Verify all wire connections are secure.

- **Light flickers:**

- Ensure the bulb is fully screwed in.

- If using a dimmable bulb and dimmer switch, ensure compatibility and proper installation of both.

- **Pendant hangs unevenly:**

- Re-check the cord adjustment within the canopy to ensure it is securely tightened at the desired length.

If problems persist, please contact customer support for assistance.

## **9. WARRANTY AND SUPPORT**

---

ELYONA offers a One-Year Warranty for this product, ensuring a valuable shopping experience. If you have any questions, require technical assistance, or need to claim warranty service, please contact us via the Amazon message box.

For additional information and product offerings, visit the official ELYONA store: [ELYONA Store](#)